



Philips  
Under-the-sink water  
purifier

### Ultrafiltration

2L/min  
No power required

**AUT3234**

## Extra compact size

Extra crisp and pure tasting water

Philips under-the-sink water filtration system AUT3234 comes with 4-stage ultrafiltration, which effectively reduces particles, heavy metals, VOCs, pesticides, bacteria, and pollutants down to 0.1 micron while retaining beneficial minerals.

#### **Crisp and pure tasting water**

- Effectively reduces heavy metals, bacteria and more
- Instant filtration of high water flow
- Long-life filtration

#### **Made easy**

- QuickTwist filter replacement
- Works without power
- Filter lifetime indicator
- Ultimate space-saving design
- No pump, no noise, no waste water

#### **Safety guaranteed**

- Lead-free faucet included

# PHILIPS

Under-the-sink water purifier  
Ultrafiltration 2L/min, No power required

# Specifications

## Filtration performance

- Microplastics reduction
- Chlorine reduction: Yes, up to 99%\*
- Soluble lead reduction: Yes, up to 99%\*
- Turbidity reduction
- Pesticides reduction: up to 99%
- VOC reduction

## Purification system

- Bacteria removal (Coli-group): > 99.999%

## Filter specifications

- Replacement filter cartridge: AUT805/AUT806/

AUT825

## Input water conditions

- Input water quality: Municipal tap water
- Input water temperature: 5-38 °C
- Input water pressure: 0.1-0.4MPa bar

## General specifications

- Rated Water Flow Rate: 2L/min

## Country of origin

- Under-the-sink water purifier: China

AUT3234/97

# Highlights

## Works without power

The purifier works without power, so clean water is always available whenever you turn on the tap.

## QuickTwist filter replacement

Horizontal placement and QuickTwist design for easy filter replacement; no on-site customer service required.

## 4-stage ultrafiltration system

Crisp and pure tasting water starts with Philips new 4-stage ultrafiltration system. It filters out pollutants down to 0.01 micron including up to 99.999% of bacteria\* while retaining beneficial minerals. It also reduces heavy metals, VOCs, pesticides, turbidity, microplastics, and improves the taste of water.

## Filter lifetime indicator

Filter lifetime reminder for optimal performance.

## Lead-free faucet

The water purifier includes a lead-free faucet.

## Space-saving

Extra compact and slim design virtually fits anywhere.

## High water flow

Instant filtration of high water flow - 8 seconds for a glass of water.\*\*

## Long-life filtration

Ultrafiltration filter made of high quality hollow fiber membrane lasts up to 2 years, while the rest filters lasts up to 1 year.\*\*\*

## Ultimate simplicity

No pump, no noise, no waste water.



Issue date 2023-11-01

Version: 1.0.1

EAN: 48 97099 30428 9

© 2023 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)

\* \*\*Based on test result by international testing and certification agency SGS under laboratory conditions.

\*\* \*\*Based on 2 liters/min water flow and a glass of 250ml water.

\*\*\* Assuming 10-liter water consumption per day. Actual filter lifetime depends on the daily usage and local tap water quality.