



Philips  
UV water purifier

Pure water UV

WP3889/01

## Pure water or no water

with Pure Protect Lock

Pure water or no water with Power UV+ remove's bacteria and chlorine. Pure Protect Lock locks your water purifier from dispensing impure water, when the filter reaches lifetime or an error is detected in the purifier.

### **Pure water**

- PureFlush flushes internal pipes and UV chamber of appliance
- Advanced UV technology and activated carbon to purify water

### **Made easy**

- PowerSave ensures low electricity consumption

### **Simplicity**

- Tilt & Twist mechanism for easy filter replacement

### **Guaranteed**

- Conforms to safety standards of Bureau of Indian Standards
- PureProtect alert warns you when filter needs replacement

# PHILIPS

# Specifications

## Purification system

- PLS UV lamp: 9 W

## Design specifications

- Product weight: 3.5 kg
- Product dimensions (L x W x H):  
287x156x422 mm

## Input water conditions

- Min. input water pressure: 0.5 bar

- Min. input water temperature: 5 °C
- Max. input water pressure: 2.0 bar
- Max. input water temperature: 45 °C

## General specifications

- Water flow rate: max 2 l/min
- Voltage: 220-240 V
- Frequency: 50 Hz
- Power rating: 25 W

# Highlights

## Certified by BIS

Product is certified according to microbiological performance standard BIS 14724 and Drinking water standard BIS 10500 by the Bureau of Indian Standards

## Power UV+

Advanced state-of-the-art UV (PLS) technology destroys known waterborne viruses, bacteria, parasites and amoebae while the activated carbon and sediment filter removes turbidity, chlorine, volatile organic chemicals (VOC's), cysts, larger micro-organisms and improves taste.

## PowerSave

This appliance has low electricity consumption and is rated at 25 watts. To make it even more energy efficient, the UV lamp switches off when the appliance has not been used for 10 minutes.

## PureFlush

At the push of button, PureFlush automatically flushes all internal pipes and the UV chamber of the appliance. Ideal for cleaning before first use, after every filter change and whenever the appliance has not been used for some time. Thanks to PureFlush, you can be sure of Pure water even if you have been away for a while.

## PureProtect alert

After 2700 liters of water consumption, PureProtect alert sends out a signal. There will still be enough capacity for another 300 liters after the signal.

## Tilt & Twist

Replacing the filter is something you can easily do yourself thanks to the simple Tilt & Twist mechanism.

