



Philips
Replacement filter for on
tap purifier

Micro Pure



WP3911

Pure water made easy

Micro Pure filter

Advanced filtration system that gives you pure water by removing bacteria, harmful organic compounds and chlorine, while keeping all the good minerals in your water.

Pure water

- Removes all bacteria, harmful organic compounds and chlorine

Simplicity

- Advanced Quick Twist mechanism for easy filter replacement

PHILIPS

Specifications

Purification system

- Bacteria removal: 99.99 %
- Turbidity removal: 3000 liters or approx. 1 year
- VOC Removal
- Chlorine removal: >80 %

Design specifications

- Materials: plastic
- Color(s): white
- Product weight: 150 g
- Product dimensions (L x W x H): 60 x 64 x 105 mm

Filter specifications

- Major filter components: hollow-fiber membrane, granular activated carbon GAC
- Filter lifetime: 2400 L or approx. 8 months

Input water conditions

- Min. input water pressure: 0.7 bar
- Max. input water pressure: 3.5 bar
- Max. input water temperature: 50 °C

General specifications

- Water flow rate: 2 l/min
- Water flow rate: 5 °C

Sustainability

- Packaging: > 90% recycled materials

Country of origin

- Replacement filter: Japan

Highlights

Micro Pure filter

The Micro Pure filter is a multi-filtration system that removes all bacteria, impurities and odors for clean, safe and tasty drinking water. It consists of a hi-tech hollow-fibre membrane, which contains more than 520 billion micro-pores for the efficient removal of 99.99% of all bacteria, and granular activated carbon which removes unpleasant chlorine, bad taste and odors. The filter also preserves all good minerals in the drinking water that are vital for human health.

Quick Twist filter change

The advanced Quick Twist filter change mechanism makes changing the filter quick, easy and secure, bringing sense and simplicity to your water purifier.

