



Philips  
Replacement filter for on  
tap purifier

Pure Taste



WP3961

## Better-tasting water made easy

### Pure Taste filter

Improves the taste of your drinking and cooking water by removing chlorine and other impurities with a silver-coated active carbon system.

#### **Better-tasting water**

- Pure Taste filter for cleaner and better tasting water

#### **Made easy**

- Hi-flow with maximum rate of 2 liters per minute

#### **Simplicity**

- Advanced Quick Twist mechanism for easy filter replacement

# PHILIPS

# Specifications

## Purification system

- Turbidity removal: 3000 liters or approx. 1 year
- Chlorine removal: >80 %

## Design specifications

- Materials: plastic
- Color(s): white
- Product weight: 50 g
- Product dimensions (L x W x H): 44 x 44 x 90 mm

## Filter specifications

- Major filter components: silver-coated GAC
- Filter lifetime: 2000 L or approx. 6 months

## Input water conditions

- Min. input water pressure: 0.7 bar
- Max. input water pressure: 3.5 bar
- Max. input water temperature: 50 °C

## General specifications

- Water flow rate: 2 l/min
- Water flow rate: 5 °C

## Sustainability

- Packaging: > 90% recycled materials

## Country of origin

- Replacement filter: Japan

# Highlights

## Pure Taste filter

The Pure Taste filter removes unpleasant chlorine, bad tastes and smells, as well as large sediment from your tap water, ensuring purer and better tasting water for drinking, cooking and cleaning fruits and vegetables. In addition, the silver-coated active carbon prevents bacteria growth inside the filter, giving you extra safety for your water.

## Hi-flow

This compact water purifier has a maximum flow rate of 2 liters per minute, which makes little change to the normal flow rate of unfiltered water. By simply rotating the water selection lever, you also have a choice of either a stream or a spray of unfiltered water or spray of filtered water.

## Quick Twist filter change

The advanced Quick Twist filter change mechanism makes changing the filter quick, easy and secure, bringing sense and simplicity to your water purifier.

