

Philips
Water purifier

WP3810



Pure water made easy

With MicroClean filter

Compact and easy to install water purifier that gives you pure water by removing bacteria, harmful organic compounds and chlorine while keeping all the good minerals in your water with a MicroClean filter.

Pure water

- Removes all bacteria, harmful organic compounds and chlorine

Made easy

- Hi-flow with maximum rate of 2 liters per minute
- Pure Protect alert shows you when to replace the filter

Simplicity

- Quick Fit tap adapters for easy installation on your tap
- Advanced Quick Twist mechanism for easy filter replacement

Sustainability

- Maximum performance without the need of electricity

PHILIPS

Specifications

Purification system

- Major Filter Components: Granular activated carbon GAC, Hollow-fiber membrane
- Filter Lifetime: 2400 L or approx. 8 months

Purification performance

- Chlorine: >75 %
- Bacteria: 99.99 %
- VOC Removal
- Turbidity removal

Design specifications

- Materials: Plastic
- Color(s): White

Input water conditions

- Min. input water pressure: 7 bar
- Min. input water temperature: 5 °C
- Max. input water pressure: 35 bar
- Max. input water temperature: 50 °C
- Water Flow Rate: on average, 2 l/min

General specifications

- Accessories: 9 QuickFit tap-mounting adapters,

- color coded PureProtect alert
- Replacement filter cartridge: WP3911
- Water selection: Unfiltered stream, Unfiltered spray, Filtered spray

Weight and dimensions

- A-box dimensions (L x W x H): 360 x 450 x 310 mm
- Product weight: 230 g
- Product dimensions (L x W x H): 60 x 137 x 105 mm
- A-box weight: 9.3 kg
- F-box dimensions (L x W x H): 84 x 170 x 140 mm
- F-box weight: 410 g

Sustainability

- Packaging: >90% recycled materials
- User manual: 100% recycled paper

Country of origin

- Water purifier: Japan
- Replacement filter: Japan

Highlights

Micro Pure filter

The Micro Pure filter is a multi-filtration system that removes all bacteria, impurities and odors for clean, safe and tasty drinking water. It consists of a hi-tech hollow-fibre membrane, which contains more than 520 billion micro-pores for the efficient removal of 99.99% of all bacteria, and granular activated carbon which removes unpleasant chlorine, bad taste and odors. The filter also preserves all good minerals in the drinking water that are vital for human health.

Pure Protect alert

The advanced and simple color-coded Pure Protect alert guides users to change the filter on time with maximum simplicity: when the membrane turns dark grey or rusty brown, it is time to replace the filter.

Hi-flow

This compact water purifier has a maximum flow rate of 2 liters per minute, which makes little change to the normal flow rate of unfiltered water. By simply rotating the water selection lever, you also have a choice of either a stream or a spray of unfiltered water or spray of filtered water.

Quick Fit tap adapters

This advanced water purifier comes with a number of tailor-made Quick Fit tap adapters, to help you having an easy and simple installation of your purifier in your tap. Real sense and simplicity.

Quick Twist filter change

The advanced Quick Twist filter change mechanism makes changing the filter quick, easy and secure, bringing sense and simplicity to your water purifier.

No energy consumption

Designed to operate without electricity while offering maximum performance. Supports sustainability.

