

PHILIPS

Pocket projector

PicoPix

110 lumens

with MP4 player



PPX3411



Project your life

This small and light mobile projector can easily be connected to various gadgets, an SD card or a USB stick to access your digital data. The addition of an integrated media player and embedded office viewer makes this PicoPix independent.

Excellent image quality

- LED technology for brilliant colours and high contrast
- Project HD videos and images up to 120" (305cm) in size
- SmartEngine with LED technology

Ultra portable

- Internal battery for playtime up to 2 hours
- Perfect pocket companion weighing only 270 g

High usability

- Integrated office viewer and media player
- Various connections for all common appliances

Specifications

Technology/optical

Display technology: DLP
Light source: RGB LED
LED light source lasts over: 30.000 hours
Native resolution: 854 x 480 pixels
Contrast ratio: 1000:1
Screen size (diagonal): 12" - 120"
Screen distance: 0.5 m - 5.0 m
Internal memory: 4 GB
Integrated MP4 player
Integrated Office/PDF viewer
Brightness with AC: up to 110 lumens

Supported video standards

PAL
 SECAM
 NTSC
 480i/p
 576i/p
 720i/p
 1080i/p

Sound

Internal 1 W sound bar

Connection

Input audio and video: mini HDMI with HDCP; VGA (custom plug with adapter; Component YPbPr (up to 1080i); Composite (CVBS) and Audio;
Output audio: 3.5 mm audio out jack
External Memory: SD/SDHC/SDXC
USB: Connect to mass storage devices
Mini USB: connect to PC, connect to mass storage device, charging
DC-IN: DC jack

Internal media player

Supported video formats: .avi, .mov, .mp4, .mkv; codecs: MJPEG, H263, MPEG4, H264
Supported audio formats: MP3, AC3

Supported photo formats: JPEG, BMP, PNG, GIF

Supported file formats: pdf, ppt/pptx, xls/xlsx, doc/docs

Power Supply

Battery life: Standard mode: 2 hours; Bright mode: 1.5 hours
Internal battery: 7.4V @ 1800mAh
Power adapter: 110-240 V AC, 50-60 Hz, 12 V@2 A for the EU and UK

Dimensions

Packed (W x D x H): 190 x 190 x 80 mm
Unpacked: 105 x 105 x 31.5 mm

Weight

Packed: 1.06 kg
Unpacked (without accessories): 0.270 kg

Temperature range

Operation: 5-40° C
Storage packed: -25-60° C
Storage unpacked: 0-45° C

Relative humidity

Operation: 15-85% RH
Storage packed: 5-93% RH
Storage unpacked: 15-85% RH

Standard package includes

Remote control
 User guide: on internal memory, Internet
 Quick start guide
 Warranty card
 AC-adapter
 Standard mini USB cable
 Carrying case
 PPX3411

Highlights

120" (305cm) image size

Enjoy the biggest mobile screen you ever had and share your HD media content wherever you want. With your PicoPix you are carrying a personal cinema in your pocket.

Internal battery

The PicoPix comes with a compact built-in rechargeable battery for long-lasting power. Up to 2 hours of continuous movie, photo and music playback enjoyment can be achieved on a single charge. This makes the PicoPix your perfect pocket companion.

LED-Technology

Your pictures and videos deserve the best quality when it comes to sharing them with those around you. This is why the PicoPix pocket projector uses high quality LED technology to project your pictures and videos in brilliant colours and breathtaking contrast.

Office viewer

The integrated MP4 Media player supports all common video and audio formats. This makes the PicoPix pocket projector a standalone device. The office viewer also allows you to share all common office files and pdf files.

Pocket companion

With a weight of only 270 g and a slim design your PicoPix pocket projector becomes your lightweight companion for business and private use.

Connections

The PicoPix pocket projector is offering quite a number of connections for your appliances. USB, HDMI, VGA, Component, Composite, SD/SDHC slot and a 3.5 mm Audio output are at your disposal for unlimited entertainment.

