

# PHILIPS

Plain paper fax

FaxPro

primo  
with telephone and copier



PPF725



## Reliable faxing

The new Philips FaxPro725 combines a smart design with sophisticated functions. A large 50-page memory, 50 name dial entries and short dial keys are proof of multifunctionality that is perfectly adapted to all your professional needs.

### Reliable plain paper fax

- stores up to 50 pages

### Economical

- Standby power consumption <1 W
- consumables for 420 pages A4 (available separately)

### Alphanumeric keyboard

- allows quick and comfortable access to the phonebook

### Easy to use copier

- with fine/photo resolution

# Specifications

## Ink-film fax

10-page automatic doc feeder  
 9600 bps modem speed: auto fall back  
 Cordless phone management  
 Easy polling: receive and send  
 Group broadcasting  
 Horizontal resolution: 8 pixels/mm  
 ITU Group 3 compatible: T.30 standard/T.30 new  
 Memory: up to 50 pages  
 Page header: automatic redial  
 Paper tray up to 50 sheets  
 Predefined fax forms  
 Printing method: thermal transfer  
 Sudoku printing with solutions: easy - medium - tough - devil  
 Timer function: send later  
 Vertical resolution fine: 7.7 lines/mm  
 Sending report: with reduced copy first page  
 Vertical resolution standard: 3.85 lines/mm

## Telephone

Caller identification (CLIP)\*  
 Chain dialling  
 Distinctive ringtones\*\*  
 Name dial entries: 50  
 On-hook dialling  
 Outgoing call log print  
 Redial of the last 10 numbers  
 Ringer melodies: 10  
 Short dial keys: 10  
 Alphanumeric phonebook search

## Copier

Fine/photo resolution  
 Grey scales: 16  
 Zoom function (enlarge/reduce)  
 Multi-copy: up to 15 pages

## Accessories

Philips PFA 363: with PLUG'N'PRINT Card / 420 pages A4

## Dimensions

Packed (W x D x H): 313 x 197 x 129 mm  
 Unpacked: 377 x 247 x 200 mm

## Power use

Copy: typ. 15 W  
 Reception: typ. 15 W  
 Stand by: < 1 W  
 Telephone conversation: typ. 4 W  
 Transmission: typ. 15 W

## Weight

Packed (including country kit): 3.1 kg  
 Unpacked (without accessories): 2.4 kg

## Features

Printing method: thermal transfer  
 Corded handset  
 Monthly Fax volume: 15 to 50 pages

# Highlights

## 420 pages A4 consumables

The Philips FaxPro supports the demands of business users who tend to receive many faxes. Therefore, the separately available consumable offers 420 pages A4 regardless of the amount of text on each page.

## Low Standby power

State-of-the-art products nowadays meet customer needs and take also care of environmental aspects. Because of this, the Philips FaxPro consumes less than 1 Watt in Standby mode.

## Page memory

Your Philips FaxPro never loses any faxes. It stores up to 50 pages of incoming messages in case of missing paper or ink film. They remain stored even after a power failure.

## Photo Resolution

Improve the quality of your copies by setting the right resolution. Choose FINE for documents with small text and drawings or PHOTO for documents with photos.

## Quick search

Access the stored directory entries by using the alphanumeric keyboard. Just enter the initial letters of the desired entry and your fax machine will show you the telephone book entry for the corresponding letters.

