Register your product and get support at

# www.philips.com/welcome



### PPX4935



**EN User Manual** 



# **Table of Contents**

Ove	erview3
	Welcome
	About this User's Manual3
	What's in the box3
	Product highlights4
1	General Safety Information5
	Setting up the Device5
	Automatic Temperature Control5
	Repairs6
	Wireless Network (WIFI)6
	Dolby Digital6
	Power Supply6
2	Overview7
	Touchpad8
	Supported Gestures8
	Virtual On-Screen Keyboard9
	Remote Control10
	Overview of the Main Menu11
	Overview of the Options Menu11
3	Initial Operation12
	Setting up the Device12
	Connect Power Supply / Charge Battery12
	Installing or Changing the Batteries of the Remote
	Control12
	Using the Remote Control13
	Initial Setup14
	Turning off the Projector14
	Standby Mode14
	Indication of different POWER button LED color
4	Connect to various Playback Devices15
	Connecting to Devices with HDMI Output15
	Connecting to an iPhone/iPad/iPod15
	Connecting to an Android Smartphone or Tablet
	via MHL cable16
	Screen Mirroring – Connect Phones or Tablets
	wirelessly to share its contents16
	Connecting Headphones or external Speakers
_	(cable connection)17
5	Memory18

	Inserting a Memory Card 18
	Connecting an USB Storage Device
	Connect to a Computer (USB) 19
6	Internet Connection, Wireless Network (WIFI)
	20
	Switching Wireless Networking (WiFi) on/off 20
	Setting up a Wireless Network (WiFi) 20
	Setting up a Wireless Network (WiFi) using the
	Wizard 21
	Wifi Hotspot 21
	Activating WiFi Hotspot 21
	Setting up a WiFi Hotspot 21
	DLNA (Digital Living Network Alliance)
	Switching DLNA on and off 22
	Play Media Using DLNA 22
7	Bluetooth23
	Activate Bluetooth 23
	Set up Bluetooth Parameters
8	Media Playback24
	Media Folder 24
	How to Navigate in the Media Folder 24
	Picture viewer, Slideshow 25
	Music Playback 25
	File Operations in the Media Folder 25
9	Web Browser
10	Android / APPs28
	Starting installed Android Apps28
	Exiting Android
	Installing Android-Apps 28
11	Settings
	Overview of the Menu Functions
12	Service
	Care Instructions for the Battery
	Charge the Device
	Cleaning
	Troubleshooting
13	Appendix
	Technical Data
	Accessories

# Overview

### Welcome

Dear valued customer, thank you for your great decision to purchase this PicoPix pocket projector. We hope you have as much fun using it as we did creating it!

### About this User's Manual

This manual is designed to let you easily find the information you need to get the most out from your pocket projector.

There is no need to read the manual from the beginning to end. But we suggest that you read the chapter's "overview" and "initial operation" as these will give you a first overview how to operate the projector

Follow all safety instructions in order to ensure proper operation of your device.

The manufacturer accepts no liability if these instructions are not followed.

#### Symbols Used



#### Troubleshooting

Tips and tricks that will help you to use your device more effectively and easily.

#### CAUTION!



**Damage to the device or loss of data!** This symbol gives warning of damage to the device and possible loss of data.

#### DANGER!



#### Danger to persons!

This symbol gives warning of danger to persons. Physical injury or damage can result from improper handling.

### What's in the box

- 1—PicoPix Projector
- 2—HDMI cable
- **3**—Power supply
- 4—Remote control
- 5—Pouch
- 6-Quick start guide



### **Product** highlights

#### Smart Engine LED technology

- HD resolution (720p)
- Amazing 350 lumens brightness
- Keystone correction
- Texas Instruments DLP® IntelliBright<sup>™</sup> technology which intelligently boosts image brightness, resulting in brighter, more dynamic images.

#### Built-in 3W power speaker

- brilliant sound with deep bass performance
- 6 Equalizer settings for perfect sound

#### Bluetooth audio-out with aptX®

 aptX® Low Latency audio codec ensures high audio quality and wireless audio/video synchronization

#### Wired connectivity

- HDMI connector for all kind of input devices
- MHL support to share content from your Smartphone or Tablet
- Headphone connector for external speaker or headphones
- High power USB to connect external USB and HDD drives

#### Wireless connectivity

- WIFI b/g/n to easily connect to private or public WIFI networks
- DLNA support to access media files stored on network drives
- WiFiDisplay (Miracast compatible) to wirelessly share content of your Smartphone or Tablet
- Built-in web-browser to share or play internet contents

#### **Multimedia player**

- Supports all widely used picture, audio and video formats
- Micro SD support to have all your media contents always available

#### **Built-in touchpad**

- Multi-touch support for easy navigation
- Pinch & zoom support for pictures and websites

# **1 General Safety Information**

Do not make any changes or settings that are not described in this user manual. Physical injury or damage to the device or loss of data can result from improper handling. Take note of all warning and safety notes indicated.

### Setting up the Device

The unit is for indoor use only. The device should be placed securely on a stable, flat surface. Position all cables in such a way that no one will stumble on them, thus avoiding possible injuries to persons or damage to the device itself.

Do not plug in the device in moist rooms. Never touch the mains cable or the mains connection with wet hands.

The device must have sufficient ventilation and may not be covered. Do not put your device in closed cabinets or boxes.

Do not place the machine on soft surfaces such as tablecloth or carpets and do not cover the ventilation slits. Otherwise the device could overheat or catch fire.

Protect the device against direct sunlight, heat, large temperature fluctuations and moisture. Do not place the device in the vicinity of heaters or air conditioners. Observe the information on temperature and humidity in the technical data.

Do not allow liquids to enter into the device. Switch off the device and disconnect it from the mains supply if liquids or foreign substances end up inside the device. Have the unit inspected by a technical service department.

Always handle the unit with care. Avoid touching the lens. Never place heavy or sharp objects on the projector or the power cable.

If the projector gets too hot or emits smoke, shut it down immediately and unplug the power cable. Arrange for your device to be investigated by a technical service centre. To prevent the spread of fire, open flames should be kept away from the device. Under the following conditions a layer of moisture can appear inside the device which can lead to malfunctions:

- if the device is moved from a cold to a warm area
- after a cold room is heated
- when this device is placed in a damp room.

Proceed as follows to avoid any moisture build-up:

- Seal this device in a plastic bag before moving it to another room, in order for it to adapt to room conditions.
- 2. Wait one to two hours before you take the device out of the plastic bag.

The device should not be used in a very dusty environment. Dust particles and other foreign objects may damage the unit.

Do not expose the device to extreme vibrations as internal components my get damaged.

Do not allow children to handle the device without supervision. The packing materials should be kept out of the hands of children.

### **Automatic Temperature**

### Control

This device includes an automatic thermal management controller. If the internal temperature gets too hot, the fan speed will automatically increase (noise increase), if the temperature still continue to growth, the brightness of your product will decrease and finally the current symbol will appear.



The product will automatically switch off the display after displaying this message during 5s. This kind of behavior should not arrive except if the outside temperature is very high (>35°C).

### Repairs

Do not repair the device yourself. Improper maintenance can result in injuries or damage to the device. Your device must be repaired by an authorized service center. Find details of authorized service centers on the warranty card.

Do not remove the type label from the device as this would void the warranty.

### Wireless Network (WIFI)

The function of security systems, medical equipment or sensitive devices can be disrupted by the transmission power of the device. Observe any usage regulations (or restrictions) in the vicinity of such equipment.

The use of this device can affect the operation of insufficiently shielded medical devices and hearing aids and pacemakers through the release of high frequency radiation. Also consult a doctor or the manufacturer of the medical device to establish whether these are sufficiently shielded from external high frequency radiation.

### **Dolby Digital**

Manufactured under license from Dolby Laboratories. Dolby and the double-D symbol are trademarks of Dolby Laboratories.

### **Power Supply**

Use only the enclosed power adapter (see chapter Appendix / Technical Data). Check whether the mains voltage of the power supply matches the mains voltage available at the setup location. This equipment complies with the voltage type specified on the unit. The capacity of the battery diminishes with time. If the device functions only with the power supply contact an authorized service center to replace the battery.

Do not try to replace the battery yourself. Incorrect handling of the battery or using the wrong type of battery can cause damage to the device or cause injury.

#### DANGER!



Risk of explosion with incorrect type of batteries

Do not try to replace the battery yourself as there is a risk of explosion if the incorrect battery type is used.

Switch the device on or off using the power switch before removing the power supply from the socket.

Turn off the device and remove it from the power supply before cleaning the surface. Use a soft, lint-free cloth. Never use liquid, gaseous or easily flammable cleansers (sprays, abrasives, polishes, alcohol). Do not allow any moisture to reach the interior of the device.

#### DANGER!



**High Power LED** This device is equipped with a high power LED (Light Emitting Diode), which emits very bright light. Possible hazardous optical radiation emitted from this device. Do not stare at operating light source. May be harmful to the eyes.

#### DANGER!

#### Danger of hearing damage

Do not use the device over a longer time at high volume - especially when using headphones.

# 2 Overview

POWER button (hold for 3s to switch on or off)

2—Micro-SD card slot

 Micro-USB port to connect to a computer (data exchange) or to connect external devices like mouse or keyboard via an OTG cable

Audio output - headphone connection or connection for external speakers

**5**—HDMI - HDMI port for a playback device **6**—USB port for a USB storage medium, mouse or keyboard

**7**—DC-IN - Power supply port

8—Remote control signal receiver window

9—Focus wheel to adjust image sharpness

Touchpad for navigation and operation of the PicoPix without remote control



#### Notice

Note that the distance to the projection surface must be a minimum of 0.5 meters and a maximum of 5 meters. If the Pocket Projector is located outside of this range, it will not be possible to focus the image. Turn the focus wheel carefully to avoid damage to the lens.



### Touchpad

The touchpad is a touch-sensitive surface. Touch the touchpad with one or more fingers to move the cursor, navigate in the menu, select menu options or carry out other actions.

**CAUTION!** 



#### Ballpoint pen!

Do not use a ball-point pen or other objects to operate the touchpad. Hard and sharp objects may damage the touchpad.



✿—Calling up the main menu

—Calling up the option menu

→ Move back in menu, move back one directory level / cancel functions



#### Notice

To enter text you can also use standard computer keyboard or mouse. It is possible to use wired models (USB) as well as wireless models (or a wireless Keyboard & Mouse combo) with USB-receiver.

### **Supported Gestures**

Below listed gestures are supported from the touchpad of your PicoPix Projector. There is a short description how to execute it as well as an example of it's usage.



- a. Touch (one-finger press, lift) to select items or type on keyboard
- b. Double touch (one-finger press, lift & one-finger press, lift) to zoom in
- c. Double-touch drag (one-finger press, lift & one-finger press, move & lift) to scroll or zoom in/out
- d. Pinch open (two-finger press, move outwards, lift) zoom in
- e. Pinch close (two-finger press, move inwards, lift) zoom out
- f. Two-finger swipe, scroll, drag (two-finger press, move, lift) scroll in lists or websites, select multiple items

### Virtual On-Screen Keyboard

When you need to enter text (e.g.: when using the web-browser or when required to enter a password), the projector displays a virtual keyboard which can be operated by the touchpad or the remote control.

- 1. Click in the input field using the touchpad, external mouse or the remote control
- 2. The software keyboard appears.



3. Use the touchpad/mouse/remote control to enter the text on the software keyboard.

### **Remote Control**



Short press: set PicoPix to standby mode / wake it up from standby mode
 Long press: Power off the projector
 —Direction Buttons
 Confirms selection
 (•), (•), (•). Navigation keys / navigation in the menus / modify settings
 (•). Modify settings / access quick settings / during music playback: select previous or next title
 (•). During video playback back/next, fast forward/backward
 —Move back in menu, move back one directory level / cancel functions

- 4—Volume keys
- $\bigcirc$ : Decrease the volume
- Mute the sound
- **5**—Call up the option menu
- 6—Call up the main menu

### **Overview of the Main Menu**

- 1. Switch on the device using the **POWER** button (hold it for 3 seconds).
- After the PicoPix has started up, the main menu appears (if you switch on the PicoPix the very first time you will be guided through a short setup procedure)



- Select the desired menu using the navigation keys 
   √, 
   √, 
   √, 
   ∞, 
   √, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞, 
   ∞,
- 4. Confirm with **OK** on the remote control or tap once using the touchpad
- 5. By pressing the 🏠 key you will return to the main menu.
- To modify important settings quickly use the key to enter the options menu
- To browse in menus up/down use the 
   (♥)
   keys in the remote control or use 2-finger
   move on the touchpad



**HDMI/MHL**—Switch to the external video input HDMI or MHL.

**Media Folder**—Display the content of the internal memory and the inserted memory Micro-SD card or USB stick (movies, pictures, music, folder view). Display the content of network drives connected via WIFI/DLNA WiFi Display— Display wirelessly multimedia content from your Smartphone or Tablet on PicoPix (Miracast compatible)

**WWW**—Opens an Internet web-browser.

**APPs**—Shows installed APPs (Android operating system)

**Settings**—Configure settings of the device.

### **Overview of the Options**

#### Menu

To change important settings quickly, you can use the Options Menu, which can be accessed via the **E** key.

The Options Menu is accessible also via movie playback or during a slideshow to change settings without the need to stop playback and enter the Settings Menu.



# **3 Initial Operation**

### Setting up the Device

You should position the device so that it stays flat on a table in front of the projection surface.

In case you need to tilt the projector upwards you can correct the projected image with the built-in keystone correction (Options Menu).

The distance between the projector and the screen determines the actual size of the image.

### Connect Power Supply

1

### **Charge Battery**

#### CAUTION!

Mains Voltage at the Site of

Installation! Check whether the mains voltage of the power supply matches the mains voltage available at the setup location.

- 1. Insert the small plug of the power supply into the socket on the rear side of your device.
- 2. Plug the power supply into the mains.
- During the charging process, the indicator light on the side of the device will be red. When the battery is fully charged, it will turn green.
- 4. Charge the built-in battery completely before using for the first time. This will prolong the life of the battery.



# Installing or Changing the Batteries of the Remote Control

#### DANGER!

•	Risk of Explosion with Incorrect Type
$\triangle$	of Batteries
$\frown$	Only use batteries of type CR2025.

 To access the battery, disengage the locking mechanism (1) and slide out the battery compartment (2).



2. Insert the new battery with the positive pole as shown on the back of the remote control.



3. Push the battery compartment back into the remote control until the locking mechanism engages.





#### Notice

Normally the battery will last for around one year. If the remote control stops working, please replace the battery.

### Using the Remote Control

Point the remote control at the remote sensor on the back of the device. The remote can be used within an angle of 60 degrees and up to 5 meters from the device. When using the remote control, no obstacle should be placed between the remote control and remote sensor.



#### **CAUTION!**

The improper use of batteries can lead to overheating, explosion, risk of fire and injury. Leaking batteries can possibly damage the remote control.

- Never expose the remote control to direct sunlight.
- Avoid deforming, dismantling or charging the batteries.
- Avoid exposure to open fire and water.
- Replace empty batteries immediately.
- If the device is not used for a long time, take out the batteries to prevent leakage and possible damage to the remote control.
- Used batteries should be disposed of according to the recycling regulations of your country.

### **Initial Setup**

 Press the **POWER** button for 3 seconds to turn the device (the power indicator light will light up).



- Turn the device towards a suitable projection surface or wall. Note that the distance to the projection surface must be a minimum of 0.5 meters and a maximum of 5 meters. Make sure the projector is in a secure position.
- 3. Use the focus wheel on the right side to adjust the image sharpness.
- 4. If you switch on the PicoPix the very first time you will be guided through a short setup procedure which includes following settings
  - a) Select language.
  - b) Set time zone and time.
  - c) Select usage of projector (Home or Shop).

Home: for normal use at home Shop: when you choose this option, the projector starts in demonstration mode and automatically displays pictures or videos stored in the internal memory in a loop.

d) Set up WIFI connection.

#### Notice

The demonstration mode can be activated or deactivated in the menu **Settings/ Maintenance/ Demo mode**.

### **Turning off the Projector**

To turn off the PicoPix completely press the **POWER** button for 3 seconds on the device or on the remote control.

### Standby Mode

Set your PicoPix in Standby Mode if you would like to switch it on very quickly again.

To switch the PicoPix to Standby Mode press the **POWER** button on the device or on the remote control shortly (1s). To wake up your PicoPix from Standby Mode, press shortly again on the **POWER** button.



#### Notice

The PicoPix will need some power in Standby Mode. If kept a long time the battery can be empty.

#### CAUTION!

 Please take care to switch your PicoPix completely off before you transport it in a bag as only a short push of the Power button will switch it on and the packed unit can get very hot or damaged.

# Indication of different

### POWER button LED color

- 1. PicoPix in power off status
  - a) No light: AC power adaptor not connected, or internal battery defect.
  - b) Green: Internal battery full charged.
  - c) Red: Internal battery under charging.
- 2. PicoPix in power on status
  - a) No light: Internal battery defect.
  - b) Green: Internal battery normal working.
  - c) Red: Internal battery in low capacity.
- 3. PicoPix in standby status
  - a) Green flash: Standby status.
  - b) Red light with green flash: Internal battery in low capacity.

# **4 Connect to various Playback Devices**

#### Supplied cables

HDMI cable

#### Cables available as accessories

PicoPix MHL cable ..... (PPA1340 / 253641800) Mini DisplayPort cable ..... (PPA1270 / 253520069)

### **Connecting to Devices with**

### HDMI Output

Use the HDMI cable to connect the projector to laptop, DVD/BR player or others devices.

- 1. Switch the device on using the **POWER** button.
- Connect the mini-HDMI plug of HDMI cable to the projector's mini-HDMI socket.
- 3. Connect the HDMI plug of HDMI cable to the HDMI socket of the playback device.
- 4. From the main menu, select HDMI/MHL.



### Connecting to an iPhone/iPad/iPod

Use the iPhone/iPad/iPod-HDMI adapter cable (not supplied) and HDMI cable to connect the projector to an iPhone/iPad/iPod.

- 1. Switch the device on using the **POWER** button.
- Connect the mini-HDMI plug of HDMI cable to the projector's mini-HDMI socket.
- Connect the HDMI plug of HDMI cable to HDMI socket of iPhone/iPad/iPod-HDMI adapter cable.
- 4. Connect the iPhone/iPad/iPod-HDMI adapter cable to the playback device.
- 5. From the main menu, select HDMI/MHL.



### **Connecting to an Android**

### Smartphone or Tablet via

### MHL cable

Use the HML cable (available as accessory) to connect the projector to your Android Smartphone or Tablet.

Make sure that your Phone/Tablet is MHL compatible (www.mhlconsortium.org)

- 1. Switch the device on using the **POWER** button.
- Connect the mini-HDMI plug of MHL cable to the projector's mini-HDMI socket.
- 3. Connect the MHL plug of MHL cable to the playback device.
- 4. From the main menu, select HDMI/MHL.





#### Notice

When MHL is working without AC power supply, the USB power output will be switched off.

# Screen Mirroring – Connect Phones or Tablets wirelessly to share its contents

The screen mirroring feature allows you to mirror your phone or tablet screen on to your projector screen wirelessly to show content stored on your handheld device.

#### Notice

PicoPix and your device must be connected to the same WiFi network

#### Android

Make sure that your Phone/Tablet is Miracast compatible. Please check on the Wi-Fi Alliance-website: (www.wi-fi.org/product-finder) Open Quick Settings (swipe from top to bottom) and activate ScreenMirroring

#### Windows

Make sure that your laptop runs at least Win8.1 and is compatible with Miracast hardware requirements

#### iOS

Screen mirroring can be accessed easily on your iDevice in the Control Center (swipe up from the bottom of screen) – and select "EZCast"

- Switch the device on using the **POWER** button.
- 2. Select Screen Mirroring from the main menu



3. Select the appropriate operating system of your mobile device in the next screen



# a) Android/Windows (Miracast compatible)

- Select on the Wifi Display (Miracast) application of the external device to search for the projector connection
- Example for mobile phones: open Quick Settings - swipe from top to bottom- and activate ScreenMirroring
- In the pop-up menu of the projector select OK to accept the connection.

#### b) iOS

- Activate Screen mirroring on your iDevice and select "EZCast Screen" to share your screen
- Example for mobile phones: open Control Center (swipe up from the bottom of screen) – and select "EZCast Screen" on right side

# Connecting Headphones or external Speakers (cable connection)

- 1. Before connecting the headphones, turn down the volume on the device.
- Connect the headphones to the projector's headphone slot. The device speakers deactivate automatically when the headphones are connected.



3. After connecting the headphones, increase the volume to a comfortable level.

#### DANGER!

#### **Danger of Hearing Damage**

Do not use the device over a longer time at high volume – especially when using headphones. This could lead to the risks of hearing damage. Before connecting the headphones, turn down the volume on the device. After connecting the headphones, increase the volume to a comfortable level.

# **5 Memory**

### Inserting a Memory Card



- Insert a microSD-card with the contacts facing upwards into the microSD slot at the side of the device.
- 2. Insert the Micro-SD card into the slot and push until it snaps into position with a "click"
- 3. Open **Media Folder** on the main screen to access the contents of the memory card
- To remove the memory card push on it (until you hear a "click") and it will eject automatically

### **Connecting an USB Storage**

#### Device



- 1. Connect the USB storage medium to the USB port on the back of the device.
- 2. Open **Media Folder** on the main screen to access the contents of the USB medium

#### DANGER!



Inserting a Memory Device!

Never pull out the memory device while the device is accessing it. This could cause data to be damaged or lost. Switch the device off in order to make sure that the device does not access the memory.

### **Connect to a Computer**

### (USB)

The User Manual and drivers are stored on the internal memory of the PicoPix - use a microUSB cable to connect the Projector to a computer to access these files.

In this way, you are able to copy files back and forth between the internal memory, an inserted memory card and the computer.

- 1. Switch the device on using the **POWER** button.
- 2. After switching on the device the main menu appears.
- 3. Connect the micro-USB plug to the Pocket Projector and the USB plug to the computer.

# i

Notice

You cannot use the memory for media playback when the Pocket Projector is connected to a computer via USB.

- 4. If a memory card has been inserted, it will be displayed as another disk drive.
- 5. You can move, copy or delete data from the computer, the memory card (if inserted) and the internal memory.

# 6 Internet Connection, Wireless Network (WIFI)

The projector can be connected to the Internet via a wireless (WiFi) connection.

Use the procedure below appropriate to the type of connection you want.

#### DANGER!

#### Information on Using WIFI!

The functioning of security systems, medical equipment or sensitive devices can be disrupted by the transmission power of the device. Observe any usage regulations (or restrictions) in the vicinity of such equipment.

The use of this device can affect the operation of insufficiently shielded medical devices and hearing aids and pacemakers through the release of high frequency radiation. Also consult a doctor or the manufacturer of the medical device to establish whether these are sufficiently shielded from external high frequency radiation.

### **Switching Wireless**

### Networking (WiFi) on/off

Wireless networking is deactivated by default. You have the option of turning this function on.

- 1. Switch the device on using the **POWER** button.
- 2. After switching on the device the main menu appears.
- 3. Use the navigation keys to select **Settings**.
- 4. Confirm with **OK**.
- Using () to select Wireless and Networks.
- 6. Confirm with **OK**.

- 7. Using  $\bigcirc / \heartsuit$  to select **WIFI**.
- 8. Confirm with **OK**.
- 9. Modify the settings with  $\bigcirc / \heartsuit$ .
- 10. Confirm with **OK**.
- The  $\bigcirc$  key takes you one step back in the menu.

### Setting up a Wireless

### Network (WiFi)

- 1. Switch the device on using the **POWER** button.
- 2. After switching on the device the main menu appears.
- 3. Use the navigation keys to select **Settings**.
- 4. Confirm with **OK**.
- 5. Using ()/ to select Wireless and Networks.
- 6. Confirm with **OK**.
- 7. Using to select **WIFI Selection**.
- 8. Confirm with **OK**.
- 9. Use ()/ to select the desired wireless network.
- 10. Confirm with **OK**.
- If your wireless network is password protected, an input window appears. Select the input field using the navigation keys of the remote control and press **OK**.
- 12. Enter the password with the virtual keyboard using the navigation keys of the remote control or with an external keyboard.
- 13. Click on Connect.

The  $\bigcirc$  key takes you one step back in the menu.

# Setting up a Wireless Network (WiFi) using the Wizard

You can integrate your device very quickly and easily into an existing wireless network using WiFi Protected Setup (WPS) or using a wireless network scan. Using WPS, all important settings like network name (SSID) are automatically configured and the connection protected with secure WPA Encryption.

#### Using Wi-Fi Protected Set-up (WPS)

Using WiFi Protected Setup (WPS), you can integrate your device into an existing wireless network in two different ways very quickly and easily. You can activate the login with a pin code or using Push Button Configuration (PBC), if your access point (Access Point, Router) supports this method.

#### Using WPS with Push Button

#### Configuration (PBC)

- 1. Switch the device on using the **POWER** button.
- 2. After switching on the device the main menu appears.
- 3. Use the navigation keys to select **Settings**.
- 4. Confirm with **OK**.
- 5. Using (a) / (c) to select Wireless and Networks.
- 6. Confirm with **OK**.
- 7. Using (A) = 0 to select **WIFI Selection**.
- 8. Confirm with **OK**.
- 10. Confirm with **OK**.
- Activate Push Button Configuration on the WIFI access point. The WIFI access point and device connect automatically and create a WPA protected connection.

### Wifi Hotspot



#### Notice

The projector can work as an access point, if no, or only a 3G wireless network is working in the location of use.

You can use the portable Wi-Fi hotspot to share the device's network connection with computers or other devices through the Wi-Fi network.



#### Notice

When the WiFi hotspot mode is activated, it takes priority over other connections.

### **Activating WiFi Hotspot**

- 1. Switch the device on using the **POWER** button.
- 2. After switching on the device the main menu appears.
- 3. Use the navigation keys to select **Settings**.
- 4. Confirm with **OK**.
- 5. Using (a) / (c) to select Wireless and Networks.
- 6. Confirm with **OK**.
- 7. Using  $\bigcirc \bigtriangledown$  to select **WIFI Hotspot**.
- 8. Confirm with **OK**.
- 9. Using (a) / (b) to select Portable WiFi Hotspot.
- 10. Confirm with OK.
- 11. Use  $(\bullet)$  to select **On**.
- 12. Confirm with OK.

The projector is now visible by other Wifi devices.

#### Setting up a WiFi Hotspot

To modify the WiFi hotspot name and define the security level.

- 1. Switch the device on using the **POWER** button.
- 2. After switching on the device the main menu appears.

- 3. Use the navigation keys to select **Settings**.
- 4. Confirm with **OK**.
- 5. Using (a) / (c) to select Wireless and Networks.
- 6. Confirm with **OK**.
- 7. Using  $\bigcirc \bigtriangledown$  to select **WIFI Hotspot**.
- 8. Confirm with **OK**.
- 9. Using (A) to select **Setup WiFi Hotspot**.
- 10. Confirm with **OK**.
- 11. Modify the settings based on actual situation.

Item	Description
Network SSID	Name of the WiFi hotspot.
	This is the name used to
	identify your projector when it is
	detected by another WiFi
	device.
	To modify the name, select the
	field and press OK. With the
	keyboard, enter the new name.
Security	Select among the 3 levels of
	security.
	Open (without security)
	WPA PSK
	WPA2 PSK
Password	Select the field and press <b>OK</b> .
	With the keyboard, enter the
	new password.
Show password	Check the box to display the
	password.

- 12. Using  $\bigcirc / \bigcirc$  to select **Save**.
- 13. Confirm with OK.

## **DLNA (Digital Living**

### Network Alliance)

This device supports DLNA (Digital Living Network

Alliance) to easily share data over a home network, such as videos and photos.

Depending on the DLNA-compatible devices you own, you will be able to e.g.: stream films from your laptop or server to your PicoPix Projector.

### Switching DLNA on and off

The DLNA function is switched on by default. You have the option of turning this function off.

- 1. Switch the device on using the **POWER** button.
- 2. After switching on the device the main menu appears.
- 3. Use the navigation keys to select **Settings**.
- 4. Confirm with **OK**.
- 5. Using (a) / (c) to select Wireless and Networks.
- 6. Confirm with **OK**.
- 7. Using  $\bigcirc / \bigcirc$  to select **DLNA**.
- 8. Confirm with **OK**.
- 9. Modify the settings with  $\bigcirc \bigcirc$ .
- 10. Confirm with **OK**.

The  $\bigcirc$  key takes you one step back in the menu.

### Play Media Using DLNA

If DLNA enabled devices are located in the connected network, then you can access them in media playback and file management by accessing **Media Folder** from Main Menu



# 7 Bluetooth

Your PicoPix comes with aptX® Low Latency audio codec which ensures high audio quality and wireless audio/video synchronization. Just activate the built-in Bluetooth function to connect external speakers to the projector.



#### Notice

The Option menu provides only quick access to prior connected (paired) devices in Bluetooth settings. To pair a device you need to enter settings on the main screen to do the basic setup.

### Activate Bluetooth

- 1. Switch the device on using the **POWER** button.
- 2. After switching on the device the main menu appears.
- 3. Use the navigation keys to select **Settings**.
- 4. Confirm with **OK**.
- Using () to select Wireless and Networks.
- 6. Confirm with **OK**.
- 7. Using  $( ) = ( \mathbf{S} )$  to select **Bluetooth**.
- 8. Confirm with **OK**.
- 9. Using  $\bigcirc / \heartsuit$  to select **On**.
- 10. Confirm with **OK**.

### Set up Bluetooth

#### **Parameters**

- 1. Switch the device on using the **POWER** button.
- 2. After switching on the device the main menu appears.
- 3. Use the navigation keys to select **Settings**.
- 4. Confirm with **OK**.
- 5. Using ()/ to select Wireless and Networks.
- 6. Confirm with **OK**.
- 7. Using  $(\bullet)$  to select **Bluetooth Selection**.
- 8. Confirm with **OK** to enter detailed settings menu
- 9. Activate "Pairing" on your external Bluetooth speaker
- 10. Click "Search for devices" in order to initiate searching for your external speaker

													8	16:20
Bluetooth									ON	SEAR	CH FO	r devi	CES	
		1		to oth	ner Blu	letooth	ı devic	es						
	A	ML-	20U											

- 11. Click on the found speaker shown in the device list to initiate pairing process
- If you are asked to enter a Pairing Code please use the code provided from the speaker manufacturer (you can try 0000 or 1234)

				(	5	16:3
Bluetooth			NO	SEARCH FOR DEVICE	S	
	PAIRE	PPX4935 Only visible to paired devices				
	A	ML-20U Connected				

13. The external speaker will be shown as "connected" in the device list.

# 8 Media Playback

### **Media Folder**

In general the **Media Folder** is used to select movie, picture or music files for playback in the built-in media player.

Enter Media Folder in order to

- access files located in
  - internal memory
    - o connected USB memory devices
    - o microSD card
    - network locations (DLNA)
- select installable "APK" files to install 3<sup>rd</sup> party APPs
- perform file operations (copy, move and delete files)



### How to Navigate in the

### Media Folder

To navigate in the **Media Folder**, use the following keys:

Keys	Action
l l or  ♥	To select folders or files in the
	displayed list.
• or OK	For directories, goes one level
	down.
	For files, starts the selected
	media file.
● or つ	Goes one level up in the
	directory

	structure.
<b>습</b>	Exits to main screen.

In order to optimize the navigation, you can select a file type on the list:

- FOLDERS to view all files (photo, audio, video and installable APPs).
- MOVIES to view videos files only.
- PICTURES to view photo files only.
- MUSIC to view audio files only.
- 1. Switch the device on using the **POWER** button.
- 2. After switching on the device the main menu appears.
- 3. Use the navigation keys to select **Media Folder**.
- 4. Confirm with **OK**.

	Internal Memory	
	🗐 Volume SD	
П	🗒 USB (A:)	
Movie	Twonky Server at vnn90888	
	Serviio (vnn90888)	
Picture		
Music		

- 5. Using ⓐ/♥ to select Folders, Movies, Pictures or Music.
- 6. Confirm with **OK**.
- 7. Using (♥) to select subfolder or file to be played.
- 8. Confirm with **OK**.

#### Notice

Only those videos that are compatible with the projector will be displayed.

### **Picture viewer, Slideshow**



Keys	Action						
	Start / Stop the picture						
	slideshow						
≡	Calls up the Option Menu.						
	Select Picture viewer to						
	setup the slideshow options						
	(see below)						
	Select music files to start a						
00	picture slideshow with						
	background music						
$\langle \rangle$	Rotate the picture						
$\bigcirc$							
<u></u>	Exits to main screen.						



#### **Music Playback**

If you play music files the projection screen will be switched off automatically if no touchpad or remote control input is detected. As soon as you press any key the screen will be switched on again immediately.

You can modify this behavior in Settings or Option Menu by changing **Screen mode** setting in **Music** section.

### File Operations in the

### **Media Folder**

or <b>OK</b> /	Double touch & hold: selects a file (marked with a green tick) Remote control: long-press
	<b>OK</b> button to select first file
	then use right arrow to select
	others
R	Single touch: marks other files
	(only works if at least one file
$\bigcup$	has been selected already)
	Calls up the Option Menu for
	file operations (copy, move or
	delete)



🖀 /storage/ext	ernal_storage/sdcard1/	
	<b>A</b>	
	0 20140224_112307_alex.jpg	
Folder	20140224_122824_alex.jpg	SI-A IN CONTRACTORISM IN A
8-8	0 20140224_123011_alex.jpg	File operation
Movie	0 20140224_123709_alex.jpg	Сору
	0 20140224_123732_alex.jpg	Move
Picture	0 20140224_124532_alex.jpg	Delete
Picture	20140224_124742_alex.jpg	1066 x 800
л	0140224_124747_alex.jpg	28/11/2014
Music	0 20140224_132948_alex.jpg	
-		

#### Supported video file formats

Container	Video codec
*.3gp	MPEG-4, H.263
*.asf	WMV3
*.avi	MPEG-4, DivX, XviD,
	H.263, H.264, VC-1,
	WMV3
*.flv	H.263, H.264
*.m2ts, .ts	H.264, VC-1
*.mkv	H.264, WMV3
*.mp4	MPEG-4, H.263,
	H.264
*.mov	MPEG-4, H.263,
	H.264
*.mts	H.264
*.rm, *.rmvb	RV 8/9/10
*.wmv	WMV3

#### Supported audio file formats

Container	Audio codec
*.mp3	MPEG-1, MPEG-2,
	MPEG-2.5, Audio
	Layer 1/2/3
*.wma	WMA 7/8/9
*.wav	PCM, ADPCM, U-Law
*.ogg, *.oga	Vorbis
*.flac	FLAC
*.alac	ALAC
*.ape	APE
*.aac	AAC, AAC+

### Supported Photo File Formats

Container	Image codec
*.jpg, *.jpeg	JPEG, GIF

*.bmp	BMP	
*.png	PNG	
*.tif	TIF	

# 9 Web Browser

Your PicoPix has a preinstalled WebBrowser which you can access easily from the main menu by clicking on the globe icon (**WWW**).





#### Notice

To easily browse the internet and enter various links or web addresses we recommend connecting an USB mouse or an USB keyboard to the USB port of the projector.

# 10 Android / APPs

Your projector uses an Android operating system allowing you to install additional applications. This enables you to add additional functionality to your device.



#### Notice

As there are a millions of different applications (APPs) available we cannot guarantee that each single one works on your PicoPix projector.

### **Starting installed Android**

### Apps

- 1. Switch the device on using the **POWER** button.
- 2. After switching on the device the main menu appears.
- 3. Use the navigation keys to select APPs.
- 4. Confirm with **OK**.
- 5. Select the APP you want to use and confirm with **OK**.

### **Exiting Android**

Press the  $\hat{\mathbf{\omega}}$  key to return to the main menu.

### Installing Android-Apps

#### **CAUTION!**

#### **Trusted Sources!**

Apps from third party sources may be malicious.

Only use installation packets from trusted sources.

To install other APPs you have 2 options: install the APK file manually or use the pre-installed Aptoide Store to download and install the APPs directly on the device

Manual installation of APK files:

- Download the APK file and save it onto a Micro-SD card or USB stick.
- 2. Insert the Micro-SD card or USB stick into the device.
- 3. Switch the device on using the **POWER** button.
- 4. After switching on the device the main menu appears.
- 5. Use the navigation keys to select **Media Folder**.
- 6. Confirm with **OK**.
- Use the navigation keys to find and select the previously downloaded **APK file** and confirm with **OK**.
- 8. Follow the installation procedure on the screen

Installation of APPs via Aptoide Store:

- 1. Switch the device on using the **POWER** button.
- 2. After switching on the device the main menu appears.
- 3. Use the navigation keys to select **APPs**.
- 4. Confirm with **OK**.
- 5. Select the **Aptoide APP** and confirm with **OK.**
- 6. In the store you can use the search function to find and install your desired application.

# **11 Settings**



#### Notice

With the ≡-key you can call up the **Options Menu** which provides the most important settings. The **Options Menu** is also accessible during media playback to do adjustments right away.

#### **Overview of the Menu**

### **Functions**

#### Wireless and Network

**WiFi** – switching the wireless network (WiFi) off and on.

**WiFi Selection** – select the wireless network with which the device is to connect.

*WiFi Hot Spot* – activate and deactivate WiFi tethering.

VPN settings - set up parameters of VPN.

*Mobile networks* – set up parameters about mobile networks.

DLNA - switching DLNA off and on.

**Bluetooth** – switching the Bluetooth connection off and on.

**Bluetooth Selection** – set up parameters of Bluetooth connection.

#### Image

**Keystone correction** – use / to skew the output image, thereby making it rectangular.

Fit Screen – use / to select the screen mode.

#### Projection mode

*Front* – normal projection; the device is located in front of the projection surface/screen.

*Rear* – rear projection; the device is located behind the projection surface; the image is reflected horizontally.

Front Ceiling - the device is hanging from

the ceiling in an upside-down position; the image is rotated by 180 degrees.

**Rear ceiling** – the device is located behind the projection surface, hanging from the ceiling in an upside-down position; the image is rotated by 180 degrees and reflected horizontally.

**Wall color correction** – color correction of the projected image to adjust to colored projection surfaces.

*Smart Settings* – select predefined settings for brightness / contrast / color saturation. If you modify these settings, the setting is switched to *Manual*.

Brightness – adjust the brightness of image.

Contrast – adjust the contrast of image.

**Saturation** - adjust the color saturation of image. **IntelliBright** – switching the intelliBright<sup>TM</sup> function off and on.

\* intelliBright<sup>™</sup> is a technique from TI (Texas Instruments) DLP® that adaptively enhances dim regions of an image, resulting in brighter and more dynamic image.

#### Sound

Volume - adjust the volume.

**Deep Bass** – switching the deep bass on and off. **Equalizer** – select the equalizer mode. **Key beep** – turn key tones on and off.

#### Video Player

Language – Select the language of video file.Subtitle – Set the subtitle of video file, or switch off.

**Repeat mode** – Set the repeat type for video files: Repeat deactivated (**Off**), repeat only the current video (**Movie**), repeat all videos in a directory (**Directory**), repeat all videos (**AII**).

#### **Music Player**

**Screen mode** – Activate or deactivate the projection during playback.

Repeat - Set the repeat type for music files:

Repeat deactivated (**Off**), repeat only the current song (**Song**), repeat all songs in a directory (**Directory**), repeat all songs (**All**).

**Shuffle** – Activate this function for random playback. Otherwise, playback will take place in sequence.

#### **Picture Viewer**

*Time per slide* – Image viewing time during slide show.

**Repeat** – Set the type of repeat for slide show photos: Repeat off (**Off**), repeat all photos in the directory (**Directory**), repeat all stored photos (**All**).

*Transition effect* – Set image transitions.

**Slideshow order** – Play slide show in order or randomly.

#### System Settings

Date and time - set date and time.

Android Settings – set Android system. Wall paper – Select background images.

Sleep mode – With this function, the projector automatically goes to ECO mode after a specified period of time or at the end of a movie. Brightness mode – select different brightness mode.

#### Language

Select the desired language for the menu.

#### Maintenance

**Reset settings** – Reset settings to factory defaults.

**Online firmware update** - Update firmware. The firmware package will be downloaded from Internet.

**Demo mode** – switching demo mode on and off. **Information** – Display free space in the internal memory and information on the device (Firmware version / Device name / Model / MAC address / IP address / serial number).

# **12 Service**

### **Care Instructions for the**

### **Battery**

The capacity of the battery diminishes with time. You can prolong the life of the battery if you observe the following points:

- Without a power supply, the device operates from the built-in battery. When the battery does not have sufficient capacity, the device turns off. Connect the device to the power supply.
- When the battery does not have sufficient capacity, it will be indicated by the color of the power switch and the battery symbol in the display.
- Charge the battery regularly. Don't store the device with a completely discharged battery.
- Keep the device and the battery away from sources of heat.

### DANGER!

**Do not Replace the Battery Yourself** Do not try to replace the battery yourself. Incorrect handling of the battery or using the wrong type of battery can cause damage to the device or cause injury.

### **Charge the Device**

	Device off	Device on
Connected	The indicator	Device
to the	light on the	remains
power	side of the	turned on.
adapter	device turns	Slow
	red.	charging
	Fast charging	within about
	within about	10 hours.
	3 hours.	When
	When	charging is
	charging is	completed
	completed	the indicator
	the indicator	light turns
	light turns off.	green.

### Cleaning

#### DANGER!

Instructions for Cleaning!

Use a soft, lint-free cloth. Never use liquid or easily flammable cleansers (sprays, abrasives, polishes, alcohol, etc.). Do not allow any moisture to reach the interior of the device. Wipe over the surfaces gently to avoid scratches to the surface..

#### **Cleaning the Lens**

Use a lens brush or lens cleaning paper for cleaning the lens of the projector.

#### DANGER!



Do not use any Liquid Cleaning Agents

Do not use any liquid cleaning agents for cleaning the lens, to avoid damaging the coating film on the lens.

### Troubleshooting

#### **Power Cycling**

If a problem occurs that cannot be corrected with the instructions in this user manual (see also the help below), follow the steps given here.

#### 1. Switch the device off using the **POWER**

button.

- 2. Wait at least ten seconds.
- 3. Switch the device on using the **POWER** button.
- 4. If the problem cannot be solved, please contact our customer service or your retailer.

1. Switch the device off using the <b>POWER</b>	
Problems	Solutions
The Pocket Projector is unresponsive or hung up.	<ul> <li>Long press the POWER button for 10 seconds until the projector is forced to power off.</li> <li>Switch the projector on again.</li> </ul>
The Pocket Projector cannot be switched on.	<ul> <li>Connect the supplied power supply to recharge the internal battery.</li> <li>Wait for 10 minutes, then switch on the projector.</li> </ul>
No sound.	• Adjust the volume using the •/+ keys on the remote control.
No sound from the external connected device.	<ul> <li>Check the cables to the external device.</li> <li>Set the volume on the external device.</li> <li>Only the original cables from the device manufacturer may work properly</li> </ul>
Bad sound quality with a computer connection.	<ul> <li>Check if the audio cable is connected to the computer line-out socket.</li> <li>The volume setting on the computer should not be too high.</li> </ul>
Only the initial screen appears and not the image from the external device.	<ul> <li>Check if the cables are connected to the right sockets.</li> <li>Please check that the external device is switched on and output is set to HDMI</li> </ul>
Only the initial screen appears and not the image from the connected computer.	<ul> <li>Check if the cables are connected to the right sockets.</li> <li>Check if the resolution of the computer is set to 1280*720.</li> </ul>
Device turns off	<ul> <li>When the device is running for a long period of time, it may get hot and a warning symbol appears on the screen. The device automatically turns off when it gets too hot. After the device has cooled down, it can be switched on and used again.</li> <li>When the battery does not have sufficient capacity, the device turns off. Connect the device to the power supply.</li> </ul>

	<ul> <li>The projector has APD (Auto Power Down) mode for power saving. If stays in main menu for 30 minutes without any operation, the projector will go to stand-by mode automatically.</li> </ul>
Device changes from maximum level of brightness	• When the environment temperature is too high,
to a lower level of brightness during playback.	the device turns automatically from maximum
	level of brightness to a lower level of brightness
	in order to protect the high power LEDs.
Bad image or color quality when connecting with	Use the supplied HDMI cable. Third-party
HDMI.	cables may cause signal distortions.
The device cannot read a microSD card or USB	The device does not support exFAT file
stick.	system, please use FAT format instead.

# 13 Appendix

### **Technical Data**

Dimensions (L×H×W115 × 32 × 115 mm
Weight 0,351 kg
Recommended Ambient
Relative Humidity
File format 3gp, *.asf, *.avi, *.flv,
*.m2ts, *.ts, *.mkv, *.mp4,
*.mov, *.mts, *.rm, *.rmvb, *wmv
Photo formatsJPEG, BMP, PNG, GIF, TIF
Music formats MP2, MP3, WAV, WMA,
OGG, OGA, FLAC, ALAC,
APE, AAC, M4A
Video connectionMini-HDMI socket
Headphone connection Stereo,
3.5 mm socket
Internal speakermono 3 W

Internal speakermo	no 3 W
Internal memory	4 GB
Compatible Memory Card Micro-SD (T	F) card
Standard USB port max. power	

5 V <del></del> , 1000 mA
Micro USB port max. power 5V, 500mA
MHL port max. power 5V, 1000 mA

#### Technology / optical

Display technology	720P 0.3" DLP®
Light source	RGB LED
Native resolution	1280 x 720 Pixel (16:9)
Supported Resolutions	VGA/SVGA/WVGA
	XGA/WXGA/FULL HD
Projected image size	15 - 150 inch
	38 – 381 cm
Screen distance	0.5 - 5 m
Display refresh rate	60/50 Hz

#### **Power supply**

Model No	HKA04519024-XA
Input	.100-240 V, 50/60 Hz, max. 1.2 A
Output	
Manufacturer	Huntkey

#### Built-in rechargeable battery

Battery type	Lithium-Polymer
Capacity	.2000 mAh 7.4 V
Charging time	3 h
Operating time	1.5 h
Manufacturer	Fujian United

### Accessories

Following accessories are available for your device:

PicoPix MHL cable ..... (PPA1340 / 253641800) Mini DisplayPort cable . (PPA1270 / 253520069) PicoPix cover ...... (PPA4400 / 253641813)

All data are provided for reference purposes only. **Sagemcom Documents SAS** reserves the right to make any changes without prior notice. €

The CE marking certifies that the product meets the main requirements of the European Parliament and Council directives 1999/5/CE, 2006/95/CE, 2004/108/CE and 2009/125/CE on information technology equipment, regarding safety and health of users and regarding electromagnetic interference.

The declaration of compliance can be consulted on the site <u>www.picopix.philips.com</u>.

Preservation of the environment as part of a sustainable development plan is an essential concern of Sagemcom Documents SAS. The desire of Sagemcom Documents SAS is to operate systems observing the environment. The desire of Sagemcom Documents SAS is to operate systems observing the environment and consequently it has decided to integrate environmental performances in the life cycle of this products, from manufacturing to commissioning use and elimination.



**Packaging:** The presence of the logo (green dot) means that a contribution is paid to an approved national organization to improve package recovery and recycling infrastructures. Please respect the sorting rules set up locally for this kind of waste.

**Batteries:** If your product contains batteries, they must be disposed of at an appropriate collection point.

**Product:** The crossed-out waste bin stuck on the product means that the product belongs to the family of electrical and electronic equipment. In this respect, the European regulations ask you to dispose of it selectively:

- At sales points in the event of the purchase of similar equipment.
- At the collection points made available to you locally (drop-off center, selective collection, etc.).

In this way you can participate in the re-use and upgrading of Electrical and Electronic Equipment Waste, which can have an effect on the environment and human health.

The paper and cardboard packaging used can be disposed of as recyclable paper. Have the plastic

wrapping recycled or dispose of it in the non-recyclable waste, depending on the requirements in your country.

**Trademarks:** The mentioned references in this manual are trademarks of the respective companies. The lack of the trademarks (a) and (a) does not justify the assumption that these dedicated terminologies are free trademarks. Other product names used herein are for identification purposes only and may be trademarks of their respective owners. Sagemcom Documents SAS disclaims any and all rights in those marks.

Neither Sagemcom Documents SAS nor its affiliates shall be liable to the purchaser of this product or third parties for damages, losses, costs, or expenses incurred by the purchaser or third parties as a result of accident, misuse, or abuse of this product or unauthorized modifications, repairs, or alterations to this product, or failure to strictly comply with Sagemcom Documents SAS operating and maintenance instructions.

Sagemcom Documents SAS shall not be liable for any damages or problems arising from the use of any options or any consumable materials other than those designated as original Sagemcom Documents SAS / PHILIPS products or Sagemcom Documents SAS / PHILIPS approved products.

Sagemcom Documents SAS shall not be held liable for any damage resulting from electromagnetic interference that occurs from the use of any interface cables other than those designated as Sagemcom Documents SAS / PHILIPS products.

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of Sagemcom Documents SAS. The information contained herein is designed only for use with this product. Sagemcom Documents SAS is not responsible for any use of this information as applied to other devices.

This user manual is a document that does not represent a contract.

Errors, printing errors and changes are reserved. Copyright © 2015 Sagemcom Documents SAS



PHILIPS and the PHILIPS' Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used by Sagemcom under license from Koninklijke Philips N.V. © 2015 Sagemcom Documents SAS All rights reserved

#### Sagemcom Documents SAS

Documents Business Unit Headquaters: 250, route de l'Empereur 92848 Rueil-Malmaison Cedex • FRANCE Tel: +33 (0)1 57 61 10 00 • Fax: +33 (0)1 57 61 10 01 www.sagemcom.com Simplified Joint Stock Company • Capital 8.479.978€ • 509 448 841 <u>RCS</u> Nanterre

PPX4935 EN VERSION A