

PHILIPS

Plain paper fax

FaxPro

voice
with answering machine



PPF755



Reliable faxing

The new Philips FaxPro755 combines a smart design with sophisticated functions. A large 50-page memory, 200 name dial entries and short dial keys are proof of multifunctionality that is perfectly adapted to all your professional needs.

Reliable plain paper fax

- stores up to 50 pages

Economical

- Standby power consumption <1 W
- consumables for 420 pages A4 (available separately)

Alphanumeric keyboard

- allows quick and comfortable access to the phonebook

Digital answering machine

- records up to 30 minutes

Easy to use copier

- with fine/photo resolution

Specifications

Ink-film fax

10-page automatic doc feeder

Cordless phone management

Easy polling: receive and send

Group broadcasting

Horizontal resolution: 8 pixels/mm

ITU Group 3 compatible: T.30 standard/T.30 new

Memory: up to 50 pages

Page header: automatic redial

Paper tray up to 50 sheets

Predefined fax forms

Printing method: thermal transfer

Sudoku printing with solutions: easy - medium - tough - devil

Timer function: send later

Vertical resolution fine: 7.7 lines/mm

Sending report: with reduced copy first page

Vertical resolution standard: 3.85 lines/mm

14,400 bps modem speed: auto fall back

Telephone

Caller identification (CLIP)*

Chain dialling

Distinctive ringtones**

Name dial entries:: 200

On-hook dialling

Outgoing call log print

Redial of the last 10 numbers

Ringer melodies:: 10

Short dial keys:: 10

Hands-free speaking

Alphanumeric phonebook search

Copier

Fine/photo resolution

Grey scales: 64

Zoom function (enlarge/reduce)

Multi-copy: up to 15 pages

Accessories

Philips PFA 363: with PLUG'N'PRINT card / 420 pages A4

Dimensions

Packed (W x D x H): 313 x 197 x 129 mm

Unpacked: 377 x 247 x 200 mm

Power use

Copy: typ. 15 W

Reception: typ. 15 W

Stand by: < 1 W

Telephone conversation: typ. 4 W

Transmission: typ. 15 W

Weight

Packed (including country kit): 3.1 kg

Unpacked (without accessories): 2.4 kg

Answering Machine

Current call recording

Direct message access:: first 9 messages

Message forwarding

Pre-recorded OGM

Recording time:: up to 30 minutes

VIP-Code

SMS Function over the landline

Broadcasting:: up to 5 recipients

Draft printing of SMS

Print and save SMS:: up to 30

Send and receive SMS:: over the landline

SMS notification

SMS forwarding

Features

Answering machine

Corded handset

Monthly Fax volume: 15 to 50 pages

Printing method: thermal transfer

Highlights

420 pages A4 consumables

The Philips FaxPro supports the demands of business users who tend to receive many faxes. Therefore, the separately available consumable offers 420 pages A4 regardless of the amount of text on each page.

Low Standby power

State-of-the-art products nowadays meet customer needs and take also care of environmental aspects. Because of this, the Philips FaxPro consumes less than 1 Watt in Standby mode.

Page memory

Your Philips FaxPro never loses any faxes. It stores up to 50 pages of incoming messages in case of missing paper or ink film. They remain stored even after a power failure.

Photo Resolution

Improve the quality of your copies by setting the right resolution. Choose FINE for documents with small text and drawings or PHOTO for documents with photos.

Quick search

Access the stored directory entries by using the alphanumeric keyboard. Just enter the initial letters of the desired entry and your fax machine will show you the telephone book entry for the corresponding letters.

Recording time

Never miss a message thanks to the possibility of recording up to 30 minutes. New messages on your FaxPro are indicated by the flashing message button on the panel.

