



Philips Series 1200
Fully automatic
espresso machines

- 2 beverages
- Classic Milk Frother
- Matte black
- Touch display

EP1220/04

2 delicious coffees from fresh beans, with ease

Thanks to the intuitive touch display

Enjoy the delicious taste and aroma of coffee from fresh beans, at the perfect temperature, thanks to our intelligent brewing system. The classic milk frother allows you to create a silky smooth cappuccino or latte macchiato with ease.

A variety of coffees customized to your taste

- Delicious milk froth thanks to the classic milk frother
- Easily adjust to your taste with 12-step grinder levels
- Adjust aroma strength and quantity via My Coffee Choice
- Easy selection of your coffee with intuitive touch display

High quality coffee from fresh beans

- 20,000 cups of finest coffee with durable ceramic grinders
- The perfect temperature, aroma and crema cup after cup**

Effortless use and cleaning for everyday enjoyment

- Easy cleaning thanks to fully removable brew group
- Up to 5000 cups without descaling thanks to AquaClean
- Dishwasher safe parts for your convenience
- Automatic descaling for your convenience

PHILIPS

Highlights

Classic milk frother



The Classic Milk Frother dispenses steam, allowing you to easily prepare silky smooth milk froth for your cappuccino. What's more? With only two parts, the Classic Milk Frother is also easy to clean.

AquaClean filter



By changing the filter after being prompted by the machine, you will not need to descale your machine for up to 5000 cups, while enjoying clear and purified water.

Intuitive touch display

The irresistible taste and aroma of coffee from fresh beans is just one touch away. Our intuitive touch display allows you to easily select your favorite coffee.

My Coffee Choice

Adjust the strength and quantity of your beverage with the My Coffee Choice menu. Easily choose from three different settings to suit your preferences.

12-step grinder adjustment



Our durable ceramic grinders can be adjusted in 12 steps, so you can turn your beans into anything from ultra-fine powder to coarse grindings.

Perfect temperature and aroma



The Aroma Extract system intelligently strikes the optimum balance between brewing temperature and aroma extraction by keeping the water temperature between 90 and 98°C, while regulating the water flow rate, so you can enjoy delicious coffees.

100% ceramic grinders



Bring out the full flavor of your coffee with our hard-wearing ceramic grinder. Our sharp-edged

grinders extract the best aroma and flavour from your beans. Made from 100% ceramic material which ensures they last for at least 20.000 cups.

Removable brew group



The brew group is the heart of every fully automatic coffee machine, and should be cleaned regularly. The removable brew group allows you to clean it thoroughly just by rinsing it under the tap.

Automatic descaling alarm

It's easy to clean and maintain your coffee machine with the automatic program which notifies when you have to descale it. You can adjust the frequency of this procedure to match the water hardness at home.

Dishwasher safe parts



For your convenience, you can put the milk system, drip tray and the coffee ground container in the dishwasher. This will save time and ensure a hygienic cleaning.

Specifications

Country of origin

- Designed in: Italy
- Made in: Romania

Customization

- Grinder Settings: 12
- Pre Brew Aroma control
- Temperature settings: 3

Variety

- Beverages: Espresso, Hot water, Coffee
- Coffee Powder Option
- Double Cup
- Milk Double Cup: No

Other features

- Removable brew group
- Guided descaling
- AquaClean

Accessories

- Included: Grease tube, Measuring scoop, Water hardness test strip

Technical specifications

- Voltage: 120 V
- Cord length: 100 cm
- Frequency: 60 Hz

- Capacity milk carafe: X L
- Capacity water tank: 1.8 L
- Capacity waste container: 12 servings
- Coffee bean capacity: 275 g
- Weight of product: 7.5 kg
- Waste container: Frontal access
- Water tank: Frontal access
- Filter compatibility: AquaClean
- Pump pressure: 15 bar
- Color & Finishing: Black
- Product dimensions: 246x371x433 mm

General specifications

- Adjustable spout height: 85 - 145 mm
- Milk Solution: Classic Milk Frother
- Ease of cleaning & maintenance: AquaClean filter compatible
- Dishwasher safe parts: Classic milk frother, Drip tray
- User Interface: Touch screen display

Service

- 2-year guarantee

Sustainability

- ECO setting
- Energy label: A-class
- Power consumption brewing: 1500 W
- Recyclable packaging material: >95 %



Issue date 2023-07-17

Version: 3.3.1

UPC: 0 75020 08617 4

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

* Based on 8 filters replacement as indicated by the machine. Actual number of cups depends on selected coffee varieties, rinsing and cleaning patterns.

* *Based on 70-82 °C.