



Philips
Replacement filter for on
tap purifier

Pure Taste

WP3961

Better-tasting water made easy

Pure Taste filter

Improves the taste of your drinking and cooking water by removing chlorine and other impurities with a silver-coated active carbon system.

Better-tasting water

- Pure Taste filter for cleaner and better tasting water

Made easy

- Hi-flow with maximum rate of 2 liters per minute

Simplicity

- Advanced Quick Twist mechanism for easy filter replacement

PHILIPS

Specifications

Purification system

- Turbidity removal: 3000 liters or approx. 1 year
- Chlorine removal: >80 %

Design specifications

- Materials: plastic
- Color(s): white
- Product weight: 50 g
- Product dimensions (L x W x H): 44 x 44 x 90 mm

Filter specifications

- Filter lifetime: 2000 L or approx. 6 months
- Major filter components: silver-coated GAC

Input water conditions

- Min. input water pressure: 0.7 bar
- Max. input water temperature: 50 °C
- Max. input water pressure: 3.5 bar

General specifications

- Water flow rate: 2 l/min
- Water flow rate: 5 °C

Sustainability

- Packaging: > 90% recycled materials

Country of origin

- Replacement filter: Japan

Highlights

Pure Taste filter

The Pure Taste filter removes unpleasant chlorine, bad tastes and smells, as well as large sediment from your tap water, ensuring purer and better tasting water for drinking, cooking and cleaning fruits and vegetables. In addition, the silver-coated active carbon prevents bacteria growth inside the filter, giving you extra safety for your water.

Hi-flow

This compact water purifier has a maximum flow rate of 2 liters per minute, which makes little change to the normal flow rate of unfiltered water. By simply rotating the water selection lever, you also have a choice of either a stream or a spray of unfiltered water or spray of filtered water.

Quick Twist filter change

The advanced Quick Twist filter change mechanism makes changing the filter quick, easy and secure, bringing sense and simplicity to your water purifier.



Issue date 2023-01-14

Version: 4.3.1

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com