



**Saeco Minuto
Super-automatic
espresso machine**

- Brews 7 coffee varieties
- Integrated milk jug & frother
- Silver
- 5 step adjustable grinder

HD8773/47

Always your favorite beverage at just one touch

With the one-click removable brewing group

Only the Saeco Minuto super-automatic espresso machine delivers the real first bean to cup experience with maximum convenience, top-notch performances and large capacities in extra compact dimensions

Ease of cleaning and maintaining

- Always a clean machine thanks to auto-clean and descaling

Ease of cleaning and maintaining

- Easy cleaning thanks to dishwasher-safe parts

A variety of coffees customized to your taste

- The strength selection remembers just how strong you like it


High comfort is part of the experience

- The fully removable brewing group can be cleaned in no time

Advanced technology designed for coffee perfection

- 20,000 cups of finest coffee with durable ceramic grinders
- Fine-tune the coffee's richness with 5 grinder settings

 **Saeco**



Highlights

Dishwasher-safe parts



For your convenience, you can put the Saeco's drip tray and milk frother or milk carafe in the dishwasher. This will save time and ensure a hygienic cleaning.

Auto cleaning and descaling



Saeco designed this espresso machine to automatically clean its coffee circuit with water upon starting up or switching off of the machine, this delivers a great, fresh taste with each cup of coffee. Regular descaling prolongs your espresso machine's life. This machine will not only prompt when descaling is needed, the automated descaling process will start on your machine and guides you with clear on-screen messages when you have to intervene. Descaling has never been so easy!

5-steps adjustable grinders



When it comes to the fineness of the grind, this machine never fails to satisfy. Different coffee blends require different levels of granularity for the full flavor to unfold. So the grind granularity of this machine has five adjustable settings - from the finest grind for a full-bodied espresso, to the coarsest for a lighter coffee.

100% Ceramic grinders



Our grinders are made of high-tech ceramic: exceptionally hard and precise. Fresh beans are gently ground, without risk of overheating: extracting all the best flavors and aroma, delivering a superior coffee taste for at least 20,000 cups.

Removable brewing group



Efficiency and ease of use were key inspirations when Saeco invented the first brewing group 30 years ago. And to this day, it still proves to be an inspired, resolute piece of technology. As always, it's so simple to clean – just remove it and wash it under the tap for a few seconds, then re-insert it just as easily.

Memo Function



Once you've chosen your ideal strength from the 5 different settings, you can easily save it with the Memo Function, as well your desired length and temperature. Then every cup in the future will be customised exactly to your taste. You'll never have to remind it again, unlike the local barista.

Super-automatic espresso machine

Brews 7 coffee varieties Integrated milk jug & frother, Silver, 5 step adjustable grinder

HD8773/47

Specifications

Country of origin

- Made in: Europe

Technical specifications

- Voltage: 120 V
- Capacity bean container: 250 g
- Cord length: 0.8 m
- Frequency: 60 Hz
- Capacity milk carafe: 500 L
- Capacity water tank: 1.8 L
- Capacity waste container: 15 servings
- Pump pressure: 15 bar
- Max. cup height: 152 mm
- Water boilers: 1
- Pump pressure: 15 bar

Design

- Color: Silver, Black

Weight and dimensions

- Dimensions of product (WxDxH): 215 x 429 x 330 mm
- Weight of product: 8.9 kg

General specifications

- Suitable for: Whole coffee beans, ground coffee powder
- Cups at the same time: 2
- Ease of cleaning & maintenance: Automatic carafe

cleaning, Automatic de-scaling cycle, Removable brewing group, Dishwasher-safe parts, Automatic rinse cycle

- Customizing per drink: Adjustable coffee strength, Adjustable cup volume, Adjustable temperature
- Ease of use and comfort: Automatic shut-off, Display, Automatic stand-by, Removable spout, Removable drip-tray, Removable water tank
- Special functions: Integrated carafe, Ceramic grinder, Pre-brewing, CoffeeSwitch
- Type of boiler: Quick heat boiler
- Type of carafe: Basic carafe
- Type of display: LCD
- Coffee drinks: Espresso, Cappuccino, hot water, Café Crème, frothed milk, Espresso Macchiato, Latte Macchiato

Finishing

- Material of main body: Plastic
- Material boiler: Stainless steel (Inox)
- Material drip tray: Stainless steel
- Material water tank: Plastic

Service

- 1-year guarantee

Sustainability

- Power consumption brewing: 1900 W



Issue date 2023-08-22

Version: 1.1.1

UPC: 0 75020 03534 9

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com