

Saeco Moltio
Focus Super-
automatic espresso
machine

- 7 Beverages
- Classic Milk Frother
- Black
- 5 step adjustable grinder



HD8767/47



Every moment deserves its coffee flavor

Changing beans is now one click away

The Moltio espresso machine, a unique masterpiece crafted to offer a tailored taste experience. Thanks to our exclusive bean switcher, preparing the right coffee that always matches your mood and the occasion will be as easy as a click

Ease of cleaning and maintaining

- Always a clean machine thanks to auto-clean and descaling

Ease of cleaning and maintaining

- Easy cleaning thanks to dishwasher-safe parts

Set the beverages to suit your taste

- Experiment with flavors thanks to the coffee bean switcher


Set the beverages to suit your taste

- Save your favorite coffee settings

A variety of coffees customized to your taste

- Fine-tune the coffee's richness with 5 grinder settings

 **Saeco**



Highlights

Coffee bean switcher



You can now change beans with only one click thanks to the patented exchangeable bean container. Enjoy the convenience of quickly changing the beans blend and find the perfect fit for every taste preference and moment of the day.

Saves your coffee settings



You will always get a perfect cup of espresso brewed just for you, according to your personal preference, thanks to our innovative memo function to adjust the coffee length, strength and temperature. Enjoy a superb coffee drink in your favorite cup with just the press of a button.

Dishwasher-safe parts



For your convenience, you can put the Saeco's drip tray and milk frother or milk carafe in the dishwasher. This will save time and ensure a hygienic cleaning.

Auto cleaning and descaling



Saeco designed this espresso machine to automatically clean its coffee circuit with water upon starting up or switching off of the machine, this delivers a great, fresh taste with each cup of coffee. Regular descaling prolongs your espresso machine's life. This machine will not only prompt when descaling is needed, the automated descaling process will start on your machine and guides you with clear on-screen messages when

you have to intervene. Descaling has never been so easy!

100% Ceramic grinders



Our grinders are made of high-tech ceramic: exceptionally hard and precise. Fresh beans are gently ground, without risk of overheating: extracting all the best flavors and aroma, delivering a superior coffee taste for at least 20,000 cups.

5-steps adjustable grinders



When it comes to the fineness of the grind, this machine never fails to satisfy. Different coffee blends require different levels of granularity for the full flavor to unfold. So the grind granularity of this machine has five adjustable settings - from the finest grind for a full-bodied espresso, to the coarsest for a lighter coffee.

Specifications

Country of origin

- Made in: Europe

Technical specifications

- Voltage: 230 V
- Capacity bean container: 290 g
- Cord length: 0.8 m
- Frequency: 50 Hz
- Capacity water tank: 1.9 L
- Capacity waste container: 15 servings
- Max. cup height: 142 mm
- Water boilers: 1
- Pump pressure: 15 bar

Design

- Color: Black, Silver

Weight and dimensions

- Dimensions of product (WxDxH): 256 x 470 x 350 mm
- Weight of product: 8.5 kg

General specifications

- Cups at the same time: 2
- Suitable for: Whole coffee beans, ground coffee

powder

- Ease of cleaning & maintenance: Automatic de-scaling cycle, Automatic rinse cycle, Dishwasher-safe parts, Removable brewing group
- Ease of use and comfort: Removable spout, Removable bean container, Removable drip-tray, Removable water tank
- Special functions: Ceramic grinder, Hot water option, Manual milk frother Pannarello, Pre-brewing, Waterfilter option
- Coffee drinks: Espresso, Cappuccino, hot water, Café Crème, frothed milk, Espresso Macchiato, Latte Macchiato

Finishing

- Material of main body: Plastic
- Material boiler: Stainless steel (Inox)
- Material panarello: Stainless steel

Service

- 1-year guarantee

Sustainability

- Power consumption brewing: 1850 W



Issue date 2023-08-22

Version: 1.1.2

UPC: 0 75020 05113 4

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com