



Philips Saeco Intelia
Super-automatic
espresso machine

- Classic Milk Frother
- Black

HD8751/47

One touch espresso and coffee

With 100% ceramic grinders

Only the Saeco Intelia super-automatic espresso machine offers you the perfect Espresso experience, easy to use, easy to customize, easy to clean. Prepare a tasty Espresso or creamy milk froth with just a touch of a button.

Authentic Italian coffee perfection

- Delicious milk froth thanks to the classic milk frother
- Coffee without burnt taste thanks to 100% ceramic grinders
- Coffee without waiting thanks to the quick heat boiler

Ease of cleaning and maintaining

- Always a clean machine thanks to auto-clean and descaling
- Easy cleaning thanks to removable brewing group

Ease of cleaning and maintaining

- Easy cleaning thanks to dishwasher-safe parts


Set the beverages to suit your taste

- Save your favorite coffee length and strength

Set the beverages to suit your taste

- Avoid heat loss and fit every cup with our adjustable spout
- Play with the coffee's richness with our adjustable grinders

 **Saeco**



Highlights

100% ceramic grinders



This espresso machine is equipped 100% ceramic grinders. Saeco uses ceramic grinders because of their consistent grind without overheating the coffee bean for an impeccable espresso. Ceramic also ensures long-lasting performance and a totally silent operation.

Quick heat boiler



The Saeco quick heat boiler technology ensures your machine is always ready. Now you won't have to wait between brewing each espresso, but can prepare coffee after coffee.

Classic milk frother



This Saeco espresso machine comes with the classic milk frother that baristas call a "Pannarello". It dispenses steam and is immersed in milk to prepare gorgeous milk foam. Unleash your inner barista by preparing your delicious milk specialties the traditional way!

Saves coffee length & strength



You will always get a perfect cup of espresso brewed according to your personal preference, thanks to our memo function which allows you to adjust the coffee length and strength to suit

your taste. Enjoy a superb coffee drink in your favorite cup with just the press of a button.

Adjustable spout



The adjustable spout on our espresso machines will fit every cup and thus prevents the coffee splashing or cooling down while pouring in your cup. This way your espresso is always served at the right temperature while maintaining a clean machine.

Dishwasher-safe parts



For your convenience, you can put the Saeco's drip tray and milk frother or milk carafe in the dishwasher. This will save time and ensure a hygienic cleaning.

Specifications

Features

- Brita Filter compatible: Optionable
- Hot water / Steam Nozzle
- Pannarello: Plastic
- Simultaneous brewing

Perfect Espresso

- Espresso technology: Saeco adapting system, Aroma-system: pre-brewing

Energy saving

- Energy saving: Automatic stand-by

Technical specifications

- Supported coffee types: Ground coffee, Whole coffee beans
- Cord length: 80 cm
- Power: 1900 W
- Boiler material: Stainless steel (Inox)
- Country of origin: Designed in Italy, Made in Europe
- Water pressure in pump: 15 bar (perfect espresso)
- Number of water boilers: 1 boiler
- Removable brewing group

Design

- Colour: Black
- Materials and finishing: Plastic

Weight and dimensions

- Coffee bean capacity: 300 g
- Product dimensions (L x D x H): 256 x 340 x 440 mm
- Product weight: 8.9 kg
- Waste container capacity: 10 servings
- Maximum cup height: 130 mm
- Water tank capacity: 1.5 L

Easy to use

- Usage: Adjustable coffee dispenser, Cup holding surface, Rapid steam, Removable brewing group, Normal / long espresso option
- Cleaning and maintenance: Automatic coffee circuit rinse, Descaling cycle

Service

- 1-year guarantee



Issue date 2023-08-22

Version: 1.1.1

UPC: 0 75020 02546 3

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com