

Philips PicoPix  
Pocket projector

**Wireless**  
50 lumens

**PPX4350W**



# Project your life

## PicoPix pocket projector

With HDMI, USB and micro SD slot it's easy to project videos and pictures. The PicoPix supports wireless screen mirroring with iOS, Android & Windows devices. With Bluetooth audio function it can be connected to Bluetooth speakers.

### **Excellent image quality**

- Project HD videos and images up to 60" (152 cm) in size
- WavEngine with LED technology

### **USBQuickLink**

- USB plug & socket for power and to play videos

### **High usability**

- HDMI interface, micro SD slot, integrated media player
- Support of MHL for mobile devices

### **Wireless connectivity**

- Bluetooth function & Wi-Fi dongle for screen mirroring

# PHILIPS

# Specifications

## Technology

- Display technology: DLP WavEngine
- Light source: RGB LED
- LED light sources: Last over 30.000 hours
- Brightness: up to 50 lumens
- Contrast ratio: 1300:1
- Resolution: 640 x 360 pixel
- Throw ratio: 2,2:1
- Screen size (diagonal): 25 cm-152 cm / 10"-60"
- Screen distance: 48 cm-285 cm / 19"-112"
- Aspect ratio: 16:9
- Projection modes: front, front ceiling, rear, rear ceiling
- Wall color correction: blue, green, pink, white, yellow
- Focus adjustment: Manual
- Integrated media player
- Internal memory: 4 GB
- Noise level: < 28 dba

## Connection

- Wi-Fi: Via dongle
- Bluetooth: Connects PPX 4350 to external bluetooth speakers
- HDMI: mini HDMI with HDCP
- USB: Slave - mass storage device (x-change data with PC); Master - connect mass storage devices; Charging
- Output audio: 3.5 mm audio out jack for headphones
- External Memory: micro SD/SDHC

## Sound

- Internal speaker: 1 Watt (max)
- Supported audio formats: mp3, wav

## Dimensions

- Packed (W x D x H): 130 x 86 x 65 mm / 5.12 x 3.39 x 2.56 inch
- Unpacked (W x D x H): 97 x 54 x 17 mm / 3.81 x 2.12 x 1.00 inch

## Weight

- Packed: 192 g / 6.17 oz
- Unpacked: 129 g / 4.14 oz

## Standard package includes

- User guide: on internal memory
- Warranty card
- Quick start guide
- PPX 4350 Wireless
- Mini-HDMI to HDMI cable
- Wi-Fi dongle

## Power source

- Internal battery: Internal battery: 1800mA, Optimal mode: 1.5 hours, Eco mode: 2 hours

## Temperature range

- Operation: 5 ~ 35° C
- Storage packed: -25 ~ 60° C
- Storage unpacked: 0 ~ 45° C

## Relative humidity

- Operation: 15 ~ 85% RH
- Storage packed: 5 ~ 93% RH
- Storage unpacked: 15 ~ 85% RH

## Internal media player

- Supported video formats: container: avi, mov, mp4, mkv; codecs: MJPEG, MPEG4, H.264"
- Supported audio formats: mp3, wav

# Highlights

## HDMI interface, micro SD slot

HDMI interface, micro SD slot, integrated media player

## Project HD videos up to 60"

Project HD videos and images up to 60" (152 cm) in size

## Support of MHL

Support of MHL for mobile devices

## USB plug & socket

USB plug & socket for power and to play videos directly from your USB-Stick

## WavEngine with LED technology

WavEngine with LED technology surprises by crystal clear pictures in brilliant colors

## Bluetooth & Wi-Fi dongle

Bluetooth function and Wi-Fi dongle for screen mirroring (Miracast compatible)

