

PHILIPS

Pocket

Xperion 6000

300 lm Boost / 150 lm Eco

100 lm Spotlight

Battery life: 3.5 h (Eco: 7 h)

Compact and flexible



X60POCKX1

Designed with you in mind

Advanced lighting performance that lasts

The compact, powerful Philips Xperion 6000 Pocket is perfect for confined spaces, with an ultra-flexible 100 lm, 25 cm hose spotlight. There's also a wide-beam light with 150 lm in Eco and 300 lm in Boost mode.

Accessories available to upgrade your work lamp

- Smart solutions for charging your device

Extended warranty

- Extend your warranty online to 3 years

Handles tough conditions easily

- Resistant to impacts, water and solvents (IP65/IK07)

Smart, ergonomic design

- Smart rotatable hook with magnet and ergonomic body
- Precision light with flexible hose spot

See where others can't

- Long running time in different light modes
- Premium LED light with multiple outputs

Highlights

Multiple light modes



The powerful Xperion 6000 Pocket offers bright and homogenous LED lamps. The main beam features dual light modes of 150 lm in Eco and 300 lm in Boost. This handy pocket torch is also equipped with a super-flexible 100 lm hose spotlight, which is perfect for getting around obstacles.

Illuminate your work



The Philips Xperion 6000 Pocket is equipped with a powerful 25 cm hose spotlight to light any angle. The narrow and compact design is extremely convenient to help you work in confined small spaces. Slip the Philips Xperion 6000 Pocket into your pocket and use it for a wide range of needs.

Designed for resistance



Designed to handle tough work environments with IK07 shock resistance, water-resistant to IP65 standards, and a surface to withstand chemicals and workshop solvents, the Philips Xperion 6000 Pocket is built to last because we know that even the steadiest hands need the extra support.

Light modes for multiple needs



The Philips Xperion 6000 Pocket is designed to be ready for action. A single charge provides enough energy for a full day's work: up to 7 hours in Eco mode, 3.5 hours in Boost mode, and 10 hours with the torch beam of the hose. Powered by a powerful Li-ion battery, the Xperion 6000 Pocket can be fully charged within 3.5 hours via USB-C, ensuring maximum usage of its bright LED light.

Enables hands-free working



Designed with you in mind, the ergonomically shaped handle with an anti-slip coating allows you to hold this work light securely. If you need both hands free for work, position the light securely thanks to the 360° rotatable, retractable hook and a strong magnet. The power button is located on the back to ensure that the light does not glare directly at your eyes when you turn it on.

Up to 3 years' warranty



Benefit from the Philips standard 2 year warranty plus 1 additional year¹

Upgrade your work light



To keep your work light to hand and ready to use, try the Philips Dock station. Placed on a table, it provides cordless charging for your lamp.² Find out more: [Philips.com/Xperion-6000](https://philips.com/Xperion-6000)

Specifications

Marketing specifications

Product highlight: Compact and flexible

Expected benefits: Designed with you in mind

Product description

Hands-free options: Rotatable hook, strong magnet

Hook: 360° rotatable

Impact protection rating (IK): IK07

Magnet: 1 magnet

Materials and finishing: Robust ABS + Soft rubber

Operating Temperature: -10°C to 40°C

Range: Xperion 6000

Technology: COB LED

UV leak detector: No

Ingress protection rating (IP): IP65

Resistant to: Grease, oil, workshop solvents

Light characteristics

Beam angle: 110 degree

Colour temperature: 6000 K

Beam angle (pointer): 60 degree

Light output (pointer): 100 lumens

Light output (eco): 150 lumens

Light output (boost): 300 lumens

Electrical characteristics

Voltage: 3.7 V

Power source: Rechargeable battery

Battery capacity: 2000 mAh

Battery run time (boost): Up to 3.5 hours

Battery run time (eco): Up to 7 hours

Battery type: Lithium battery

Plug type: EU plug (not included for UK)

Charging cable type: Type C USB

Battery charging time: Up to 3.5 hours

Wattage: 3 W

Battery run time (pointer): Up to 10 hours

Ordering information

Order entry: X60POCKX1

Ordering code: 01465831

Packaging Data

EAN1: 8719018014658

EAN3: 8719018014665

Packed product information

Length: 6.5 cm

Height: 15 cm

Pack Quantity / MOQ: 6

Weight with batteries: 324 g

Cable length: 100 cm USB cable, 5 V 1 A adapter

Outer pack information

Length: 21.5 cm

Width: 17 cm

Height: 17 cm

