

PHILIPS

Motorcycle
headlights

WhiteVision ultra
moto

HS1

Pack of: 1

12 V, 35/35W

Irresistible white style

12636WVUBW



Sharp irresistible look

Sharp white look

Philips WhiteVision ultra moto halogen headlamp upgrades the style of your motorcycle with a bright white light.

Sharp irresistible look

- Bright white light for a stylish xenon look

Road-legal performance

- Stunning white road-legal headlights for a stylish look
- Respecting the high quality standards of ECE homologation

Enhanced safety

- Our whitest bulbs for stylish performance on the road
- High-quality quartz glass for an enhanced safety

Philips quality

- Philips is the choice of major car manufacturers

Highlights

Sharp light for a stylish look

Philips WhiteVision ultra moto is a unique halogen lamp that offers a bright white light. High-tech and efficient to differentiate and personalise your motorcycle, with better visibility and comfort.

Stunning road-legal headlights

Philips WhiteVision ultra moto upgrade headlight bulbs are ECE certified for bright white light on the road. Drivers enjoy a vibrant look and a street-legal bulb compliant with relevant regulations. Without compromising safety by dazzling oncoming drivers, it gives you great visibility.

High quality manufacturing

Philips automotive products and services are considered best-in-class in the Original Equipment Manufacturer market and the aftermarket. Manufactured from high quality materials and tested to the highest specifications, our products are designed to maximise the safety and comfort of our customers' driving experience. Our entire product range is thoroughly tested, controlled and certified (ISO 9001, ISO 14001 and QSO 9000) to the highest ECE requirements. Put simply, this is quality you can trust.

Engineered for stylish vision

Better and brighter lights allow for increased performance on the road. With their optimised high-precision filament geometry, high-pressure gas filling, high-precision coating and high-quality UV-Quartz glass,

Philips WhiteVision ultra moto headlight bulbs set a new standard for road-legal white light. Engineered for great style and visibility, these bulbs provide a more relaxed and fun driving experience.

High-quality quartz glass

Quartz glass is stronger than hard glass and highly resistant to temperature extremes and vibrations, which eliminates the risk of explosion. So Philips quartz-glass lamps (filament at 2 800°C and glass up to 800°C) are able to withstand severe thermal shocks. With the capability of increased pressure inside the lamp, quartz glass is able to produce a more powerful light. And more powerful light means an enhanced driving experience, however dark the road in front of you. All Philips quartz-glass lamps also offer a UV shield to protect your modern plastic optics from harmful UV rays.

Highest quality car lighting

Technologically advanced Philips lighting is renowned in the automotive industry, and has been for over 100 years. The Philips Original Equipment Quality products are designed and developed following strict quality control processes (including applicable ISO norms), leading to consistently high production standards. Philips WhiteVision ultra moto is compatible with motorcycle models of major brands.

Specifications

Electrical characteristics

Rated voltage: 12V

Wattage: 55 W

Lifetime

Life time: 400h

Light characteristics

Color temperature: 3600 K

Lumens: 600 ±10% / 400 ±10%

Marketing specifications

Expected Benefits: Style

Product highlight: Irresistible white style

Ordering information

Order entry: 12636WVUBW

Ordering code: 2401530

Outerpack information

Height: 14.0 cm

Length: 26.1 cm

Width: 19.6 cm

Gross weight per piece: 0,497 kg

Packaging Data

EAN1: 8719018024015

EAN3: 8719018024022

Packaging type: BW

Packing: Blister

Quantity in box: 1

Packed product information

Gross weight per piece: 22,5 g

Height: 12.9 cm

Length: 9.5 cm

Width: 4.8 cm

MOQ (for professionals): 10 pcs

Pack Quantity: 1 pc

Product description

Technology: Halogen

Type: HS1

Range: WhiteVision ultra

Application: High beam, Low beam

Homologation ECE

Designation: HS1 12636 WVU 12V 35/35W

PX43t-38 BW

Base: PX43t-38

