



Philips Xperion 6000 Headlight

300 lumen panoramic beam
120 lumen rotatable spotlight
Motion sensor
High-quality soft headband



LUMX60HEADX1

Designed with you in mind

Dual-mode, motion-sensing LED headlight

The Philips Xperion 6000 Headlight projects a 300 lumen panoramic light beam in front of you. Its rotating 120 lumen spotlight allows you to see every detail. An additional motion-sensor function makes it a versatile, hands-free tool.

Extended warranty

- Extend your warranty online to 3 years

Top-quality finish

- Comfortable headband
- IK07 impact-resistant casing
- IP65 splash- and dust-protected

Dual-mode light output

- 220° panoramic LED light beam
- Rotating light module

Enhanced versatility

- Motion-sensor mode
- Fast-charge, long-life battery

PHILIPS

Headlight

300 lumen panoramic beam 120 lumen rotatable spotlight, Motion sensor, High-quality soft headband

Specifications

Marketing specifications

- Product highlight: 220° panoramic light beam
- Expected benefits: Designed with you in mind

Product description

- Hands-free options: Motion detection
- Headband
- Hook: No
- Impact protection rating (IK): IK07
- Magnet: No
- Materials and finishing: Robust ABS
- Operating Temperature: -10°C to 40°C
- Orientable light: 60° rotatable spot light module
- Pointing light
- Range: Xperion 6000
- UV leak detector: No
- Ingress protection rating (IP): IP65
- Resistant to: Grease, oil, workshop solvents

Light characteristics

- Beam angle: 220 degree
- Colour temperature: 6000 K
- Beam angle (pointer): 15 degree
- Light output (pointer): 120 lumens
- Light output (eco): 150 lumens
- Light output (boost): 300 lumens

Electrical characteristics

- Voltage: 3.7 V
- Power source: Rechargeable battery
- Battery capacity: 1200 mAh
- Battery run time (boost): Up to 2.5 hours
- Battery run time (eco): Up to 4 hours
- Battery type: LFP battery
- Plug type: Not included
- Charging cable type: Type C USB
- Battery charging time: Up to 2.5 hours
- Wattage: 2 W
- Battery run time (pointer): Up to 4.5 hours

Ordering information

- Order entry: X60HEADX1
- Ordering code: 02173131

Packaging Data

- EAN1: 8719018021731
- EAN3: 8719018021748

Packed product information

- Length: 15 cm
- Width: 9 cm
- Height: 4 cm
- Pack Quantity / MOQ: 6
- Weight with batteries: 80 g
- Cable length: USB type-C 100 cm cable

LUMX60HEADX1/10

Highlights

Rotating LED spotlight module

The Philips Xperion 6000 Headlight features a 60° rotating spotlight module to direct the light exactly where needed and get the job done.

Enabling hands-free working

The Philips Xperion 6000 Headlight comes with a motion-sensor mode for hands-free use. This means you can control the headlamp by waving your hand in front of the sensor. To activate the sensor mode, turn on your lamp, press the motion-sensing button until the blue light illuminates, and enjoy hands-free control.

Fast-charge, long-life battery

The Philips Xperion 6000 Headlight takes less than 2.5 hours to charge fully. With a battery that lasts from 2.5 to 4.5 hours, our Headlight light allows you to work a full day without interruption. Then recharge it overnight, ready to go again the next day.

Comfortable headband

The Philips Xperion 6000 Headlight boasts an anti-slip elastic headband which fits comfortably around your head. The headband is easily adjustable.

IK07 impact-resistant casing

Conforming to international impact-resistance standard IK07, the robust Philips Xperion 6000 Headlight is built to withstand the toughest working environments.

Up to 3 year warranty

Benefit from Philips standard 2 year warranty plus 1 additional year.*

Clear, panoramic light beam

The Philips Xperion 6000 Headlight projects a panoramic white light with a 220° beam angle. It illuminates everything in front of you up to 70 metres ahead with its 300 lumen main light. The 6000 Kelvin light is gentle on the eyes, improving visual comfort and reducing eye strain for fatigue-free working.

IP65 splash- and dust-protected

The Philips Xperion 6000 Headlight is IP65-rated for splash and dust resistance. Built to strict manufacturing standards with multiple sealing processes, your Headlight is resistant to splashed water and protected from dust.



Issue date 2024-06-04

Version: 4.4.1

© 2024 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

* To be claimed on the Philips extended-warranty webpage