

PHILIPS

Motorcycle
headlights

CrystalVision Moto

Type of lamp: H4

Pack of: 1

12 V, 35/35 W



12458EDCVMBW



Ride with style

Ride your motorcycle with style

Philips CrystalVision moto halogen headlamp upgrades the style of your motorcycle with up to 4300K bright white light.

High quality and ultra-resistant headlamp

- Philips moto lamps are made of high-quality quartz glass
- Respecting high quality standards of the ECE homologation
- Philips is the choice of major motorbike manufacturers.

White modern xenon look

- Bright white light up to 4300K for a stylish xenon look

Highlights

White light for motorcycle

CrystalVision moto is a unique halogen lamp, that offers a bright white light with up to 4300K. High technology and efficiency to differentiate and personalize your motorcycle, with better visibility and confort.

High quality quartz glass



UV-Quartz glass is stronger than hard glass and highly resistant to temperature extremes and vibrations, which eliminates the risk of explosion. So Philips quartz-glass lamps (filament 2 650° C and glass 800° C) are able to withstand severe thermal shock. With the capability of increased pressure inside the lamp, UV-quartz glass is able to produce a

more powerful light. And more powerful light means an enhanced driving experience, however dark the road in front of you.

ECE homologation

Philips automotive products and services are considered best-in-class in the Original Equipment Manufacturer market and the aftermarket. Manufactured from high quality products and tested to the highest specifications, our products are designed to maximize the safety and comfort of our customers' driving experience. Our entire product range is thoroughly tested, controlled and certified (ISO 9001, ISO 14001 and QSO 9000) to the highest ECE requirements. Put simply, this is quality you can trust.

Manufacturers' choice

For over 100 years, Philips lamps have been at the forefront of the automotive lighting industry, introducing technological innovations that have become standard in modern vehicles. Today, one in two cars in Europe and one in three worldwide is equipped with Philips lighting.

Specifications

Packaging Data

Packaging type: BW
EAN1: 8727900376821
EAN3: 8727900376838

Light characteristics

Color temperature: 4300 K

Marketing specifications

Expected benefits: Style
Product highlight: Ride with style

Product description

Range: CrystalVision Moto
Technology: Halogen
Application: High beam, Low beam
Type: H4
Base: P43t-38
Designation: 12458EDCVMBW

Electrical characteristics

Voltage: 12 V
Wattage: 35/35 W

Ordering information

Ordering code: 37682130
Order entry: 12458EDCVBW

Packed product information

Gross weight per piece: 33.759 g
Height: 12.9 cm
Length: 9.5 cm
Net weight per piece: 21.359 g
Width: 4.86 cm
MOQ (for professionals): 10
Pack Quantity: 1

Outerpack information

Gross weight per piece: 0.462 g
Height: 13 cm
Length: 25.5 cm
Net weight per piece: 213.59 g
Width: 19 cm

