

# PHILIPS

LED work light

EcoPro61 Slim

Professional work lamp



RC620X1



## Quality light to get the job done

### Ultra-slim design to light up narrow spaces

The versatile, ultra-slim and rechargeable Philips EcoPro61 Slim is ideal for lighting up narrow spaces with its 270° rotating lighting module. Its long-lasting battery life up to 20 hours allows you to work a full day without interruption.

#### Ultra-slim design to light up narrow spaces

- Ultra-slim, 270° pivoting design to light up narrow spaces

#### 3 light modes for different uses

- 3 light output levels for the flexibility you need

#### 140 lm spotlight

- 140 lm pointer for spot inspection

#### Long-life battery up to 20 hours

- Long-life battery up to 20 hours

#### Hands-free working

- 360° hook and strong magnet

# Highlights

## Ultra-slim, rotatable design

The Philips EcoPro61 has been designed with a 270° lighting module so you can easily direct the light beam and illuminate extremely narrow spaces. Its ultra-slim design (1.6m-wide head) eliminates blind spots deep inside your engine or machinery.

## 3 light output levels

Different jobs demand different amounts of light. With its three power modes, the Philips EcoPro61 Slim lets you adjust the light to your needs. Boost mode gives you a powerful 500-lumen light output, helping you to spot even the smallest of details. If the ambient light changes or if you just want to preserve the battery, switch to Eco mode from 50 to 250 lumen and use your lamp for up to 20 hours. What's more, the EcoPro61 Slim's 6,500 Kelvin temperature is gentle on your eyes, preventing fatigue.

## 140 lm pointer

Philips EcoPro61 Slim offers you a spotlight combined with a lamp delivering 140 lumen. You'll be able to see small details even in dark corners. The spotlight can be used in both positions: with the lamp folded and with the lighting module open.

## 360° hook and strong magnet

The 360° retractable, stainless-steel hook lets you hang this lamp anywhere you need. It also attaches easily to any metal surface, leaving both your hands free to work.

## Long-life battery up to 20 hrs

Once fully charged, your Philips EcoPro61 Slim delivers 2.5 hours of continuous bright light from its main 500-lumen beam. The 50-lumen Eco mode lasts up to 20 hours. So with occasional use, the lamp can last days before requiring a recharge.

# Specifications

## Electrical characteristics

**Battery run time:** 2,2hr / 20hr (pointer)

**Power Source:** USB

**Wattage:** 3 W

## Light characteristics

**Beam angle (pointer)**

**Light intensity (boost):** 500 Lm

**Light intensity (Pointer):** 140 Lm

## Ordering information

**Order entry:** RC620X1

**Ordering code:** 00484031

## Outerpack information

**Gross weight per piece:** 330 g

**Height:** 26,2 cm

**Length:** 21,8 cm

**Width:** 17,2 cm

## Packaging Data

**EAN1:** 8719018004840

**EAN3:** 8719018004857

## Packed product information

**Pack Quantity / MOQ:** 6

## Product description

**Hook:** Stainless foldable hook

**Impact protection rating (I):** IK07

**Ingress protection rating (IP):** IP20

**Magnet:** Strong magnet

