

PHILIPS

PJH10

Professional

1000 lumen / 10 W

Shock and water resistant

Battery life: 3 h (12 h dimmed)

Battery life indicator



LPL64X1



Daylight in your workshop

Portable rechargeable projector light

Fitted with high-quality LEDs, the Philips PJH10 projector provides an intense 1000 lumen beam of light. Smart dimming lets you adjust the light output down to 100 lumens. Resistant to shock and water, this lamp is built to last.

Rechargeable battery with battery life indicator

- Indicator shows you how long the battery will last
- Rechargeable battery lasts up to 12 hours per charge

Smart and powerful bright white light

- Powerful white light (1000 lumen / 10 W) lights up large area
- Smart dimming to adjust light between 1000 and 100 lumens

Sturdy and durable lamp for daily use

- Feel confident with a lamp that is almost unbreakable
- Water resistant against splashes and immersion

Versatile, hands free and easy to use

- Smaller and lighter than comparable products
- Magnetic mounting accessory for hands-free lighting
- Rotating handle lets you position light for hands-free use

Highlights

Powerful light while you work

Whether you need to light up a work site, temporarily replace a wall lamp or illuminate outdoor activities, the Philips PJH10 projector is perfect for lighting up large dark areas. Delivering a powerful 1000 lumens (10 W), its consistently bright light gives off a super-wide beam. This light output is significantly higher than comparable models on the market, helping you see more. If you need less light and more battery life, you can easily dim the lamp to a 100 lumen output. The 6000 Kelvin natural light is also gentler on your eyes, preventing fatigue while you work.

Smart dimming to adjust light

Different jobs demand different amounts of light. With a smart dimming feature, the Philips PJH10 lets you easily adjust the light output from 1000 lumens down to 100 lumens. So if the ambient light changes, or there is too much glare or you just want to preserve the battery, you can quickly and easily adjust the brightness to suit the needs of the job. Why is it smart? Because it remembers your last setting. So if you're continuing a similar job, you'll start with just the right amount of light.

Almost impossible to break

The Philips PJH10 is a full rubber workshop lamp, providing a comfortable and secure grip. But despite this, we know it's easy to

drop your tools. With an IK09 shock resistance rating (which is 5x better than the IK07 rating achieved by comparable products), you can handle your workshop lamp with confidence. In impact resistance tests, the lamp was dropped on its 6 faces from a height of 1.5 meters/4.9 feet (about shoulder height) a total of 25 times. While the robust PJH10 easily survives being dropped like this, most standard lamps would almost certainly break.

Highly water resistant

As you may use Philips PJH10 projector lamps for various indoor or outdoor activities, the lamp is designed to survive in tough conditions. With an IP68 rating for resistance to water, the device will continue to work when splashed or even immersed in water for a long time. Most comparable workshop lamps only achieve an IP54 rating, which only protects against low pressure jets of water, such as rain.

Versatile rotating handle

Sometimes you need both hands free to focus on your task. The 180° rotating handle on the back of the Philips PJH10 gives you the freedom to position the projector as needed. You can use the handle as a hook to hang the light or as a support to stand it up by itself. This versatility allows you to direct the light just where you need it.

Hands-free magnetic mounting

The Philips PJH10 projector comes with two magnets integrated into the rotating handle. You can simply mount your projector onto any metal surface, perfect for use in a garage or other work site. There is also an M8 hole in the handle so you can fix it on top of a tripod.

Compact and lightweight

At just 399 g (14 oz.) and with dimensions of 145 x 100 mm (5.7 x 3.9"), the PJH10 is lighter and more compact than comparable lighting products on the market. That means it's not only easier to use while you're working, it also takes up less space when you're not.

Up to 12 hours of battery life

Once fully charged, your Philips PJH10 delivers bright white light (1000 lumens/10 W) for up to 3 hours of continuous use. If you need the battery to last longer, simply switch to eco mode (100 lumens) and enjoy up to 12 hours of continuous light. This is significantly longer than similar models currently available.

Battery life indicator

Never worry about your light dying just when you need it the most. Philips PJH10 projector lamps have a battery life indicator on the back. This tells you how long you've got before you'll need to recharge the battery.

Specifications

Ordering information

Order entry: LPL64X1
Ordering code: 5167731

Electrical characteristics

Battery capacity: 4400 mAh
Power source: Micro USB charger
Wattage: 10 W
Battery run time (boost): Up to 3 hours
Voltage: 3.7 V
Battery run time (eco): Up to 12 hours
Battery type: Li-ion battery
Charging cable type: Rechargeable
Plug type: Micro USB
Battery charging time: around 4.5 hours
Power Source: Li-ion 18650 x2

Light characteristics

Colour temperature: 6000 K
Light output (pointer): N/A
Light intensity (boost): 1500 lux at 0.5 m (1.6 ft.)
Light intensity (eco): 150 lux at 0.5 m (1.6 ft.)
LED lifetime: 10,000 hours
Beam angle: 90°
Light output (eco): 100 lumens

Light output: 1000 lumens, 1000/100 Lumens
Beam angle (pointer): N/A
Light intensity (Pointer): N/A

Outer pack information

Gross weight per piece: 3330 g
Height [cm]: 17.5 cm (6.9")
Length [cm]: 30.5 cm (12")
Width [cm]: 17 cm (6.7")

Packaging Data

EAN1: 8719018051677
EAN3: 8719018051684

Packed product information

Pack Quantity / MOQ: 6
Weight with batteries: 520 g
Size: Compact, Standard
Cable length: 120 cm (47.2")
Height [cm]: 14 cm (5.5")
Length [cm]: 15 cm (5.9")
Width [cm]: 5 cm (2")
Diameter: N/A
Weight without batteries: N/A
Weight without cable: N/A
Weight with cable: N/A

Product description

Hook: N/A
Impact protection rating (IK): IK09
Ingress protection rating (IP): IP68
Magnet
Materials and finishing: ABS with rubber
Orientable light: 180° pivoting handle
Resistant to: grease, oil, workshop solvents
Technology: LED
Headband: N/A
Hands-free options: strong magnet, third foot including a clip
Range: PJH
Number of LEDs: 1
Operating temperature: -10°C to 40°C
Pointing light: N/A
UV leak detector: No
Range: Professional

Marketing specifications

Product highlight: Rechargeable work lamp
Expected benefits: See better, Work better

