

# PHILIPS

Cordless slim  
professional lamp

EcoPro30

300 lm Boost / 150 lm Eco

Versatile hands-free use

Battery lasts up to 8 hours

Robust work light



LUMRC220X1



## Quality light to get the job done

### Cordless slim professional lamp

The rechargeable Philips EcoPro30 hand light is ideal for quick inspection jobs and longer repair work. It eliminates all shadow with its 120°-wide light beam, while a 360° rotating hook and strong magnet allow hands-free working.

#### Dual-mode natural white LED light

- Light up your whole work area
- Choose 150lm in 'Eco' mode or an intense 300lm in 'Boost'
- Work comfortably and fatigue-free

#### Robust work light

- Designed to withstand tough workshop conditions

#### Rechargeable long-life battery

- Work continuously all day

#### Versatile hands-free use

- Work better with hands-free lighting

# Specifications

## Electrical characteristics

**Battery capacity:** 2200 mAh  
**Battery charging time:** Up to 3 hours  
**Battery run time (boost):** Up to 4 hours  
**Battery run time (eco):** Up to 8 hours  
**Battery type:** Li-ion battery  
**Charging cable type:** Rechargeable  
**Plug type:** Plug+Micro USB  
**Power source:** Battery  
**Voltage:** 3.7 V  
**Wattage:** 3 W

## Light characteristics

**Beam angle:** 120° degree  
**Color temperature:** 6000K  
**LED lifetime:** 10000 hours  
**Light output:** 150–300 lumen lumen  
**Light output (boost):** 300 lumen  
**Light output (eco):** 150 lumen

## Marketing specifications

**Expected benefits:** Quality light to get the job done  
**Product highlight:** Cordless slim professional lamp

## Ordering information

**Order entry:** RC220X1  
**Ordering code:** 01769731

## Outerpack information

**Gross weight per piece:** 270 g  
**Height:** 30,5 cm  
**Length:** 5,5 cm  
**Width:** 4,5 cm

## Packaging Data

**EAN1:** 8719018017697  
**EAN3:** 8719018017703

## Packed product information

**Height:** 32 cm  
**Length:** 6.5 cm  
**MOQ (for professionals):** 6  
**Pack Quantity:** 1  
**Width:** 4.5  
**Cable length:** 50 cm Micro USB  
**Size:** Standard  
**Weight with batteries:** 235 g  
**Weight with cable:** 247 g  
**Weight without cable:** 235 g

## Product description

**Range:** EcoPro  
**Hands free options:** Hook, Magnets  
**Headband:** No  
**Hook:** 360 degrees retractable hook  
**Impact protection rating (IK):** IK07  
**Ingress protection rating (IP):** IP54  
**Magnet**  
**Materials & finishing:** ABS plus rubber coating  
**Operating Temperature:** 0°C to 40°C  
**Orientable light:** 360° pivoting base  
**Resistant to:** grease, oil, workshop solvents  
**Technology:** LED  
**UV leak detector:** No

# Highlights

## Wide beam angle: up to 120°

The Philips EcoPro30 provides a wide 120° beam angle, perfect for lighting up the whole area in front of you.

## Bright dual-mode light

The main beam on the Philips EcoPro30 has two output levels. For everyday use and extended battery life, the Eco mode provides you with a bright 150-lumen output. On Boost mode, you get an intense 300 lumen, but shorter battery life. This flexibility allows you to choose the right light for the job at hand.

## 6000K natural white LED light

Philips EcoPro30 produces a 6000 K natural white light that improves visual comfort and reduces eye strain for fatigue-free working.

## Up to 8 hours' battery life

The Philips EcoPro30 cordless LED lamp is designed to be ready for action. Powered by a high-energy Li-ion battery, the Philips EcoPro30 is fully recharged within 5 hours, ensuring maximum usage of the LED light. Work for up to 8 hours in Eco mode or 4 hours in Boost mode. The one-turn opening cap makes it even easier to recharge your Philips EcoPro30.

## Easy-to-use inspection lamp

Hands-free lighting helps you work more productively. Our Philips EcoPro30 comes with a powerful magnet on the bottom as well as a 360° rotatable hook, leaving both your hands free to get the job done.

## Built to last

When you're busy working, it's easy to drop and damage your equipment. That's why it's important the tools you use are built to last. The Philips EcoPro30 is water- and dust-resistant (IP54 rating). It's also IK07-rated to withstand impacts and drops from a height of up to 1.5 meters.

