

# PHILIPS

## RCH10S

### Professional

200 lm Boost / 100 lm Eco

Versatile hands-free use

Ultra-durable battery up to 6 H

Robust work light



LPL66X1



## See better, work better

### Cordless, slim, professional lamp

The compact, rechargeable Philips RCH10S is ideal for quick inspection jobs and longer repair operations. It eliminates all shadow with its 120° wide light beam, while a 360° rotating hook and a strong magnet allow hands-free work.

#### **Dual-mode natural white LED light**

- Work comfortably and fatigue-free
- Choose 100 lm in 'Eco' mode or an intense 200 lm in 'Boost' mode
- Light up your whole work area

#### **Robust work light**

- Robust light designed to withstand tough workshop conditions

#### **Rechargeable long-life battery**

- Work continuously for up to 6 hours

#### **Convenient, hands-free, rotatable work light**

- Work better with hands-free lighting

# Specifications

## Ordering information

Order entry: LPL66X1  
Ordering code: 05205631

## Electrical characteristics

Battery capacity: 1500 mAh  
Power source: Rechargeable battery  
Wattage: 3 W  
Voltage: 3.2 V  
Battery run time (eco): Up to 6 hours  
Battery type: LFP battery  
Charging cable type: Rechargeable  
Plug type: Plug+Micro USB  
Battery charging time: Less than 3 hours  
Battery run time (boost): Up to 3 hours

## Light characteristics

Colour temperature: 6000 K  
Light intensity (pointer): N/A  
Light output: 150-300 lumen, 200 lumen  
Light output (pointer): N/A  
LED lifetime: 10,000 hours  
Beam angle: 120°  
Light output (eco): 100 lm  
Beam angle (pointer): N/A

## Outer pack information

Gross weight per piece: 2752 g  
Height: 26.2 cm  
Length: 35 cm  
Width: 10.5 cm

## Packaging Data

EAN1: 8719018052056  
EAN3: 8719018052063

## Packed product information

Height: 32 cm  
Length: 6.5 cm  
Pack Quantity / MOQ: 6  
Weight with batteries: 235 g  
Weight with cable: 247 g  
Width: 4.5 cm  
Size: Compact, Standard  
Cable length: 50 cm Micro USB  
Diameter: N/A  
Weight without batteries: N/A  
Weight without cable: 235 g

## Product description

Hook: 360 degrees retractable hook  
Impact protection rating (IK): IK07  
Ingress protection rating (IP): IP54  
Magnet  
Materials and finishing: ABS plus rubber coating  
Orientable light: 360° pivoting base  
Resistant to: grease, oil, workshop solvents  
Technology: LED  
Range: Professional  
Hands-free options: Hook, Magnets  
Number of LEDs: 20 (COB)  
Operating temperature: 0°C to 40°C  
Pointing light: N/A  
Headband: NO  
UV leak detector: NO

## Marketing specifications

Product highlight: Rechargeable work lamp  
Expected benefits: See better, Work better

# Highlights

## 6000K natural white LED light

Philips RCH10S produces a 6000 K natural white light that improves visual comfort and reduces eye strain for fatigue-free working.

## Bright dual-mode light

The main beam on the Philips RCH10S has two output levels. For everyday use and extended battery life, Eco mode provides you with a bright 100-lumen output. With Boost mode, you get an intense 200 lumen but shorter battery life. This flexibility allows you to choose the right light for the job at hand.

## Wide beam angle: up to 120°

The Philips RCH10S provides a versatile, wide 120° beam angle, perfect for lighting up the whole area in front of you.

## Built to last

When you're busy working, it's easy to drop and damage your equipment. That's why it's important the tools you use are built to last. The Philips RCH10S is water- and dust-resistant (IP54 rating). It's also IK07-rated to withstand impacts and drops from a height of up to 1.5 metres.

## Up to 6 hours' battery life

The Philips RCH10S cordless LED lamp is designed to be ready for action. Powered by a high-energy Li-ion battery, the Philips RCH10S is fully recharged within 3 hours, ensuring maximum usage of the LED light. Work for up to 6 hours in Eco mode or 3 hours in Boost mode. The one-turn opening cap makes it even easier to recharge your Philips RCH10S.

## Easy-to-use inspection lamp

Hands-free lighting helps you work more productively. Our Philips RCH10S comes with a powerful magnet on the bottom as well as a 360° rotatable hook, leaving both your hands free to get the job done.

