

# PHILIPS

## DayLight 4

LED Daytime lights

DRL

12 V

12820WLEDX1



## High visibility for maximum safety

### LED daytime running lights for better visibility

The high-power Luxeon LED daytime running lights improve your safety on the road, increasing your visibility without compromising on lifetime or energy consumption.

#### **Fits most car models**

- Hybrid, electric and start & stop compatible

#### **Original Equipment Quality**

- Water and gravel-impact resistant
- High-quality aluminium housing

#### **Simple, click installation**

- Simple wiring system
- Smart clip-on system

# Highlights

## Start & stop compatible



With the intelligent electronics of the control box, the modules are compatible with the latest types of vehicles: hybrid, electric and start & stop cars are all supported. Please refer to the application guide section for an overview of all makes and models.

## Gravel-impact resistant



The high-quality aluminium housing and lens are water and gravel-impact resistant. After mounting, the system does not require any maintenance.

## Aluminium housing



The robust high-quality aluminium housing prevents corrosion and is weatherproof: water, salt, sand and dust stand no chance. The result is long life and no maintenance work.

## Simple wiring system

The simple wiring system will enable you to install your daylight easily.

## Clip-on system



Simple installation with smart clip-on system. Install the brackets in any cavity and simply click the modules into place. The modules will lock tightly and are protected from theft.

# Specifications

## Technical specifications

Voltage: 12 V

Application: Daylight

Homologation: ECE compliant (street legal)

Lasts car's lifetime: 5000 hours

## Maximum visibility

Colour temperature: 6000K

## Easy to install

Easy click system: clip-on system

## Original equipment quality

Premium finishing: High-quality aluminium housing

Quality: Certified automotive quality

Gravel impact resistance lens: Automotive test PSA B21 7090

Homologation: ECE R87

Standard waterproof connectors: Waterproof connector

Waterproof - Weather-proof: Water, salt, dust, sand

