

PHILIPS

RCH5S

Professional

300 lumens/3 W

Shock and water resistant

Battery life: 1.5 h (dim: 12 h)

High-quality Lumileds LED



LPL62X1



Small but powerful dimmable LED light

Compact design for quick inspection jobs

Fitted with high-quality LEDs, the Philips RCH5S is a pocket-sized cordless work lamp that provides bright light. Smart dimming lets you easily adjust the light between 300 and 30 lumens. And it's highly resistant to water and impacts.

Easy-to-use cordless pocket lamp

- Strong built-in magnets allow hands-free use
- Compact design to easily slip into your pocket.
- Useful 180° pivoting lamp to direct light beam

Superior bright light from high-quality LED chips

- 120° wide beam angle illuminates a large work area
- High-quality LEDs light up to 300 lumens
- Powerful 120 lumen LED spot light
- Smart dimming to adjust light between 300 and 30 lumens

Ultra-long-life and fast-charging battery

- Advanced battery with long life
- Feel confident with a lamp that is almost unbreakable
- Indicator shows you how long the battery will last
- Docking station for efficient battery charging
- Water resistant against splashes and immersion

Highlights

High-quality LEDs

Equipped with high-quality LEDs, the Philips RCH5S provides bright light and a useful dimming feature. Boost mode gives you a powerful 300 lumen wide beam of light, so you're able to see every little detail. And if you're using the lamp for a long time while it's unplugged, you can dim the light to preserve battery life. At a reduced 30 lumen output you'll still get high-quality light for up to 12 hours. The 6000 Kelvin natural light is also gentler on your eyes, preventing fatigue while you work.

Smart dimming to adjust light

Different jobs demand different amounts of light. With a smart dimming feature, the Philips RCH5S lets you easily adjust the light output from 300 lumens down to 30 lumens. So if the ambient light changes, or there is too much glare or you just want to preserve the battery, you can quickly and easily adjust the brightness to suit the needs of the job. Why is it smart? Because it remembers your last setting. So if you're continuing a similar job, you'll start with just the right amount of light.

Powerful LED spot light

The RCH5S is equipped with a powerful spotlight to help you illuminate those hard-to-see places. Providing up to 120 lumens of bright white light, you'll be able to spot even the smallest of details as you work.

120° wide beam angle

The Philips RCH5S provides a 120° wide beam angle, perfect for illuminating the entire work area in front of you. With the bright light evenly spread over a large area, you can easily see what you're doing.

Advanced and durable battery

The RCH5S rechargeable LED inspection lamp features advanced battery technology. In eco mode, the battery will last for up to 12 hours, significantly longer than comparable models on the market. And you'll get a full charge in less than 2.5 hours. So this is an LED inspection lamp that will keep working for a long time and be ready to use quickly.

Battery life indicator

Never worry about your light dying just when you need it the most. Philips RCH5S inspection lamps have a battery life indicator on the front. This tells you how long you've got before you'll need to recharge the battery.

Almost impossible to break

The Philips RCH5S is a rubber-coated workshop lamp, providing a comfortable and secure grip. But despite this, we know it's easy to drop your tools. With an IK09 shock resistance rating (which is 5x better than the IK07 rating achieved by comparable products), you can handle your workshop lamp with confidence. In impact resistance tests, the lamp was dropped on its 6 faces from a height of 1.5 metres/4.9 feet (about shoulder height) a total of 25 times. While the robust RCH5S easily survives being dropped like this, most standard lamps would almost certainly break.

Highly water resistant

As you may use Philips RCH5S inspection lamps for various indoor or outdoor activities, the lamp is designed to survive in tough conditions. With an IP68 rating for resistance to water, the device will continue to work when splashed or even immersed in water for a long time. Most comparable workshop

lamps only achieve an IP54 rating, which only protects against low-pressure jets of water, such as rain.

Docking station for charging

Included with your Philips RCH5S is a convenient docking station. Not only does this charge your battery efficiently (faster than most USB connections), it's also compatible with the RCH25, so you can use one charging dock for multiple lamps, saving space in your workshop.

Slim pocket-sized design

The unique compact design of the RCH5S LED inspection lamp means you can use it for a wide range of needs. Similar in size to a deck of cards, you can easily slip this lamp into your pocket.

Useful pivoting lamp

Thanks to the 180° pivoting lamp on its base, you can easily adjust the direction of the light beam, depending on your needs.

Magnets for hands-free use

Sometimes you need both hands to get the job done. With a strong built-in magnet on the base and another on the lamp's rear side, you can easily attach the device to any nearby metal surface. Together with the 180° pivoting lamp, this gives you great flexibility while you work.

Specifications

Ordering information

Order entry: LPL62X1
Ordering code: 5163931

Electrical characteristics

Power source: docking station
Wattage: 3 W
Voltage: 3.7 V
Charging cable type: Rechargeable
Plug type: Micro USB
Battery capacity: 1200 mAh
Battery charging time: around 2.5 hours
Battery run time (boost): Up to 1.5 hours
Battery run time (eco): Up to 12 hours
Battery type: Li-ion battery
Power Source: Lithium Polymer PL 703450

Light characteristics

Light output: 300 lumens, 300/30 Lumens
Beam angle: 120° degree
Beam angle (pointer): 60°
LED lifetime: 10,000 hrs
Light intensity (boost): 500 lux at 0.5 m
Light intensity (eco): 50 lux at 0.5 m(1.6 ft.)
Light intensity (Pointer): 550 lux at 0.5 m

Light output (eco): 30 lumens
Light output (pointer): 120 lumens
Colour temperature: 6000 K

Outer pack information

Gross weight per piece: 2960 g
Height: 21.5 cm
Length [cm]: 33 cm (13")
Width [cm]: 17 cm (6.7")

Packaging Data

EAN1: 8719018051639
EAN3: 8719018051646

Packed product information

Height: 15 cm
Length: 10.2 cm
Pack Quantity / MOQ: 6
Weight with batteries: 460 g
Width: 9.7 cm
Size: Standard
Cable length: 120 cm (47.2")
Diameter: N/A

Weight without batteries: N/A
Weight without cable: N/A
Weight with cable: N/A

Product description

Impact protection rating (IK): IK09
Ingress protection rating (IP): IP68
Technology: LED
Hands-free options: 360° retractable hooks, strong magnet
Headband: N/A
Hook: 360 degrees retractable hook
Magnet
Materials and finishing: ABS with rubber
Number of LEDs: 4+1
Operating temperature: -10°C to 40°C
Orientable light: 180° pivoting base
Pointing light: N/A
Range: Professional
Resistant to: grease, oil, workshop solvents
UV leak detector: No

Marketing specifications

Product highlight: Rechargeable work lamp
Expected benefits: See better, Work better

