

PHILIPS

Flood Mini

Xperion 6000

500 lumens/250 lm Spotlight

Light zoom function

Battery life: 3 h (Eco: 9 h)

Versatile

LUMX60FLMIX1



Designed with you in mind

Compact LED projector light

With its 500 lm flood light and variable beam, the Philips Xperion 6000 Flood compact projector gets the job done. The smart-zoom knob simplifies control, while resistance to impacts and water guarantees durability.

See where others can't

- Combines the two most commonly used work lights in one lamp

Smart, compact design

- Compact and lightweight to take with you everywhere
- Smart-zoom knob to easily control your light
- Smart handle to position light for hands-free use
- Rechargeable via USB type C or wireless dock station
- Indicator shows remaining battery life

Handles tough conditions easily

- Resistant to impacts, water and solvents (IP65/IK07)

Accessories available to upgrade your work lamp

- Smart solutions for charging and finding your device

Extended warranty

- Extend your warranty online to 3 years

Highlights

Multi-purpose light

Different jobs demand different amounts of light. The Philips Xperion 6000 Flood compact projector combines in one lamp the two most commonly used forms of workshop lighting. A wide-angle homogeneous flood light for working on big areas over longer periods, and a focused light that concentrates illumination within small areas to get the best contrast and brightness, ideal for detailed inspections and narrow spaces.

Compact, lightweight design

Philips Xperion 6000 Flood compact projector allows you to take your rechargeable projector light with you, wherever you go. Easy to store in a glove box.

Smart-zoom knob

Co-designed with mechanics, the ergonomic smart-zoom knob allows you to adjust your light from wide flood illumination to focused brightness easily, even with your gloves on. Positioned on the side of the lamp, the rotatable smart-zoom knob is always within reach, meaning you don't have to move the lamp from its mounted position. The lamp's smart design enables it to remember your last setting and restart directly at the desired intensity.

Versatile attachments

The smart handle can be used as a support to hold the projector up by itself or as a hook to hang the light from, and can be screwed on to a tripod or attached to any metal surface with its integrated magnets. This versatility allows you to position the light easily and at the right angle, directing the beam just where you need it.

Don't get left in the dark

Never worry about your light dying just when you most need it. On the back of the Philips Xperion 6000 Flood compact projector you will find a battery-life indicator, which tells you exactly how long you've got before you need to recharge the battery.

Designed for durability

Designed to handle tough work environments with IK07 shock resistance, water resistance to IP65 standards, and a surface to withstand chemicals and workshop solvents, the Philips Xperion 6000 Flood is built to last because we know that even the steadiest hands need extra help.

Upgrade your work light

Don't worry about losing your device anymore. You can add the "Find My Device" function to your Philips Xperion Flood compact projector. Use the remote control to trigger an audible buzzer and flashing light to locate your device. The vibrant lime-green body will help you spot your device even in dark settings.

Up to 3 years' warranty

Benefit from a Philips standard 2 year warranty plus 1 additional year*.

Ready for action

The Philips Xperion 6000 Flood compact projector can be charged by USB type C cable (included in the pack), or directly on the Philips wireless dock station. Find out more: [Philips.com/Xperion-6000](https://philips.com/Xperion-6000)

Specifications

Electrical characteristics

Battery capacity: 2500 mAh
Battery charging time: Up to 3.5 hours
Battery run time: 3 h @ 500 lumens
Battery run time (boost): 3 h @ 500 lumens
Battery run time (eco): 9 h @ 100 lumens
Battery run time (pointer): 5 h @ 250 lumens
Battery type: Lithium battery
Charging cable type: Type C USB
Plug type: EU plug (not included for UK)
Voltage: 3.7 V
Wattage: 5 W
Power source: Rechargeable battery

Light characteristics

Beam angle: 100 degree
Beam angle (pointer): 15 degree
Colour temperature: 6000 K
Light output (boost): 500 lumens
Light output (eco): 100 lumens
Light output (pointer): 250 lumens

Marketing specifications

Expected benefits: Designed with you in mind
Product highlight: Compact and ergonomic

Ordering information

Order entry: X60FLMIX1
Ordering code: 1913431

Packaging Data

EAN1: 8719018019134
EAN3: 8719018019141

Packed product information

Cable length: 100 cm USB cable, 5 V 1 A adapter
Height: 120 cm
Length: 70 cm
Pack Quantity / MOQ: 6
Width: 50

Product description

Hands-free options: Rotatable hook, strong magnet, Smart handle
Impact protection rating (IK): IK07
Ingress protection rating (IP): IP65
Magnet: Magnetic handle
Materials and finishing: Robust ABS
Operating Temperature: -10°C to 40°C
Resistant to: Grease, oil, workshop solvents
Technology: COB LED
UV leak detector: No
Range: Xperion 6000
Hook: 180° rotatable

