

PHILIPS

Car air purifier

GoPure

Powerful 3-layer filtration

Cleanable pre-filter

HESA Filter

HEPA Filter



LUMGP523BLACKX1



Removes up to 100 different types of pollutants Hassle-free automatic filtration

A compact, automotive air purifier that can easily remove up to 100 different types of pollutants including allergens, viruses, bacteria, and exhaust gases, and also neutralizes unpleasant odors inside the vehicle.

Filters harmful PM2.5 fine particles

- Filters harmful PM2.5 fine particles in less than 10 min.

Quickly remove toxic gases like exhaust fumes

- Quickly remove toxic gases like exhaust fumes from your car

Airmid filter removes 90% of airborne allergens

- Airmid certified filter removes 90% of airborne allergens

Easy installation

- Easy to install anywhere in your vehicle

Highlights

Certified filter

Independently tested by the respected biomedical research organization, Airmid Healthgroup, the Philips unique SelectFilter Plus technology removes up to 90% of airborne pollen allergens. The Airmid tests prove that this filtration is achieved in just one single pass of air through our SelectFilter, known as the single pass efficiency test. With these irritating particles removed, anyone suffering from hay fever can now enjoy clean air.

Easy to install

With a 12 ft power cable, you can easily install the GoPure anywhere inside your vehicle. Plug the cable into the vehicle's auxiliary power outlet and then use the mounting accessories to position the device where you prefer, such as the armrest, headrest or under the seats.

Powerful 3-layer filtration

Philips unique SelectFilter Plus filtration technology quickly and effectively removes particles detected in the car cabin, such as PM2.5. With a Clean Air Delivery Rate (CADR) of 16 m3/hour for particulate matter down to 2.5 microns (PM2.5), 50% of a standard sedan or SUV is filtered in less than 10 minutes. Not only does it remove harmful particles, but also cigarette smoke and dust so that you breathe fresh and clean air.

SelectFilter Plus technology

Philips unique SelectFilter Plus technology includes a HESA layer. This decontaminates your car of harmful gaseous chemicals. Cleans the air of chemicals emitted by plastic materials and other odor emitting substances e.g. volatile organic compounds (VOCs), toluene and formaldehyde.

Specifications

Product description

Designation: GP5212
Automatic On/Off
Filter replacement indicator
Fragrance dispenser: No
Speed settings: 2-speed fan
Filter Lifetime: 350hr hr
Technology: Car air purifier
Color: Black
App enabled: No
Voltage [V]: 12V DC
Frequency: N/A

Performance

Filtration of fine particles: CADR of 16 m3/hour

Replacement

GoPure clean air system type: SelectFilter Plus
Filter type: SFP120

Weight and dimensions

Box dimensions (LxWxH)(mm): 226 x 188 x 77
Box weight (incl. product) (g): 900
Product weight (g): 600
Product dimensions (LxWxH)(mm): 180 x 180 x 68 m

Marketing specifications

Product highlight: Filtered from 100 pollutants
Expected benefits: Healthy air in your car

Accessories in the box

Mounting accessories: Attachment belt, Hook fastener (X2)
power cable length: 4 m

Logistic data

Quantity in box: 1

Ordering information

Order entry: GP523BLACKX1
Ordering code: 78002002

Packaging Data

EAN1: 46678002007

