

PHILIPS

Penlight Premium
Colour+

Professional

200 lm Boost / 120 lm Eco

180 lm Spotlight

Daylight Colour Match (CRI 95)

Aluminium Housing,
Rechargeable



LPL81X1



See better, work better

Compact LED worker's companion

Equipped with a robust aluminium housing, the Philips Penlight Premium Colour+ provides bright, high-quality light. The Colour+ function shows objects in their true colours. Resistant to shocks, chemicals and water, this lamp is built to last!

See what others can't

- Colour+ function reveals objects in their true colours (CRI 95)

Highly robust

- Shock-, chemical- and water-resistant (IK07/IP54)
- Maximum durability with aluminium body

Be seen, stay safe

- Unique warning mode with bright red flashing light

Hands-free lighting

- Intelligently designed 80° swivel clip with magnet and ergonomic body

Highlights

Reveal colours accurately

The higher the Colour Rendering Index (CRI*), the easier it is to do a quick and precise inspection on your car body. You can inspect your paint, polish, clean or prep zone as if you were working outdoors on a bright sunny day. Lamps with a low CRI value cause some colours to appear unnatural. Light sources with a CRI of 90 or above will let you easily and quickly spot the colour difference such as paint scratch.

Robust and tough

Designed to withstand the toughest working environments with IK07 shock resistance. Because Philips knows even the most careful workers sometimes drop their tools. Water resistant to IP54 standards and with a surface that resists chemicals and workshop solvents, the Philips Penlight Premium Colour+ is a handy pocket tool that is built to last.

Maximum durability

Build for incredible durability with an aluminium body, the Philips Penlight Premium Colour+ is ready for just about any task or situation. This inspection lamp is impact- and scratch-resistant for safe, reliable use indoors and outdoors.

Unique warning mode

Philips Penlight Premium Colour+ offers a unique high frequency warning mode (75 flashes/min). The bright red flashing function means your Penlight Premium Colour+ can warn other road users of danger.

Hands-free for work

With the 80° swivel clip, it's easy to hang the Philips Penlight Premium Colour+ on your belt for a handy everyday carry. The 2 magnets leave both your hands free for work.

Specifications

Electrical characteristics

Battery capacity: 1200 mAh

Battery charging time: 1.8 hrs

Battery run time: Up to 4 hours

Battery type: Lithium Iron phosphate

Charging cable type: Type C USB cable

Power source: Rechargeable battery

Voltage: 100–240 V V

Wattage: 5 W

Plug type: EU plug (not included for UK)

Light characteristics

Beam angle: 70 degree degree

Beam angle (pointer): 20 degree

Colour temperature: 5700 K K

LED lifetime: Up to 10,000 hrs

Light output: 200 lm (Boost)/120 lm (Eco) lumen

Light output (pointer): 180 lm

Ordering information

Order entry: LPL81X1

Ordering code: 01391094

Outer Carton

Number of consumer packages: 4

Packaging Data

EAN1: 8719018013910

EAN3: 8719018013927

Packed product information

Pack Quantity / MOQ: 4

Size: 231 mm*98 mm*54 mm

Weight with batteries: 110 g

Product description

Hook: 80° swivel clip

Impact protection rating (IK): IK07

Ingress protection rating (IP): IP54

Magnet: 2

Materials and finishing: Robust aluminium housing

Operating Temperature: -10 to 50 °C

Range: Penlight, Professional

Resistant to: grease, oil, workshop solvents

Technology: LED

