



Philips Ultinon Pro5100  
Passive cooling LED bulb

### Type of lamp: H1

Brighter light  
Silent in operation  
5,800 K cool white light

LUM11258U51X2

# Brightness to penetrate the dark

## White light for brighter roads

Generating brightness close to daylight levels, Philips Ultinon Pro5100 LED bulbs provide crystal-clear forward visibility without dazzling other road-users. Their brilliant white beam comes from a compact, easy-fit design.

### Reliable Philips quality

- Philips automotive lighting for the highest quality

### Long lasting performance

- Built to last up to 3,000 hours

### Brilliant white light

- 5800 Kelvin color temperature for crisp white light

### Clearer vision

- Up to 160% brighter light\*
- Experience improved visibility

### Enhanced fit with compact design

- 12V- and 24V-compatible for wider usability
- Plug-and-play use

# PHILIPS

Passive cooling LED bulb  
Type of lamp: H1 Brighter light, Silent in operation, 5,800 K cool white light

LUM11258U51X2

# Specifications

## Marketing specifications

- Expected benefits: Brighter Lights
- Product highlight: Automotive Grade LED

## Product description

- Application: High beam
- Base: P14,5s
- Designation: LED H1 11258 U51 X2
- Homologation ECE: NO
- Range: Ultinon Pro5100
- Technical features: AirFlux+, SafeBeam Technology
- Technology: LED
- Type: LED-HL [-H1]

## Lifetime

- Life time: 3000 hrs

## Light characteristics

- Color temperature: 5800K
- Lumens [lm]: 1100

## Electrical characteristics

- Wattage: 12 W
- Voltage: 13.2 V

## Ordering information

- Order entry: 11258U51X2
- Ordering code: 01878694

## Packaging Data

- EAN1: 8719018018786
- EAN3: 8719018018793
- Packaging type: X2

## Packed product information

- Length: 11 cm
- Width: 5 cm
- Height: 16 cm
- Pack Quantity: 2 pcs
- MOQ (for professionals): 4 packs
- Net weight per piece [g]: 70
- Gross weight individual pack: 240

## Outerpack information

- Length: 27 cm
- Width: 17 cm
- Height: 15 cm
- Gross weight per piece: 1.2 kg

# Highlights

## Up to 160% brighter light\*

Take the strain out of driving at night. Philips Ultinon Pro5100 LED headlight bulbs offer razor-sharp vision without dazzling other road-users. More effective headlights enable you to spot hazards earlier, judge distances better and position your vehicle more accurately on the road. Featuring optimal color temperature and SafeBeam technology, these lamps generate a brilliant white beam close to daylight in its intensity. Experience visibility enhanced by up to 160%. So choose Philips for a safer, more satisfying drive in the dark.

## 5800 K for crisp white light

With a high color temperature of up to 5800 Kelvin, the Philips Ultinon Pro5100 produces a bright white light that's close to daylight. The clearer vision this provides makes it easier to spot obstacles and take the perfect driving line. The optimal color temperature avoids tiring or straining the eyes, giving you more comfortable and safer night-time driving.

## Built to last

You want bright, stylish headlights but you don't want to keep replacing failed lamps. LED lights generate heat that must be managed. Philips AirFlux+ technology is a powerful cooling system with high thermal dispersion based on optimized materials and a high-performance coating. It diverts heat away from the light's critical components. Greater heat resistance enables Philips Ultinon LED to last longer than comparable products currently on the market. Philips Ultinon Pro5100 provides up to 3,000 hours' use.

## Plug-and-play use

This bulb is compatible with a wide range of car models and can be easily installed by DIYers or specialist mechanics.

## Experience improved visibility

Beam pattern is just as important as brightness: a uniform, accurate beam pattern lets you see and be seen more clearly. Thanks to the perfect positioning of the LED chips on Philips Ultinon Pro5100 bulbs, drivers have light exactly where they need it on the road without dazzling oncoming vehicles.

## 12V - 24V for wider usability

Philips Ultinon Pro5100 is compatible with 12V and 24V electrical systems, making it suitable for most vehicle types.

## Highest quality lighting

Technologically advanced Philips lighting is renowned in the automotive industry, and has been for over 100 years. Philips Automotive Grade Quality products are designed and developed following strict quality-control processes, leading to consistently high production standards. Major car manufacturers choose Philips lamps, because when you buy Philips, you buy quality. You get powerful, bright light and precise beam performance. You get high-end style. And you get an advanced LED lighting system for a safer, smoother, more enjoyable drive.



Issue date 2024-08-28

Version: 4.4.1

© 2024 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)

\* Compared to the legal minimum for halogen bulbs.