



Philips Ultinon Pro9100  
with exclusive +Lumileds  
automotive LED

LED-FOG [~H8/H11/H16]

Up to 350% brighter light  
Cool white light  
Lumileds TopContact LEDs

LUM11366U91X2

## Breakthrough LED for driving enthusiasts

### Original automotive performance

The Philips Ultinon Pro9100 sets a new standard in retrofit LED bulbs. It offers up to 350% brighter\*, whiter light for optimal performance and a compact design for easy fitting to most vehicles.

#### **Automotive-grade quality**

- The durability that today's drivers demand

#### **Performance made to last**

- Enhanced lifetime of up to 5,000 hours

#### **Best-in-class cut-off line**

- Light exactly where you need it on the road

#### **Superior visibility and high-end style**

- OEM LEDs exclusive to Lumileds in aftermarket
- Up to 350% brighter light
- Up to 5,800 Kelvin colour temperature for cool white light

#### **Optimal design for the perfect fit**

- 12 V and 24 V compatible for wider usability
- High electrical compatibility with most vehicles
- Small footprint, big performance

# PHILIPS

with exclusive +Lumileds automotive LED  
LED-FOG [~H8/H11/H16] Up to 350% brighter light, Cool white light, Lumileds TopContact LEDs

# Highlights

## Up to 350% brighter light

The new Philips Ultinon Pro9100 headlight bulbs provide the exceptional visibility that you need while driving. Thanks to enhanced LED binning and meticulous product refinement, they offer consistent light that's up to 350% brighter than the legal minimum for halogen bulbs. Their optimal spectrum makes road signs more visible. See further, react faster!

## Exclusive Lumileds TopContact

Always a step ahead, Philips Ultinon Pro9100 is driving performance with its exclusive top-quality Lumileds TopContact LED chips. These unique OEM LEDs provide optimised light consistency, generate less heat and feature the ideal light colour for sharper visibility. One reason why the world's major car manufacturers choose Lumileds automotive LED chips and Philips headlight bulbs is that they're fitted with the very best components and technologies, giving you unparalleled performance and enhanced bulb lifetime.

## Up to 5800 Kelvin

Enjoy the balance of practicality and performance. Philips Ultinon Pro9100 features a colour temperature of up to 5800 K, proven among Original Equipment Manufacturers to maximise eye comfort while driving at night. This reduces fatigue and the risk of eye strain to make driving in the dark a safer, more pleasant experience.

## Light exactly where you need

Thanks to the perfect positioning of the LED chips on Philips Ultinon Pro9100 bulbs, drivers have light on the road exactly where they need it, without dazzling oncoming vehicles. Our bulbs also feature Philips SafeBeam, producing the best usable beam and glare-free pattern. Drive safer with Philips Ultinon Pro9100.

## Small footprint

Philips Ultinon Pro9100 gives you powerful technology in a small but effective design. Conceived with performance and ease of use in mind, the Philips Ultinon Pro9100's new one-piece bulb design allows

fast, hassle-free installation. The built-in driver means no more worries about limited space in the headlight unit. This super-compact design ensures compatibility with a wide range of car models.

## Electrical compatibility

LED retrofit and halogen bulbs differ from one another in terms of wattage, composition and power consumption. Replacing your halogen bulbs with other LEDs may cause issues such as flickering light. Philips Ultinon Pro9100 bulbs need no additional adapters\*\* to eliminate flickering in most vehicles. They work right away with the vehicle's electrical system, providing a consistent light beam and colour temperature. \*\* In rare cases, an additional Light repair CAN bus may be needed to eliminate flickering completely.

## 12 V-24 V for wider usability

Philips Ultinon Pro9100 is compatible with both 12 V and 24 V electrical systems, making it suitable for most vehicle types.

## Up to 5000 hours' lifetime

You want bright, stylish headlights but you don't want to keep replacing failed lamps. That's a major weakness of conventional headlights; the more powerful the light, the shorter its lifespan. At a higher light-intensity level, LEDs last much longer, and Philips Ultinon Pro9100 headlights are built to last. Due to features such as AirBoost and AirCool heat-management systems, they last for up to 5000 hours of operation.

## Durability for today's drivers

IP55-certified against dust ingress and with splash-water protection, Philips Ultinon Pro9100 bulbs are also guaranteed EMI-compliant, conforming to automotive-industry standards on electromagnetic interference. Precision engineered to withstand the rigours of modern motoring life, they offer the durability that today's drivers demand. Their daily performance provides confidence behind the wheel and brighter, consistent light throughout the journey.

LUM11366U91X2

# Specifications

## Marketing specifications

- Expected benefits: Brighter Lights
- Product highlight: Automotive Grade LED, Lumileds TopContact LED, AirBoost Technology

## Product description

- Application: Front fog
- Base: PGJ19-1; PGJ19-2; PGJ19-3
- Designation: LED Fog 11366 U91 X2
- Homologation ECE: NO
- Range: Ultinon Pro9100
- Technical features: AirBoost, SafeBeam Technology
- Technology: LED
- Type: LED-FOG [~H8/H11/H16]

## Lifetime

- Life time: 5000 hrs

## Light characteristics

- Colour temperature: 5800 K
- Lumens [lm]: 1000

## Electrical characteristics

- Voltage: 13.2 V
- Wattage: 11 W

## Ordering information

- Order entry: 11366U91X2
- Ordering code: 01860194

## Packaging Data

- Packaging type: X2
- EAN1: 8719018018601
- EAN3: 8719018018618

## Packed product information

- Length: 15.2 cm
- Width: 7 cm
- Height: 18.9 cm
- Net weight per piece: 53 g
- Pack Quantity: 2 pcs
- MOQ (for professionals): 4 packs
- Gross weight individual pack: 346

## Outer pack information

- Length: 32.5 cm
- Width: 22 cm
- Height: 19.1 cm
- Gross weight [kg]: 1.7



Issue date 2023-11-28

Version: 1.0.1

© 2023 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)

\* Compared to the legal minimum for halogen bulbs.

\*\* In rare cases, an additional Light repair CAN bus may be needed to eliminate flickering completely.