

PHILIPS

Xenon car headlight bulb

X-tremeVision

Type of lamp: D1S

Pack of: 1

85 V, 35 W



85415XVC1



Feel safe, drive safe

Up to 50% more vision

Philips X-tremeVision Xenon offers up to 50% more vision. This high-power xenon lighting solution provides maximum brightness for maximum visibility.

Brighter light for maximum visibility and safety

- Better visibility for safer driving
- Xenon X-treme vision is the ultimate performance solution

Xenon quality and ultra-resistant car bulb

- Philips is the inventor of Xenon HID technology
- Philips car lamps are highly UV resistant
- Philips car lamps are made of high-quality quartz glass
- Philips car lamps are highly resistant to humidity

Original Equipment manufacturer

- Philips is the choice of major car manufacturers
- Award-winning car lamp manufacturer
- Respecting the high-quality standards of the ECE homologation

Highlights

Car manufacturers' choice



For 100 years, Philips has been at the forefront of the automotive lighting industry, introducing technological innovations that have become standard on modern automobiles. Today, one in two cars in Europe and one in three worldwide is equipped with Philips lighting

ECE homologation

Philips automotive products and services are considered best-in-class in the Original Equipment Manufacturer market and the aftermarket. Manufactured from high quality products and tested to the highest specifications, our products are designed to maximise the safety and comfort of our customers' driving experience. Our entire product range is thoroughly tested, controlled and certified (ISO 9001, ISO 14001 and QSO 9000) to the highest ECE requirements. Put simply, this is quality you can trust.

Award-winning car lamps



Our lamps are often rewarded by automotive experts

Maximum safety and visibility

Xenon X-tremeVision provides you with a better reactivity thanks to earlier recognition of obstacles and traffic signs. Light is a fundamental part of the driving experience and light is the first and only part of the safety circle that actually helps prevent accidents. Philips promotes active safety protection to prevent accidents by increasing overall visibility and road illumination; as a matter of fact the 4800 K colour temperature increases the visual comfort.

Original Xenon technology



Xenon HID (High Intensity Discharge) lamps offer twice as much light for safer driving in all conditions. As a matter of fact, the intense white light produced by the Xenon HID lamps is comparable to daylight. Studies have demonstrated that xenon automotive lighting helps drivers to concentrate on the road and to distinguish obstacles and road signs much faster than traditional lamps.

Up to 50% more vision

Xenon X-tremeVision lamps are engineered with Philips Xenon technology for ultimate performance. Producing a longer beam, Xenon X-treme vision helps you to see obstacles earlier and improves the side perception. By producing even more light, Xenon X-treme vision lamps satisfy the most demanding drivers while maintaining their high Original Equipment quality and superior performance.

UV Resistant



Philips special anti-UV coating technology protects the headlights against harmful ultraviolet radiation, making Philips UV-coated quartz glass perfect for all driving conditions and ensuring their longevity

High-quality quartz glass



UV-Quartz glass is stronger than hard glass and highly resistant to temperature extremes and vibrations, which eliminates the risk of explosion. Philips quartz-glass lamps are able to withstand severe thermal shock. With the capability of increased pressure inside the lamp, UV-quartz glass is able to produce a more powerful light.

Resistance to humidity

Only a burning bulb made of quartz glass can resist thermal shocks, such as a drop of cold water touching the hot bulb, which can happen when you drive through water with a broken headlight unit.

Specifications

Packaging Data

EAN3: 8727900364439

EAN1: 8727900364415

Packaging type: C1

Electrical characteristics

Voltage: 85 V

Wattage: 35 W

Lifetime

Life time: 2500h

Light characteristics

Colour temperature: 4800±600 K

Lumens: 3200 ±450 lm

Ordering information

Order entry: 85415XVC1

Ordering code: 36441533

Outer pack information

Height: 5.7 cm

Length: 11.1 cm

Width: 9.6 cm

Gross weight per piece: 0.204 kg

Product description

Type: D1S

Application: High beam, Low beam

Designation: D1S X-tremeVision

Homologation ECE

Range: X-tremeVision

Technology: Xenon

Base: PK32d-2

Packed product information

Pack Quantity: 1

MOQ (for professionals): 2

Gross weight per piece: 152.5, 97 g

Height: 9.3 cm

Length: 5.4 cm

Net weight per piece: 73.2 g

Width: 5.4 cm

Marketing specifications

Expected benefits: More light

Product highlight: Up to 50% more vision

