

# PHILIPS

Moto headlight bulb

Ultinon Essential  
Moto LED

LED-HL [-M5]

+100% brighter light

6500 K sharp white light

Compact design for 2-wheelers

11163UEMX1



## Stand out from the crowd

Stylish LED lighting that's easy to fit

Compatible with most two-wheelers, this bulb easily upgrades your style and safety. Featuring a stylish look and effective heat management, Ultinon Essential Moto LED headlight bulbs provide consistently high-performing light on the road.

### **Powerful brightness**

- Experience improved visibility

### **Stylish white look**

- Enjoy a stylish, white-light experience

### **Effective heat management**

- Excellent cooling via effective heat dissipation

### **Compatible with most motorcycles**

- Compact design for quick and simple installation

### **Reliable Philips quality**

- Expect long-lasting performance, not early failure
- Highest quality Philips automotive lighting

# Highlights

## 100% Brighter light

For enhanced safety and perfect style, choose high-performing Philips Ultinon Essential moto LED with +100% brighter light for better visibility ahead of you. The uniform, accurate beam pattern allows you to see well and be seen for your safety

## 6500 Kelvin sharp white light

For that modern, high-end look, customize your motorcycle with Ultinon Essential moto LED headlights. With a color temperature of 6500 Kelvin, these lights project a trendy, white light. Stand out from the crowd with a stylish beam.

## Excellent cooling performance

Heat management is critical to the performance of LED lights. The built-in aluminum heatsink with anodized coating for effective heat dissipation helps Philips Ultinon Essential moto LED headlights disperse heat effectively, so they always perform at optimal brightness (even when very hot – unlike inferior quality LEDs). And they also last longer, so you don't have to replace them as often.

## Compact design for easy fit

The compact design of the Ultinon Essential Moto LED makes installation simple. Even in the smallest two-wheeler headlamps, you'll have space to fit these bulbs.

## Long-lasting performance



You want bright white LED lights for that modern look. But some who opt for new LED lights are disappointed by the experience. This is usually because the claimed heat-management performance does not materialize in real-world conditions. In other words, they have bought inferior products that fail too quickly. Philips Ultinon Essential LED products are durable and reliable, lasting up to five years under real-life conditions.

## Automotive grade quality

Technologically advanced Philips lighting is renowned in the automotive industry, and has been for over 100 years. The Philips Automotive Grade Quality products are designed and developed following strict quality control processes (including applicable ISO norms), leading to consistently high production standards.

# Specifications

## Packaging Data

Packaging type: X1  
EAN1: 8719018003157  
EAN3: 8719018003171

## Light characteristics

Color temperature: 6500 K  
Lumens: 460 lm

## Marketing specifications

Expected benefits: Transform your lights  
Product highlight: Philips LED lamps

## Product description

Range: Ultinon Essential Moto  
Technology: LED  
Base: P15d-25-1  
Application: High beam, Low beam  
Type: LED-HL [-M5]  
Homologation ECE: NO  
Designation: LED-HL [-M5]

## Lifetime

Life time: 5 years

## Electrical characteristics

Voltage: 12 V  
Wattage: 6 W

## Ordering information

Ordering code: 315730  
Order entry: 11163UEMX1

## Packed product information

Height: 7.5 cm  
Length: 5.5 cm  
Width: 2.6 cm  
MOQ (for professionals): 10  
Pack Quantity: 1  
Net weight per piece [g]: 3.3

## Outerpack information

Height: 6 cm  
Length: 16 cm  
Net weight per piece: 70 g  
Width: 14 cm  
Gross weight per piece [kg]: 65

