

Philips Ultinon Drive
Accessory
Aluminium back-mounting
kit

Corrosion-resistant
Stainless steel hardware incl.
Reliable Philips quality

LUMUD1001MX1



Precise fit and easy installation

Smooth and reliable installation

The aluminium back-mounting brackets offer a lightweight, highly corrosion-resistant, versatile solution for mounting any Philips LED driving-light bars*. The brackets are supplied in pairs with A2 stainless-steel hardware included.

Optimal fit

- Easy to install

Reliable Philips automotive quality

- Durable material for long-lasting performance

PHILIPS

Aluminium back-mounting kit
Corrosion-resistant Stainless steel hardware incl., Reliable Philips quality

LUMUD1001MX1/10

Specifications

Highlights

Product description

- Technology: Back-mounting accessory kit
- Compatible with: Philips Ultinon Drive UD5001L, UD5002L, UD5004L, UD5101L, UD5102L, UD5103L, UD5104L, UD7050L
- Material: Aluminium, powder coated painted

Ordering information

- Order entry: UD1001MX1
- GOC: 01858834

Packaging Data

- EAN1: 8719018018588
- EAN3: 8719018018595

Packed product information

- MOQ (for professionals): 12
- Box dimensions-L (mm): 350
- Box dimensions-W (mm): 60
- Box dimensions-H (mm): 90

Back-mounting brackets

The UD1001M back-mounting brackets offer a lightweight, versatile solution for fitting Philips LED driving-light bars* to your vehicle. The brackets can be bolted into pre-existing holes in the vehicle's bodywork and then attached to the rail on the back of the light bar. This avoids further drilling and allows you to raise/lower the lights by <2 cm.

Corrosion free

The UD1001M back-mounting kit is made from 6 mm folded aluminium that is black-powder-coated for high corrosion resistance. The brackets are supplied in pairs with A2 stainless steel hardware.



Issue date 2024-04-04

Version: 5.5.1

© 2024 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

* Compatible with: Philips Ultinon Drive UD5001L, UD5002L, UD5004L, UD5101L, UD5102L, UD5103L, UD7050L