



Philips Xenon X-tremeVision gen2  
Xenon car headlight bulb

Type of lamp: D5S

Up to 120% more vision  
Optimal light spectrum  
Enhanced light performance

12410XV2C1

## Feel safe and drive safe with brighter lights

See every bump, curve and obstacle in the road

With a powerful beam that pushes light emission to the limit, X-tremeVision gen2 is the latest development in xenon technology. This outstanding light performance extends your driving limits, so you enjoy a safer, more comfortable drive.

### Light spectrum: a comfortable driving experience

- Better visibility for safer, more comfortable driving

### Optimal light performance

- Directing the light to the right spot in front of your car

### Xenon quality and ultra resistant car lamp

- Philips invented innovative Xenon HID technology

### Original equipment manufacturer

- Philips car lamps are award-winning
- Respecting high quality standards of the ECE homologation
- Protection from UV damage
- Philips car lamps are made of high-quality quartz glass
- Philips is the choice of major car manufacturers

### Brighter for maximum visibility and safety

- Xenon X-tremeVision gen2: for superior visual performance

# PHILIPS

## Xenon car headlight bulb

Type of lamp: D5S Up to 120% more vision, Optimal light spectrum, Enhanced light performance

# Highlights

### Up to 120% more vision

Xenon X-tremeVision gen2 lamps are engineered with Philips Xenon technology for ultimate performance. Producing a longer beam and up to 150% more vision, X-tremeVision gen2 lamps help you spot obstacles earlier, allowing you to react in time. And with improved peripheral vision, you'll have greater awareness of any dangers at the side of the road, such as pedestrians or upcoming junctions. Brightly illuminating every bump, curve and hazard in the road, these are headlamps to satisfy the most demanding drivers and the most demanding driving conditions.

### Maximum safety and visibility

Light is a fundamental part of the driving experience. Simply by improving the quality of light you can help prevent accidents. The Xenon X-tremeVision gen 2 improves visibility, so you're able to recognize obstacles and traffic signs earlier, improving your reaction times. The spectral composition of this light is adapted to the natural color sensitivity of your eye. And with 4800K color temperature, this headlamp produces light that's gentle on your eyes, making the night-time driving experience safer and more comfortable.

### Optimal light performance

It's not enough to just have powerful headlights; optical precision matters, too. The Xenon X-tremeVision gen2 lamps have the most precise arc bending technology aligned at 150-350µm. This means they illuminate the road just where you need it, without dazzling oncoming drivers.

### Original Xenon technology

Xenon HID (High Intensity Discharge) lamps offer twice as much light for safer driving in all conditions. Studies have shown xenon automotive lighting helps drivers to concentrate on the road and to distinguish obstacles and road signs much faster than with traditional lamps. And what better way to defeat darkness than with an intense white light comparable to daylight?

### High quality quartz glass



UV-Quartz glass is stronger than hard glass and highly resistant to temperature extremes and

vibrations, which eliminates the risk of explosion. So Philips quartz-glass lamps are able to withstand severe thermal shock. With the capability of increased pressure inside the lamp, UV-quartz glass is able to produce a more powerful light. And more powerful light means an enhanced driving experience, how ever dark the road in front of you.

### UV resistant glass

Philips special anti-UV coating technology protects the headlights against harmful ultraviolet radiation, making Philips UV-coated quartz glass perfect for all driving conditions. This additional protective layer ensures your lights are built to last.

### Highest quality car lighting

Technologically advanced Philips lighting is renowned in the automotive industry, and has been for over 100 years. The Philips Original Equipment Quality products are designed and developed following strict quality control processes (including applicable ISO norms), leading to consistently high production standards. Philips Xenon X-tremeVision gen2 is compatible with car models of major brands, such as Audi, BMW, Ford, GM, Toyota and Volkswagen. See the product selector guide for more information.

### Award-winning car lamps

Our high-quality and innovative vehicle lights are award-winning, being consistently recognized by automotive experts.

### ECE homologation

Philips automotive products and services are considered best-in-class in the Original Equipment Manufacturer market and the aftermarket. Manufactured from high quality products and tested to the highest specifications, our products are designed to maximize the safety and comfort of our customers' driving experience. Our entire product range is thoroughly tested, controlled and certified (ISO 9001, ISO 14001 and QSO 9000) to the highest ECE requirements. Put simply, this is quality you can trust.

12410XV2C1

# Specifications

### Marketing specifications

- Expected benefits: More light
- Product highlight: Up to 150% more vision

### Product description

- Application: High beam, Low beam
- Base: PK32d-7
- Designation: 12410XV2C1
- Homologation ECE
- Range: Xenon X-tremeVision gen2
- Technology: Xenon
- Type: D5S

### Lifetime

- Life time: 3000

### Light characteristics

- Lumens: 2000lm +300/-200
- Color temperature: 4800 K

### Electrical characteristics

- Wattage: 25 W
- Voltage: 12 V

### Ordering information

- Order entry: 12410XV2C1
- Ordering code: 35392133

### Packaging Data

- Packaging type: C1
- EAN1: 8727900353921
- EAN3: 8719018005090

### Packed product information

- Length: 6.1 cm
- Width: 6.6 cm
- Height: 8.1 cm
- Pack Quantity: 1
- MOQ (for professionals): 2

### Outerpack information

- Length: 14.6 cm
- Width: 12.2 cm
- Height: 11.8 cm
- Gross weight per piece: 0.377 kg



Issue date 2024-08-05

Version: 5.5.1

© 2024 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)