

PHILIPS

UV Pillar

Xperion 6000

500 lm Boost / 250 lm Eco

180 lm Spotlight + UV

Battery life: 4.5 h (Eco: 10 h)

High CRI and UV leak-detector



X60UVPIX1

Designed with you in mind

Advanced lighting performance that lasts

Our premium lamp, the Philips Xperion 6000 UV Pillar, is a multi-purpose work light with several powerful light sources, UV light, high CRI and long-lasting battery. Locate your lamp in seconds with the "Find My Device" function.

Accessories available to upgrade your work lamp

- Smart solutions for charging your device

Extended warranty

- Extend your warranty online to 3 years

Handles tough conditions easily

- Resistant to impacts, water and solvents (IP65/IK07)

Smart, ergonomic design

- Easily retrieve your device
- Smart rotatable hook with magnet and ergonomic body

See where others can't

- Long running time in different light modes
- Premium LED light with multiple outputs
- Reveals objects in their true colours (CRI95)
- Spot leaks with UV light

Highlights

Multiple light modes



The premium, homogenous LED illuminates with 100% reliability, ideal for multiple uses. It helps you see clearly in dark environments, easily revealing discolouration and damaged components. The Philips Xperion 6000 UV Pillar is a top-quality, trustworthy light for all types of inspection and repair work.

Unique UV leak detector



This premium work lamp comes with an additional UV light to help you easily spot leakages. Direct the UV light over any area to identify where leak repairs are necessary. The Philips Xperion 6000 UV Pillar has all your illumination needs covered.

Reveal colours accurately



The higher the Colour Rendering Index (CRI), the easier it is to perform a quick and accurate inspection of car bodywork. You can inspect your paint, polish, clean or prep zone as if you were working outdoors on a bright sunny day. Lamps with a low CRI value cause some colours to appear unnatural. Light sources with a CRI of 90 or above will let you easily and quickly spot colour differences such as paint scratches.

Light modes for multiple needs



The Philips Xperion 6000 UV Pillar is designed to be ready for action. A single charge provides enough energy for a full day's work: up to 10 hours in Eco mode, 4.5 hours in Boost mode and 12 hours with the torch beam. Powered by a powerful Li-ion battery, the Philips Xperion 6000 UV Pillar can be fully charged within 4.5 hours via USB-C, ensuring maximum usage of its bright LED light.

Enables hands-free working



Designed with you in mind, the ergonomically shaped handle with an anti-slip coating allows you to hold this work light securely. If you need both hands free for work, position the light securely thanks to the 360° rotatable, retractable hook and a strong magnet. The power button is located on the back to ensure that the light does not glare directly at your eyes when you turn it on.

"Find My Device" function



Don't worry about losing your device anymore. You can find it easily with the "Find My Device" function. Use the remote control to trigger an

audible buzzer and flashing light to locate your device. The lime-green body will help you spot your device even in dark settings.

Designed for resistance



Designed to handle tough work environments with IK07 shock resistance, water-resistant to IP65 standards and a surface to withstand chemicals and workshop solvents, the Philips Xperion 6000 UV Pillar is built to last because we know that even the steadiest hands need the extra support.

Up to 3 years' warranty



Benefit from the Philips standard 2 year warranty plus 1 additional year¹

Upgrade your work light



To keep your work light to hand and ready to use, try the Philips Dock station. Placed on a table, it provides cordless charging for your lamp². Find out more: [Philips.com/Xperion-6000](https://philips.com/Xperion-6000)

Specifications

Marketing specifications

Product highlight: High CRI and UV leak-detector

Expected benefits: Designed with you in mind

Product description

Hands-free options: Rotatable hook, strong magnet

Hook: 360° rotatable

Impact protection rating (IK): IK07

Magnet: 2 magnets

Materials and finishing: Robust ABS + Soft rubber

Operating Temperature: -10°C to 40°C

Range: Xperion 6000

Technology: COB LED

UV leak detector

Ingress protection rating (IP): IP65

Resistant to: Grease, oil, workshop solvents

Light characteristics

Beam angle: 100 degree

Colour temperature: 6000 K

Light output (pointer): 180 lumens

Light output (eco): 250 lumens

Beam angle (pointer): 15°

Light output (boost): 500 lumens

Electrical characteristics

Voltage: 3.7 V

Power source: Rechargeable battery

Battery capacity: 4400 mAh

Battery run time (boost): Up to 4.5 hours

Battery run time (eco): Up to 10 hours

Battery type: Lithium battery

Plug type: EU plug (not included for UK)

Charging cable type: Type C USB

Battery charging time: Up to 4.5 hours

Wattage: 5 W

Battery run time (pointer): Up to 12 hrs

Ordering information

Order entry: X60UVPIX1

Ordering code: 01471931

Packaging Data

EAN1: 8719018014719

EAN3: 8719018014726

Packed product information

Length: 5.2 cm

Height: 23 cm

Pack Quantity / MOQ: 6

Weight with batteries: 432 g

Cable length: 100 cm USB cable, 5 V 1 A adapter

Outer pack information

Length: 25 cm

Width: 17 cm

Height: 18 cm

