

PHILIPS

Flood

Xperion 6000

1000 lumens/250 lm Spotlight

Light zoom function

Motion-sensing

Highly versatile

LUMX60FLX1



Designed with you in mind

Multi-purpose LED projector light

With its 1000 lm flood light and variable beam, the Philips Xperion 6000 Flood multi-purpose projector gets the job done. The smart-zoom knob and motion sensor simplify control, while resistance to impacts and water guarantees durability.

See where others can't

- Powerful white light (1000 lumen / 10 W) lights up large area
- The two most used lights combined into one lamp

Smart, ergonomic design

- Rechargeable via USB type C or wireless dock station
- Motion detection enables remote control for your light
- Smart-zoom knob to easily control your light
- Smart handle to position light for hands-free use

Highly versatile

- Recharge other devices with a useful USB port

Extended warranty

- Extend your warranty online to 3 years

Handles tough conditions easily

- Resistant to impacts, water and solvents (IP65/IK07)

Highlights

Illuminate the whole work area

Whether you need to light up a work site, temporarily replace a wall lamp or illuminate outdoor activities, the Philips Xperion 6000 Flood projector is perfect for lighting up large dark areas. Delivering a powerful 1000 lumen (10 W), its consistently bright light gives off a super-wide beam. If you need less light and more battery life, you can easily dim the lamp to a 100 lumen output.

Multi-purpose light

Different jobs demand different amounts of light. The Philips Xperion 6000 Flood projector combines in one lamp the two most commonly used forms of workshop lighting. A wide-angle homogeneous flood light for working on big areas over longer periods, and a focused light that concentrates illumination within small areas to get the best contrast and brightness, ideal for detailed inspections and narrow spaces.

Smart-zoom knob

Co-designed with mechanics, the ergonomic smart-zoom knob allows you to adjust your light from wide flood illumination to focused brightness easily, even with your gloves on. Positioned on the side of the lamp, the rotatable smart-zoom knob is always within reach, meaning you don't have to move the lamp from its mounted position. The lamp's smart design enables it to remember your last setting and restart directly at the desired intensity.

Control your light remotely

If you need both hands free for work, you can remotely power the light on or off by simply waving your hand. Designed to ignore unintended movements, the sensor only responds to a specific double-wave gesture.

Versatile attachments

The smart handle can be used as a support to hold the projector up by itself or as a hook to hang the light from, and can be screwed on to a tripod or attached to any metal surface with its integrated magnets. This versatility allows you to position the light easily and at the right angle, directing the beam just where you need it.

Designed for durability

Designed to handle tough work environments with IK07 shock resistance, water resistance to IP65 standards, and a surface to withstand chemicals and workshop solvents, the Philips Xperion 6000 Flood is built to last because we know that even the steadiest hands need extra help.

Recharge other devices

The Philips Xperion 6000 Flood projector can be also used as a power bank to charge other devices, such as your phone. Simply plug your device into the USB port on the back of the lamp and it will begin charging.

Up to 3 years' warranty

Benefit from a Philips standard 2 year warranty plus 1 additional year*.

Ready for action

The Philips Xperion 6000 Flood projector can be charged by USB type C cable (included in the pack), or directly on the Philips wireless dock station. Find out more: [Philips.com/Xperion-6000](https://www.philips.com/Xperion-6000)

Specifications

Electrical characteristics

Battery capacity: 4400 mAh mAh
Battery charging time: Up to 5 h
Battery run time (boost): 3 h
Battery run time (eco): 22 h
Battery run time (pointer): 9 h
Battery type: Lithium battery
Charging cable type: Type C USB
Plug type: EU plug (not included for UK)
Voltage: 3.7 V
Wattage: 10 W
Power source: Rechargeable battery

Light characteristics

Beam angle: 100 degree
Beam angle (pointer): 15 degree
Colour temperature: 6000 K
Light output (boost): 1000 lumens
Light output (eco): 100 lumens
Light output (pointer): 250 lumens

Marketing specifications

Expected benefits: Designed with you in mind
Product highlight: Powerful and ergonomic

Ordering information

Order entry: X60FLX1
Ordering code: 1909731

Packaging Data

EAN1: 8719018019097
EAN3: 8719018019103

Packed product information

Cable length: 100 cm USB cable, 5 V 1 A adapter
Height: 140 cm
Length: 90 cm
Pack Quantity / MOQ: 6
Width: 60

Product description

Bluetooth connection
Hands-free options: Rotatable hook, strong magnet, Smart handle
Impact protection rating (IK): IK07
Ingress protection rating (IP): IP65
Magnet: Magnetic handle
Materials and finishing: Robust ABS
Operating Temperature: -10°C to 40°C
Resistant to: Grease, oil, workshop solvents
Technology: COB LED
UV leak detector: No
Range: Xperion 6000
Hook: 180° rotatable

