

PHILIPS

Pocket

Xperion 6000

300 lm Boost / 150 lm Eco

100 lm Spotlight

Battery life: 3,5h (Eco: 7h)

Compact and flexible



X60POCKX1



Designed with you in mind

Advanced lighting performance that lasts

The compact, powerful Philips Xperion 6000 Pocket is perfect for confined spaces with an ultra-flexible 100 lm, 25cm hose spotlight. There's also a wide-beam light with 150 lm in Eco and 300 lm in Boost mode.

See where others can't

- Premium LED light with multiple outputs
- Long running time in different light modes

Smart, ergonomic design

- Precision light with flexible hose spot
- Smart rotatable hook with magnet and ergonomic body

Handles tough conditions easily

- Resistant to impacts, water and solvents (IP65/IK07)

Extended warranty

- Extend your warranty online to 3 years

Accessories available to upgrade your work lamp

- Smart solutions for charging your device

Highlights

Multiple light modes



The powerful Xperion 6000 Pocket offers bright and homogenous LED lamps. The main beam features a dual light mode of 150 lm in Eco and 300 lm in Boost. This handy pocket torch is also equipped with a super flexible 100 lm hose spotlight, which is perfect for getting around obstacles.

Illuminate your work



The Philips Xperion 6000 Pocket is equipped with a powerful 25cm hose spotlight to light any angle. The narrow and compact design is extremely convenient to help you work in confined small spaces. Slip Philips Xperion 6000 Pocket into your pocket and use it for a wide range of needs.

Designed for resistance



Designed to handle tough work environments with IK07 shock resistance, water-resistant to IP65 standards, and a surface to withstand chemicals and workshop solvents, the Philips Xperion 6000 Pocket is built to last because we know that even the steadiest hands need the extra support.

Light modes for multiple needs



The Philips Xperion 6000 Pocket is designed to be ready for action. A single charge provides enough energy for a full day's work: up to 7 hours in Eco mode, 3,5 hours in Boost mode, and 10 hours with the torch beam of the hose. Powered by a powerful Li-ion battery, the Xperion 6000 Pocket can be fully charged within 3,5 hours via USB-C, ensuring maximum usage of its bright LED light.

Enables hands-free working



Designed with you in mind, the ergonomically shaped handle with anti-slip coating allows you to hold this work light securely. If you need both hands free for work, position the light securely thanks to the 360° rotatable, retractable hook and a strong magnet. The power button is located on the back to ensure the light does not glare directly at your eyes when you turn it on.

Up to 3 years warranty



Benefit from Philips standard 2-year warranty plus 1 additional year¹

Upgrade your work light



To keep your work light to hand and ready to use, try the Philips Dock station. Placed on a table, it provides cordless charging for your lamp.² Find out more: [Philips.com/Xperion-6000](https://philips.com/Xperion-6000)

Specifications

Electrical characteristics

Battery capacity: 2000 mAh
Battery charging time: Up to 3,5 hours
Battery run time (boost): Up to 3,5 hours
Battery run time (eco): Up to 7 hours
Battery run time (Pointer): Up to 10 hours
Battery type: Lithium battery
Charging cable type: Type C USB
Plug type: EU plug (not included for UK)
Voltage: 3.7 V
Wattage: 3W
Power source: Rechargeable battery

Light characteristics

Beam angle: 110 degree
Beam angle (pointer): 60 degree
Color temperature: 6000 K
Light output (boost): 300 lumens
Light output (eco): 150 lumens
Light output (pointer): 100 lumens

Marketing specifications

Expected benefits: Designed with you in mind
Product highlight: Compact and flexible

Ordering information

Order entry: X60POCKX1
Ordering code: 01465831

Outerpack information

Height: 17 cm
Length: 21.5 cm
Width: 17 cm

Packaging Data

EAN1: 8719018014658
EAN3: 8719018014665

Packed product information

Cable length: 100cm USB cable, 5V 1A adaptor
Height: 15 cm
Length: 6.5 cm
Pack Quantity / MOQ: 6
Weight with batteries: 324 g

Product description

Hands free options: Rotatable hook, strong magnet
Hook: 360° rotatable
Impact protection rating (IK): IK07
Ingress protection rating (IP): IP65
Magnet: 1 magnet
Materials & finishing: Robust ABS + Soft rubber
Operating Temperature: -10°C to 40°C
Resistant to: Grease, oil, workshop solvents
Technology: COB LED
UV leak detector: No
Range: Xperion 6000

