



Philips Ultinon Pro6000 SI  
Car signalling bulb

LED-WHITE [~W21W]

Number of bulbs: 2  
12 V, 6000 K Cool White  
Advanced automotive system

11065CU60X2

# Enjoy lasting brightness

Brighter, elegant signals

For a stylish drive, upgrade to Philips Ultinon Pro6000 LED-WHITE [~W21W] reverse, rear fog and stop lights. Their cool white colour looks great and increases visibility so you can signal safely and stylishly.

#### High-end, stylish signalling

- Upgrade your lights, upgrade your style

#### Simple plug-and-play replacement

- Easy to install and compatible with most car models
- Electrical compatibility with most cars

#### Superior visibility

- Instant safety information for other drivers
- Signal your intent with brighter exterior lighting
- Ergonomic design with three-LED array

#### Performance made to last

- Enhanced lifetime of up to 5,000 hours

# PHILIPS

## Car signalling bulb

LED-WHITE [~W21W] Number of bulbs: 2, 12 V, 6000 K Cool White, Advanced automotive system

# Specifications

### Marketing specifications

- Product highlight: Automotive Grade LED, Powerful brightness, Uniform light distribution
- Expected benefits: Brighter, elegant signals

### Product description

- Application: Reverse, Rear fog, Stop
- Base: W3x16d
- Designation: W21W LED white 11065 CU60 12 V X 2
- ECE certification: NO
- Range: Ultinon Pro6000 SI
- Technology: LED
- Type: LED-WHITE [~W21W]
- Voltage: 12 V

### Lifetime

- Life time: 5000 hrs

### Light characteristics

- Lumens: 250
- Colour temperature: 6000 K

### Ordering information

- Order entry: 11065CU60X2
- Ordering code: 1554930

### Packaging Data

- EAN1: 8719018015549
- EAN3: 8719018015556
- Packaging type: X2

### Packed product information

- Gross weight per piece: 36 g
- Length: 14.2 cm
- Width: 12.1 cm
- Height: 10.3 cm
- Net weight per piece: 3 g
- Pack Quantity: 2 pcs
- MOQ (for professionals): 10 packs

### Outer pack information

- Length: 9.5 cm
- Width: 1.5 cm
- Height: 13.5 cm
- Net weight per piece: 360 g
- Gross weight per piece: 0.51 kg

11065CU60X2/10

# Highlights

### Powerful brightness

Signalling the intended movement of your vehicle is vital to your safety. To avoid collisions, other people need to know what you're doing. And when poor weather reduces visibility, the need for bright and vibrant signalling becomes even greater. Philips Ultinon Pro6000 LED signalling lights provide you with bright lighting for signals. Your car says a lot about you, so make a style statement with Philips LED signalling lights.

### Instant-on technology

Compared with incandescent lights, Philips Ultinon Pro6000 LEDs light up instantly to ensure that other drivers can react faster, keeping you safer.

### Uniform light distribution

For your reverse, rear fog and stop signals, Philips Ultinon Pro6000 LED gives you uniform light distribution. Its wide angle ensures that the light is projected where you need it.

### Elegant LED light

While the main goal of exterior lighting is to help you see and be seen, there's no reason why you shouldn't look good at the same time. If you're wanting to upgrade your style without buying a newer car, replacing your exterior lighting with Philips Ultinon Pro6000 LED signals is a smart way to spend your money.

### Lifetime of up to 5,000 hours

You want bright, stylish car lights but you don't want to keep replacing failed lamps. That's a major weakness of conventional bulbs - the more powerful the light, the shorter its lifespan. Even at a higher light intensity, LEDs last much longer. Philips Ultinon Pro6000 LED lights are built to last. Due to features such as high-end LED technology and advanced heat-management systems, they last for up to 5,000 hours of operation.

### Ready, steady, installed!

Enjoy the plug-and-play experience: with Philips Ultinon Pro6000, bulb replacement is quick and easy.

### Electrical compatibility

LED retrofit and conventional bulbs differ from one another in terms of wattage, composition and power consumption. Replacing your conventional bulbs with other LEDs may prove problematic. Philips Ultinon Pro6000 bulbs are electrically compatible with most cars. Additional adapters are available as accessories for troubleshooting, if needed. We sell a complete solution.



Issue date 2024-01-18

Version: 2.0.1

© 2024 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)

\* Non-ECE compliant