

PHILIPS

4 inch LED light bar

Ultinon Drive 5100

Road-legal ECE R149-12,5

1150 lm, 240 m beam length

Dual-color position light

All terrain, all weather



LUMUD5101LX1



Powerful brightness driving safety at the wheel Bright, durable gear for overland journeys

The Philips Ultinon Drive 5101L LED light bar has the power to keep you safer, wherever you're headed. Spot hazards up to 240 meters away with lighting that performs in the most hostile environments and gives your vehicle a touch of style.

Brilliance that makes you a safer driver

- Intense, far and wide illumination for superior visibility

Dual-color position lights that get you noticed

- Choose your position-light color

Designed to handle hostile environments

- Corrosion-free body, stainless-steel mounting brackets
- IP68 & IP69K-rated to master the elements

Road-legal auxiliary lights

- Powerful road-legal LED lightbars

Easy to install with flexible mounting options

- Low-profile design for simpler fitment

Highlights

Up to 240 -meter visibility

The Philips Ultinon Drive 5101L LED light bar provides a brilliant light beam that illuminates the road ahead for up to 240 meters*. Its effective 1150 lumens are homogeneously distributed in an optimized indirect beam, generating intense illumination far and wide with reduced glare for everyday use. This enables drivers to react faster on dark, rural and dirt roads. Its cool light color of 6500 Kelvin produces daylight conditions, improving contrast and helping drivers stay focused.

Brilliant-white or -amber LED

Never go unnoticed on side roads or in parking areas with the extra LED position lights of our Philips Ultinon Drive 5101L. Express your style and personality by choosing your light color, either intense amber or cool white.

Waterproof for durable light

With its ingenious screwless design, the Philips Ultinon Drive 5101L LED light bar can withstand the wettest conditions. Its IP69K certification means it will perform, wherever your road leads and whatever the weather. And it will be more than a match for any power washer you use to clean your car afterwards.

Corrosion-free

With its anodised pre-treated and automotive-grade powder-top-coat body, the Philips Ultinon Drive 5101L LED light bar

offers ultimate corrosion protection. Its mounting brackets are made of stainless steel, which is corrosion-free. It can withstand snow, ice and even salt. Built from durable, high-quality materials, your Philips auxiliary LED lights will provide years of reliable service.

Road-legal lights

The Philips Ultinon Drive 5101L LED light bar meets ECE standards and is 100% road-legal for high-beam and position-light functions. For added safety, Philips LED light bars are tested to EMC R10 specification to ensure they will function smoothly with your vehicle's electrical systems. The Philips Ultinon Drive 5101L LED light bar meets ECE standards and is 100% road-legal for high-beam and position-light functions. For added safety, Philips LED light bars are tested to EMC R10 specification to ensure they will function smoothly with your vehicle's electrical systems.

Easy and flexible installation

The sleek, low-profile design makes installation easier, and flexible fitment options are possible with side-mounting brackets (included) and back-mounting brackets (UD1001M optional). Supplied with a pre-wired male/female 3-pin superseal DT connector, it is voltage-overload and reverse-polarity protected to make installation secure and easy.

Specifications

Electrical characteristics

Voltage: 9-30 Volt DC

Product description

Accessories (optional): LUMUD1001M, LUMUD1003W, LUMUD1004W
Boost function installation: No
Boost mode activation: No
Break resistance
corrosion-free brackets: U shape mounting bracket
ECE R10
ECE R148
ECE R149
ECE reference number: 12.5
Impact protection rating (IK): IK07
Ingress protection rating (IP): IP68 & IP69K
Installation angle: 360°
Material: Aluminum extruded
Offroad boost: No
One-piece body design
Operating temperature: -40° C to 80° C
Parking position light: Yes, white or amber
Range: Ultinon Drive 51000
Plug type: 4-pin DT Connector with 0.5m cable
Scratch resistant lens
Technology: LED
Width: 150 mm / 4 inch

Light characteristics

Beam length 1 lux-m: 240
Color temperature: 6500 K K
Effective lumen output: 1150 lumens
Raw lumen output: 4950 lumens

Packed product information

Box dimensions-L(mm): 350
Box dimensions-W(mm): 90
Box dimensions-H(mm): 90
MOQ (for professionals): 8
Number of product in the box: 1 lamp

Ordering information

GOC: 01842750
Order entry: UD5101LX1

Packaging Data

EAN1: 8719018018427
EAN3: 8719018018434

Outerpack information

Height: 200 cm
Length: 370 cm
Width: 200 cm

