

PHILIPS



Pillar

Xperion 6000

500 lm Boost / 250 lm Eco

180 lm Spotlight

Battery life: 4.5 h (Eco: 10 h)

Ergonomic and foldable



X60PILLX1

Designed with you in mind

Advanced lighting performance that lasts

The Philips Xperion 6000 Pillar lasts all day on a single charge. Its bright 250 and 500 lm main light and inbuilt 180 lm torch will meet multiple needs. Foldable for easy carrying and adjustable lighting angles.

Accessories available to upgrade your work lamp

- Smart solutions for charging and finding your device

Extended warranty

- Extend your warranty online to 3 years

Handles tough conditions easily

- Resistant to impacts, water and solvents (IP65/IK07)

Smart, ergonomic design

- Smart rotatable hook with magnet and ergonomic body

See where others can't

- Long running time in different light modes
- Premium LED light with multiple outputs

Highlights

Multiple light modes



Featuring high-quality and bright LED light, the Philips Xperion 6000 Pillar displays objects faithfully and vibrantly via a high-luminosity, wide-beam main source producing 250 lm in Eco and 500 lm in Boost mode. Use the strong spotlight with a 180 lm torch beam to see better and spot the smallest details.

Light modes for multiple needs



The Philips Xperion 6000 Pillar is designed to be ready for action. A single charge provides enough energy for a full day's work: up to 10 hours in Eco mode, 4.5 hours in Boost mode, and 12 hours with the torch beam. Powered by a powerful Li-ion battery, the Philips Xperion 6000 Pillar can be fully charged within 4.5 hours via USB-C, ensuring maximum usage of its bright LED light.

Enables hands-free working



Designed with you in mind, the ergonomically shaped handle with an anti-slip coating allows you to hold this work light securely. If you need both hands free for work, position the light securely thanks to the 360° rotatable, retractable hook and a strong magnet. The power button is located on the back to ensure that the light does not glare directly at your eyes when you turn it on.

Designed for resistance



Designed to handle tough work environments with IK07 shock resistance, water-resistant to IP65 standards, and a surface to withstand chemicals and workshop solvents, the Philips Xperion 6000 Pillar is built to last because we know that even the steadiest hands need the extra support.

Up to 3 years' warranty



Benefit from the Philips standard 2 year warranty plus 1 additional year¹

Upgrade your work light



Don't worry about losing your device any more. You can find it easily with the "Find My Device" function. Use the remote control to trigger an audible buzzer and flashing light to locate your device. The vibrant lime-green body will help you spot your device even in dark settings. To keep your work light to hand and ready to use, try the Philips Dock station. Placed on a table, it provides cordless charging for your lamp.² Find out more: [Philips.com/Xperion-6000](https://philips.com/Xperion-6000)

Specifications

Marketing specifications

Product highlight: Ergonomic and foldable

Expected benefits: Designed with you in mind

Product description

Hands-free options: Rotatable hook, strong magnet

Hook: 360° rotatable

Impact protection rating (IK): IK07

Magnet: 2 magnets

Materials and finishing: Robust ABS + Soft rubber

Operating Temperature: -10°C to 40°C

Range: Xperion 6000

Technology: COB LED

UV leak detector: No

Ingress protection rating (IP): IP65

Resistant to: Grease, oil, workshop solvents

Light characteristics

Beam angle: 100° degree

Colour temperature: 6000 K

Light output (pointer): 180 lumens

Light output (eco): 250 lumens

Beam angle (pointer): 15°

Light output (boost): 500 lumens

Electrical characteristics

Voltage: 3.7 V

Power source: Rechargeable battery

Battery capacity: 4400 mAh

Battery run time (boost): Up to 4.5 hours

Battery run time (eco): Up to 10 hours

Battery type: Lithium battery

Plug type: EU plug (not included for UK)

Charging cable type: Type C USB

Battery charging time: Up to 4.5 hours

Wattage: 5 W

Battery run time (pointer): Up to 12 hours

Ordering information

Order entry: X60PILLX1

Ordering code: 01469631

Packaging Data

EAN1: 8719018014696

EAN3: 8719018014702

Packed product information

Length: 5.2 cm

Height: 23 cm

Pack Quantity / MOQ: 6

Weight with batteries: 412 g

Cable length: 100 cm USB cable, 5 V 1 A adapter

Outer pack information

Length: 25 cm

Width: 17 cm

Height: 18 cm

