



Philips MasterDuty  
24 V headlight bulb

Type of lamp: H3

Pack of: 1  
24 V, 70 W  
More light

13336MDC1

## Built to last

### Maximum vibration resistance

The Philips MasterDuty headlight bulbs are designed for maximum vibration resistance and excellent lifetime. They provide more light. Philips MasterDuty is the right choice for drivers seeking toughness that lasts.

#### **Good visibility**

- See further and react faster with more light

#### **Philips automotive quality**

- Philips is the choice of major car manufacturers

#### **Enhanced lifetime**

- A lifetime of safety so you can see and be seen

#### **Durable lights with vibration resistance**

- Durable lights with increased resistance to vibration
- Among the safest road-legal headlights

# PHILIPS

24 V headlight bulb  
Type of lamp: H3 Pack of: 1, 24 V, 70 W, More light

77460660

# Specifications

## Marketing specifications

- Expected benefits: Long lasting
- Product highlight: Maximum vibration resistance

## Product description

- Application: fog beam, High beam, Low beam
- Base: PK22s
- Designation: 13336MDC1
- ECE certification
- Range: MasterDuty
- Technology: Halogen
- Type: H3

## Lifetime

- Life time: 450 hrs

## Light characteristics

- Colour temperature: 3200 K K

## Electrical characteristics

- Wattage: 70 W
- Voltage: 3200 K V

## Ordering information

- Order entry: 13336MDC1
- Ordering code: 77460660

## Packaging Data

- Packaging type: C1
- EAN1: 8711500774606
- EAN3: 8711500774637

## Packed product information

- Gross weight per piece: 0.099 g
- Length: 2.5 cm
- Width: 2.5 cm
- Height: 8.5 cm
- Net weight per piece: 0.064 g
- Pack Quantity / MOQ: 1
- MOQ (for professionals): 100

## Outer pack information

- Length: 26.6 cm
- Width: 13.8 cm
- Height: 18.7 cm
- Gross weight per piece: 1.2 kg

# Highlights

## Maximum vibration resistance

Philips MasterDuty features increased mount and base stiffness for ultimate protection against mechanical shock as well as a robust double-coil filament designed to withstand severe vibration while remaining stable. Philips MasterDuty provides drivers with an increased lifetime of up to 500 hours.

## Good visibility

Perfect illumination is especially important in the distance – usually between 75 and 100 metres in front of your vehicle. Philips MasterDuty boosts your visibility with more light on the road. This helps you recognise obstacles and any potential dangers earlier than with most other halogen headlight lamps.

## Enhanced lifetime

Every potential failure of a spare part is a risk for you and your vehicle. This is especially true for headlights. Every broken headlight lamp reduces visibility and safety for you and the oncoming traffic. Philips MasterDuty is optimised for a long and reliable lifetime. You can see and be seen for longer than with any other high-performance lamp.

## Safe road-legal headlights

Philips MasterDuty is among the safest, easiest and most efficient way to upgrade your lorry or bus headlights within legal parameters. The lights are fully ECE certified.

## Highest quality car lighting

Technologically advanced Philips lighting is renowned in the automotive industry and has been for over 100 years. The Philips Original Equipment Quality products are designed and developed following strict quality control processes (including applicable ISO norms), leading to consistently high production standards. Philips MasterDuty is compatible with truck and bus models of major brands.



Issue date 2024-01-18

Version: 2.0.1

© 2024 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)