

PHILIPS

Car driving video recorder

ADR810

Full-HD 1080p

Automatic collision detection

Fatigue index and driver alert

Emergency Easy Capture



ADR81BLX1



Your personal road safety guardian

with collision detection & emergency Easy Capture

Enjoy peace of mind while driving, Philips automotive driving recorder will protect you in case the unexpected happens. Feel guarded thanks to automated safety functions; Collision Detection, Emergency EasyCapture, and Fatigue Alert.

Crystal clear images in all driving conditions

- Vivid details with 1080p Full HD definition
- Perfect night view
- 156° degree wide angle lens

Hassle free & reliable with emergency support

- Automatic recording when you start your vehicle
- Collision detection and automatic emergency recording
- Emergency EasyCapture, to always catch the unexpected
- Fatigue index and driver alert

Impartial evidence anytime

- Original equipment quality
- Instant replay with proof stamped evidence

Highlights

Automatic recording



Automatic recording

As soon as you power on your vehicle, the driving recorder starts operating automatically.

Collision detection



Collision detection

In case of a collision, an emergency recording is automatically saved to secure the evidence and prevent overwriting.

Fatigue index



Fatigue index

The fatigue index shows the evolution of a driver's fatigue, and will indicate a visual and acoustic warning message when the driver should be taking a rest.

Full HD



Full HD

Capture vivid details with 1080p Full HD definition

Proof stamp



Instant replay to clarify responsibility on the spot, with proof stamped evidence, to support & speed up insurance claim process

Emergency Easy Capture



Emergency EasyCaptur

Philips EasyCapture ensures fast and easy emergency recording buttons at hand. Capture and save everything that happens on the road when you need it: one button clearly identified on the device, and one on the cigarette lighter adaptor.

Night view



Night visibility

Capture sharpest details, day and night. With optimized Night View.

OE quality



Philips brought its worldwide automotive expertise to provide the best in-car performance and a long-lasting quality. High vibration and temperature resistance CE/FCC certified for safe installation and use. Sturdy mounting with easy fitting and adjustment.

View angle



Wide angle 156°

Capture more of the scene with a proven 156° degree super wide angle

Specifications

Product description

Designation: ADR810
Technology: Automotive Driving Recorder
Languages: English, Chinese, Japanese
Interface: Mini USB 2.0, HDMI, Speaker
Operating Temperature: -10 ~ 65 °C
Storage Temperature: -20 ~ 70 °C
File Format: .MOV, H.264 video compression
Fixed Lens: 156° super wide angle lens
Internal Memory: 64Mb SPI Flash
Random Access Memory: 64Mx16bit (1Gbits)
DDR2 SDRAM
Recording Time: 160min @16GB for full HD
Display: 2.7" LCD
G-sensor
Auto exposure
Auto white balance
Improved night visibility
LCD Auto Off
Seamless loop recording

Automatic recording
Aperture Range: F/#2.0
Collision detection
Date and time stamp
Image Sensor: 2.1 Mega-pixels CMOS
Video resolution: Full
HD(1920x1080p) @30fps
Emergency file protection
Recording media (ext. Memory): Micro SD
card (up to 32GB)

Packaging Data

EAN1: 6947939173983
EAN3: 6947939173990

Accessories included

Accessories: 12V cable, mounting bracket
Power cable length: 4 m
Power: 12 V car adapter

Weight and dimensions

Product dimensions (L x W x H): 106.7 x 50.0 x
32.5 mm
Product weight: 83 g
Box weight (incl. product): 370 g

Marketing specifications

Expected benefits: Your road safety guardian
Product highlight: with emergency Easy
Capture

Logistic data

EAN (China): 6947939172160
Ordering code (China): 17216030
Quantity in box: 1
Reference: ADR81BLX1

