



Philips WhiteVision ultra
moto
Motorcycle headlights

HS1
Pack of: 1
12 V, 35/35 W
Irresistible white style

12636WVUBW

Sharp irresistible look

Sharp white look

The Philips WhiteVision ultra moto halogen headlamp upgrades the style of your motorcycle with a bright white light.

Enhanced safety

- Our whitest bulbs for stylish performance on the road
- High-quality quartz glass for enhanced safety

Road-legal performance

- Stunning white road-legal headlights for a stylish look
- Respecting the high quality standards of ECE homologation

Sharp irresistible look

- Bright white light for a stylish xenon look

Philips quality

- Philips is the choice of major car manufacturers

PHILIPS

Specifications

Marketing specifications

- Product highlight: Irresistible white style
- Expected Benefits: Style

Product description

- Application: High beam, Low beam
- Base: PX43t-38
- Designation: HS1 12636 WVU 12 V 35/35 W PX43t-38 BW
- ECE certification
- Range: WhiteVision ultra
- Technology: Halogen
- Type: HS1

Lifetime

- Life time: 400h

Light characteristics

- Lumens: 600 \pm 10% / 400 \pm 10%
- Colour temperature: 3600 K

Electrical characteristics

- Wattage: 55 W
- Rated voltage: 12 V

Ordering information

- Order entry: 12636WVUBW
- Ordering code: 2401530

Packaging Data

- Packing: Blister
- EAN1: 8719018024015
- EAN3: 8719018024022
- Packaging type: BW
- Quantity in box: 1

Packed product information

- Gross weight per piece: 22,5 g
- Length: 9.5 cm
- Width: 4.8 cm
- Height: 12.9 cm
- Pack Quantity: 1 pc
- MOQ (for professionals): 10 pcs

Outer pack information

- Length: 26.1 cm
- Width: 19.6 cm
- Height: 14.0 cm
- Gross weight per piece: 0,497 kg

Highlights

Sharp light for a stylish look

Philips WhiteVision ultra moto is a unique halogen lamp that offers a bright white light. High-tech and efficient to differentiate and personalise your motorcycle, with better visibility and comfort.

Stunning road-legal headlights

Philips WhiteVision ultra moto upgrade headlight bulbs are ECE certified for bright white light on the road. Drivers enjoy a vibrant look and a street-legal bulb compliant with relevant regulations. Without compromising safety by dazzling oncoming drivers, it gives you great visibility.

High-quality manufacturing

Philips automotive products and services are considered best-in-class in the Original Equipment Manufacturer market and the aftermarket. Manufactured from high-quality materials and tested to the highest specifications, our products are designed to maximise the safety and comfort of our customers' driving experience. Our entire product range is thoroughly tested, controlled and certified (ISO 9001, ISO 14001 and QSO 9000) to the highest ECE requirements. Put simply, this is quality you can trust.

Engineered for stylish vision

Better and brighter lights allow for increased performance on the road. With their optimised high-precision filament geometry, high-pressure gas filling, high-precision coating and high-quality UV-Quartz glass, Philips WhiteVision ultra moto headlight bulbs set a new standard for road-legal white light. Engineered for great style and visibility, these bulbs provide a more relaxed and fun driving experience.

High-quality quartz glass

Quartz glass is stronger than hard glass and highly resistant to temperature extremes and vibrations, which eliminates the risk of explosion. So Philips quartz-glass lamps (filament at 2 800°C and glass up to 800°C) are able to withstand severe thermal shocks. With the capability of increased pressure inside the lamp, quartz glass is able to produce a more powerful light. And more powerful light means an enhanced driving experience, however dark the road in front of you. All Philips quartz-glass lamps also offer a UV shield to protect your modern plastic optics from harmful UV rays.

Highest quality car lighting

Technologically advanced Philips lighting is renowned in the automotive industry, and has been for over 100 years. The Philips Original Equipment Quality products are designed and developed following strict quality control processes (including applicable ISO norms), leading to consistently high production standards. Philips WhiteVision ultra moto is compatible with motorcycle models of major brands.



Issue date 2024-01-18

Version: 1.0.1

© 2024 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com