



Philips Ultinon Drive  
5014L  
30 Inch Single Row LED  
Lightbar

**Sturdy one-piece body**

IP69K waterproof  
Corrosion-free stainless steel  
Trouble-free operation



LUMUD5014LX1

## Brilliant LED lighting for off-road adventures

Built for where you want to go

For drivers who demand the maximum of themselves and their machines, we offer Philips Ultinon Drive 5000 series LED lightbars. Exceptionally rugged, with unsurpassed illumination and beam focus, that can light the way.

**Off-road auxiliary lights**

- Trouble-free operation

**Powerful brightness, Rugged performance**

- Bright, long beam for superior visibility

**Durable equipment for challenging conditions**

- Corrosion-free, stainless-steel mounting brackets
- IP69K waterproof to master the elements
- Sturdy one-piece body for tough environments

# PHILIPS

30 Inch Single Row LED Lightbar  
Sturdy one-piece body IP69K waterproof, Corrosion-free stainless steel, Trouble-free operation

LUMUD5014LX1/50

# Specifications

## Product description

- Impact protection rating (IK): IK07
- Ingress protection rating (IP): IP68 & IP69K
- One-piece body design
- Operating Temperature: -40° F to 176° F
- Range: Ultinon Drive 5000
- Scratch resistant lens
- Technology: LED
- Accessories (optional): additional wiring kit
- corrosion-free brackets: yes, included
- Heat sink: 13-piece 1.5 in
- Material: Aluminum die-cast

## Light characteristics

- Color temperature: 6500 K
- Effective lumen output: 7000 lumens

## Electrical characteristics

- Voltage: 9-30 Volt DC

## Ordering information

- Order entry: UD5014LX1
- GOC: 78002620

## Packaging Data

- EAN1: 46678002625
- EAN3: 50046678002620

# Highlights

## Superior visibility

The Philips Ultinon Drive 5000 series provides outstanding beam performance with brilliant illumination that extends up to 423 yards. With high lumen output coming from the powerful LEDs, the Ultinon Drive series provides ample visibility for faster reactions. Cool light color of 6500 Kelvin keep you focused without straining your eyes.

## Sturdy one-piece body

Philips Ultinon Drive 5000 series lightbars are built with single-piece assemblies to withstand the toughest conditions. This also allows for excellent heat management and consistently high light output throughout your journey. Ultinon Drive 5000 series has an impact protection rating of IK07, to ensure it can withstand the hazards of aggressive offroading. Rugged polycarbonate lenses resist damage and scratches and the convenient DT connector guarantees a perfect connection.

## Waterproof for durable light

With its ingenious screwless design, the Ultinon Drive 5000 series is rated IP68 and IP69K against dust, high temperature, and high pressure water. These lights will perform, wherever your road leads and whatever the weather. And they will be more than a match for any powerwasher you use to clean your ride after your adventures.

## Corrosion-free brackets

Ultinon Drive 5000 series mounting brackets are made of highly corrosion resistant stainless steel. Built to withstand years of exposure in snow, ice, and salt air environments, these brackets and the entire lightbar will provide years of reliable service.

## Trouble-free

Philips Ultinon Drive 5000 series lightbars are designed and tested to ensure they will function smoothly with your vehicle's electrical systems. They will not create electrical interference that might interfere with other vehicle functions.



Issue date 2024-02-03

Version: 1.0.3

© 2024 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)