

PHILIPS

 Product Picture

Under-Bonnet Light

Xperion 6000

High lumen output

1,200 lm and 110° beam radius

Presence sensor

Extension up to 2.08 meters

LUMX60BONNX1

Designed with you in mind

Extendable, powerful LED under-bonnet lamp

The Philips Xperion 6000 Under-Bonnet LED Light offers a seamlessly dimmable beam of up to 1,200 lumens, 360° rotatability, and a telescopic mount extending up to 2.08 meters on both sides, ideal for working on cars, vans, and trucks.

Powerful, bright LED light

- Seamless light dimming

Enhanced versatility

- Telescopic, extendable mount
- Sliding light module

Long lasting performance

- Presence sensor to save battery life
- Long-life battery

Enhanced durability

- Robust, and water dust protected

Extended warranty

- Extend your warranty online to 3 years

Highlights

Powerful bright LED light

The Philips Xperion 6000 Under bonnet LED light offers a powerful 1,200 lumens of light, helping you spot even the smallest of details. Tune the light intensity as you wish with a rotatable knob, to adjust to your environment or preserve battery life.

Telescopic, extendable mount

The Philips Xperion 6000 Under-Bonnet LED Light is equipped with two integrated telescopic hooks extendable on both sides and rotatable through 360°. The hooks feature wider openings and are covered with soft rubber for easy attachment to the vehicle bonnet without scratching the paintwork. With a mount stretching from 1.10 to 2.08 meters, our Philips Xperion 6000 Under-Bonnet LED lamp can be used in a wide range of locations. Whether under the bonnet, roof, or rear hatch of any car, van, or truck, this lamp has the flexibility you need.

Sliding light module

Thanks to the Philips Xperion 6000 Under-Bonnet LED Light's unique design, you can slide the light module along the mount to the area you want to illuminate. No need to change the lamp angle when repositioning the module.

Presence sensor

The Philips Xperion 6000 Under-Bonnet LED Light is equipped with a presence sensor that senses human activity within a 2,5-meter

radius. This enables the lamp to switch off automatically after 5 minutes when unused. It switches on again when a presence is detected, saving battery life and giving you hands-free control.

Enhanced durability

Complying with international impact-resistance standard IK07, the robust aluminum housing of the Philips under bonnet LED light is designed to withstand tough working environments. It is IP54-rated for splash and dust resistance. Built to strict manufacturing standards with multiple sealing processes, our lamp is resistant to splashed water and protected from dust.

Up to 3-year warranty

Benefit from Philips standard 2-year warranty plus 1 additional year.*

Long-life battery

The 5200 mAh long-life battery of the Philips Xperion 6000 Under-Bonnet LED Light provides you with three hours of continuous use in Boost mode, and up to 20 hours in Eco mode. See when the battery needs charging. It features a battery-status indicator that shows how much battery life is left. Never run out of power in the middle of a job again. The indicator also displays the time remaining until the battery is fully charged.

Specifications

Electrical characteristics

Battery capacity: 5200 mAh

Battery charging time: Up to 3.5 hours

Battery run time (boost): Up to 3 hours

Battery run time (eco): Up to 20 hours

Battery type: Lithium battery

Charging cable type: Type C USB

Plug type: 5V 2A adaptor (except UK)

Voltage: 3.7 V

Wattage: 1,2 W

Power source: Rechargeable battery

Light characteristics

Beam angle: 110 degree

Color temperature: 5800 K

Light output (boost): 1200 lumens

Light output (eco): 120 lumens

Marketing specifications

Expected benefits: Designed with you in mind

Product highlight: 2.08 m extendable for all vehicles

Ordering information

Order entry: X60BONNX1

Ordering code: 02171731

Packaging Data

EAN1: 8719018021717

EAN3: 8719018021724

Packed product information

Cable length: USB type-C 100cm cable, 5V 2A adaptor

Height: 60 cm

Length: 1160 cm

Pack Quantity / MOQ: 6

Weight with batteries: 960 g

Width: 118 cm

Product description

Hands free options: Presence sensor

Hook: Rotatable, 2 sides extendable

Impact protection rating (IK): IK07

Ingress protection rating (IP): IP65

Magnet: No

Materials & finishing: Aluminum

Number of LEDs: 32

Operating Temperature: -10°C to 40°C

Range: Xperion 6000

Resistant to: Grease, oil, workshop solvents

Technology: LED

