

# PHILIPS

## 7" round

### LED Headlamp

#### LED01X1

#### Dual beam system

#### DOT compliant



LED01X1



## 50x Longer life

First to market with street-legal exterior LEDs

Philips LED Headlamps feature our advanced LUXEON Altilon LEDs. This innovative technology delivers powerful, precise illumination and bright white 5600 K light output that's closer to the color temperature of daylight.

#### **Brighter, whiter light output**

- High-Power Luxeon® Altilon LEDs

#### **Extremely impact resistant**

- Military-grade die-cast aluminium housing

#### **Dual beam system**

- Split-lamp with a low beam and high beam

# Highlights

## Brighter, whiter light output

Philips LED Headlamps feature our advanced LUXEON Altilon LEDs. This innovative technology delivers powerful, precise illumination and bright white 5600 K light output that's closer to the color temperature of daylight, while dramatically improving overall nighttime visibility.

## Dual beam system

The split-lamp low beam and high beam offers a unique look, when on and off. In addition, the complex reflector design optimizes and evenly distributes for the best visibility and pattern.

## Extremely impact resistant

Unlike your traditional headlamp, the Philips LED Headlamp is bulb-free and electronics are encapsulated in hardened epoxy to resist damage caused by shock and vibration. The LED Headlamp features a military-grade die cast aluminium housing and an impact-resistant polycarbonate lens. The 'split-lamp' appearance offers a unique look when on and off, and their ultra-rugged construction make these LED headlamps ready for tough conditions - on road or off.

# Specifications

## Technical specifications

**Voltage:** 12 V

## Product description

**Application:** Headlight

**Designation:** Philips LED Headlamp

**Range:** LED Headlamp

**Type:** 7" round

**Color temperature:** 5600

**Light source:** 2 LED Arrays

**Replaces:** 6014, 6015, 6016, H6024

## Marketing specifications

**Expected benefits:** High-Performance LEDs

**Product highlight:** 12 year-lifespan, 5x time more light, road legal LED

