



Philips WhiteVision ultra
moto
Motorcycle headlights

H7

Pack of: 1
12V, 55W
Irresistible white style

12972WVUBW

Sharp irresistible look

Sharp white look

The Philips WhiteVision ultra moto H7, featuring the latest coating formula, delivers stunning 4200 Kelvin. These are the whitest road-legal halogen lights in our portfolio and the perfect choice if you're looking for a cool, stylish look.

Stylish white look with up to 4200 Kelvin

- Up to 4200 Kelvin sharp white light
- Halogen upgrade headlights that offer a highly stylish look

Comfort with up to 60% more vision

- Up to 60% more vision to maximise clarity
- White light to enhance visibility and comfort

Enhanced safety

- Our whitest bulbs for stylish performance on the road

Road-legal performance

- Stunning white road-legal headlights for a stylish look

Philips quality

- Philips is the choice of major car manufacturers

PHILIPS

Motorcycle headlights
H7 Pack of: 1, 12V, 55W, Irresistible white style

Specifications

Marketing specifications

- Product highlight: Irresistible white style
- Expected Benefits: Style

Product description

- Application: High beam, Low beam
- Base: PX26d
- Designation: H7 12972 WVU 12 V 55 W BW
- ECE certification
- Range: WhiteVision ultra
- Technology: Halogen
- Type: H7

Lifetime

- Life time: 200 h

Light characteristics

- Lumens: 1500 ±10%
- Colour temperature: 4200 K

Electrical characteristics

- Wattage: 55 W
- Rated voltage: 12 V

Ordering information

- Order entry: 12972WVUBW
- Ordering code: 2387230

Packaging Data

- Packing: Blister
- EAN1: 8719018023872
- EAN3: 8719018023889
- Packaging type: BW
- Quantity in box: 1

Packed product information

- Gross weight per piece: 24,1 g
- Length: 9.5 cm
- Width: 3.5 cm
- Height: 12.9 cm
- Pack Quantity: 1 pc
- MOQ (for professionals): 10 pcs

Outer pack information

- Length: 19.6 cm
- Width: 19.6 cm
- Height: 14.0 cm
- Gross weight per piece: 0,332 kg

12972WVUBW/10

Highlights

4200 Kelvin sharp white light

With up to 4200 Kelvin, Philips WhiteVision ultra moto headlight bulbs revolutionise the look of your motorcycle with a sharp white light. The right choice for a bright and stylish driving experience!

Cool white effect

Philips WhiteVision ultra moto is designed for drivers who are looking for an upgrade with the style and appearance of LED lighting, but who drive a vehicle with halogen technology. Thanks to the advanced coating formula on the glass, Philips WhiteVision ultra moto bulbs are our whitest road-legal lights, providing a stunning look in the headlamp's reflector.

Stunning road-legal headlights

Philips WhiteVision ultra moto upgrade headlight bulbs are ECE certified for bright white light on the road. Drivers enjoy a vibrant look and a street-legal bulb compliant with relevant regulations. Without compromising safety by dazzling oncoming drivers, it gives you great visibility.

Comfort light for visibility

The Philips WhiteVision ultra moto coating formula, along with its cool white light, significantly improves visibility at night and enhances driver comfort by reducing eye fatigue. When design meets functionality, you enjoy a great look and enhanced driving comfort.

Up to 60% more vision

A longer beam pattern, with up to 60% more vision compared to the legal minimum standard, enables you to not only see other road users more clearly but also be better seen by them. It improves safety and gives you more time to react to potential hazards on the road ahead.

Engineered for stylish vision

Better and brighter lights allow for increased performance on the road. With their optimised high-precision filament geometry, high-pressure gas filling, high-precision coating and high-quality anti-UV quartz glass, Philips WhiteVision ultra moto headlight bulbs set a new standard for road-legal white light. Engineered for great style and visibility, these headlights provide a more relaxed and fun driving experience.

Highest quality car lighting

Technologically advanced Philips lighting is renowned in the automotive industry, and has been for over 100 years. The Philips Original Equipment Quality products are designed and developed following strict quality control processes (including applicable ISO norms), leading to consistently high production standards. Philips WhiteVision ultra moto is compatible with motorcycle models of major brands.



Issue date 2024-01-18

Version: 2.0.1

© 2024 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com