

# PHILIPS

Truck signalling bulb

Ultinon Pro6000 SI

LED-T10 [~W5W]

Number of bulbs: 2

24 V, 6000 K Cool White

Advanced automotive system

24961CU60X2



## Enjoy lasting brightness

### Brighter, elegant signals

For a stylish drive, upgrade to Philips Ultinon Pro6000 LED [~W5W] 24 V position lights. They are bright and elegant so you can signal safely and stylishly.

#### **Performance made to last**

- HeatShield ensures durable performance
- Enhanced lifetime of up to 5,000 hours

#### **Superior visibility**

- Signal your intent with brighter exterior lighting
- Ergonomic design with three-LED array

#### **Simple plug-and-play replacement**

- Electrical compatibility with most trucks
- Easy to install and compatible with most truck models

#### **High-end, stylish signalling**

- Upgrade your lights, upgrade your style

## Highlights

### Powerful brightness

Signalling the intended movement of your vehicle is vital to your safety. To avoid collisions, other people need to know what you're doing. And when poor weather reduces visibility, the need for bright and vibrant signalling becomes even greater. Philips Ultinon Pro6000 LED signalling lights provide you with a bright daylight effect plus up to 6000 K for positioning and interior lighting. Your truck says a lot about you, so make a style statement with Philips LED signalling lights.

### Uniform light distribution

Whether it's for parking lights, glove compartment or interior lighting, Philips Ultinon Pro6000 LED gives you uniform light distribution. Its wide angle ensures that the light is projected where you need it.

### Elegant LED light

While the main goal of exterior lighting is to help you see and be seen, there's no reason why you shouldn't look good at the same time. If you're wanting to upgrade your existing truck, replacing your exterior lighting with Philips Ultinon Pro6000 LED signals is a smart way to spend your money.

### Lifetime of up to 5,000 hours

You want bright, stylish truck lights but you don't want to keep replacing failed lamps. That's a major weakness of conventional bulbs - the

more powerful the light, the shorter its lifespan. Even at a higher light intensity, LEDs last much longer. Philips Ultinon Pro6000 LED lights are built to last. Due to features such as high-end LED technology and advanced heat-management systems, they last for up to 5,000 hours of operation.

### Good at handling heat

With HeatShield technology, Philips Ultinon Pro6000 T10 bulbs are resistant to high temperatures even when installed next to headlight bulbs. Made with a special composite material, they can endure any thermal challenge and still offer high performance.

### Ready, steady, installed!

Enjoy the plug-and-play experience: Philips Ultinon Pro6000 comes with standard caps and is polarity-free, so replacement is quick and easy.

### Electrical compatibility

LED retrofit and conventional bulbs differ from one another in terms of wattage, composition and power consumption. Replacing your conventional bulbs with other LEDs may prove problematic. Philips Ultinon Pro6000 bulbs are electrically compatible with most trucks. Additional adapters are available as accessories for troubleshooting, if needed. We sell a complete solution.

## Specifications

### Marketing specifications

**Product highlight:** Automotive Grade LED, Powerful brightness, HeatShield, Uniform light distribution

**Expected benefits:** Brighter, elegant signals

### Product description

**Application:** Front position, Interior, Number plate

**Base:** W 2.1 x D 9.5

**Designation:** W5W LED white 24961 CU60 24 V X 2

**ECE certification:** NO

**Range:** Ultinon Pro6000 SI

**Technology:** LED

**Type:** LED-T10 [~W5W]

**Voltage:** 24 V

### Lifetime

**Life time:** 5000 hrs

### Light characteristics

**Lumens:** 110

**Color temperature:** 6000 K

### Ordering information

**Order entry:** 24961CU60X2

**Ordering code:** 1520430

### Packaging Data

**EAN1:** 8719018015204

**EAN3:** 8719018015211

**Packaging type:** X2

### Packed product information

**Gross weight per piece:** 24 g

**Length:** 14.2 cm

**Width:** 12.1 cm

**Height:** 10.3 cm

**Net weight per piece:** 3 g

**Pack Quantity:** 2 pcs

**MOQ (for professionals):** 10 packs

### Outerpack information

**Length:** 9.5 cm

**Width:** 1.5 cm

**Height:** 13.5 cm

**Net weight per piece:** 240 g

**Gross weight per piece:** 0.37 kg

