

PHILIPS

RCH5 Rechargeable Compact Lamp

LED Inspection lamps

High Quality LED

110lm Boost/ 55lm Eco

New 180° flexible design

Ultra-slim and pocket-size

LPL32X1



See better, work better

Compact rechargeable LED work light

Philips ultra-slim rechargeable LED inspection lamp is a perfect tool for a quick inspection. 180° flexible high quality LED light eliminates all shadows. Its 360° rotating hook and strong magnet provides a hands-free working environment.

Superior bright light

- Defeat darkness with soft natural light
- Eco & Boost light modes: 110lm/55lm
- High quality 3 x SMD LED
- Wide beam angle: up to 120°

Versatile design

- 180° tilting lamp head for maximum flexibility
- 360° Adjustable & retractable hook
- Handy belt-clip for maximum flexibility
- Strong magnet on the flexible bottom part
- Pocket-size - height 120mm
- 13 mm ultra-slim LED lamp

Reliable battery technology

- Durable Li-Ion battery
- Full recharge in only 2,5 hours

Highlights

180° tilting lamp head



The LED Inspection lamp RCH5 has a flexible lamp head which tilts up to 180° to ensure that you spot even the smallest details.

360° rotating hook



The adjustable and retractable hook enables you to hang this professional work light, leaving both of your hands free for required work.

Defeat darkness

Philips professional work lights feature powerful LEDs for an intense white light and a bright wide beam to defeat darkness. Designed to optimize clarity and vision, the 6500 K white light also improves visual comfort for fatigue-free working.

Dual light mode: 110lm/55lm



The white LEDs provide 110lm of light output in a Boost mode, as well as 55lm of Eco mode light to ensure that you are not left in the dark when trying to spot even the smallest details.

Durable Li-Ion battery



Philips LED rechargeable lamp RCH5 is powered by high-energy Lithium-Ion battery, which has no memory effect and provides up to 300 charge cycles.

Fast charging



Philips compact LED lamp is designed to be at your disposal whenever required. Powered by high-energy Li-ion battery, LED inspection lamp RCH 5 is fully recharged in up to 2,5 hours, insuring maximum usage of the LED light.

Handy belt-clip

Belt-clip on the back of Philips RCH5 ensures your LED light is always at hand.

High autonomy



Boost mode - 2,5h Normal mode - 5h

High quality LED

Philips LED Inspection lamp RCH5 is designed with SMD LED technology, insuring low power consumption and bright long-lasting light.

Strong magnet



With the new strong magnet, you have the possibility to attach the tool to metal surfaces for hands-free maintenance.

Ultra-slim

Thanks to its 13mm ultra-slim design, LED inspection lamp RCH5 perfectly fits into the pocket and provides a comfortable hand grip.

Pocket-size

Pocket-size dimensions of the cordless LED work lamp ensure ultimate ergonomics of the tool.

Wide beam angle



The wide beam angle of up to 120° allows for a comprehensive illumination of the task, while delivering the right amount of light.

Specifications

Ordering information

Order entry: LPL32X1

Ordering code: 39386631

Electrical characteristics

Battery capacity: 1000 mAh

Battery charging time: 2.5 hrs

Battery run time: Up to 5 hours

Battery type: Li-ion

Charging cable type: USB

Plug type: EU

Power source: Rechargeable battery

Voltage: 100–240 V

Wattage: 1.5 W

Light characteristics

Beam angle: 120 degree

Color temperature: 6500 K

LED lifetime: Up to 50000 hrs

Light output: 110 lumen

Light output (Eco): 55 lumen

Outerpack information

Gross weight per piece: 1370 g

Height: 18.5 cm

Length: 16 cm

Width: 14 cm

Packaging Data

EAN1: 8727900393866

EAN3: 8727900393873

Packed product information

Height: 5.9 cm

Length: 2.5 cm

Pack Quantity / MOQ: 6

Weight with batteries: 164 g

Width: 12 cm

Size: Compact

Product description

Hook: 360° retractable hook

Ingress protection rating (IP): IP20

Magnet

Materials & finishing: Electrical characteristics

Number of LED's: 3

Operating Temperature: -10 to 50 °C

Orientable light: 180° pivotable base

Technology: LED

Range: RCH

