



Philips X-tremeUltinon  
LED  
car fog light bulb

LED-FOG [~H8/H11/H16]  
6500K  
Up to 200% brighter light  
Advanced automotive system



12794UNIX2

## Brighter. Whiter. Stronger.

Bright white LED fog lights for high-end look

Philips X-tremeUltinon LED fog lights feature premium LUXEON LEDs with up to 6500 Kelvin. Our patented SafeBeam technology projects up to 200% brighter light exactly where you need it. Built to last with advanced AirFlux design.

### Upgrade your style

- Up to 6500 K for a crisp white light
- Upgrade your lights, upgrade your style
- Powerful bright light for superior visibility

### Superior light diffusion

- Powerful bright light, directed exactly where you need it

### Longer lasting LED fog lights

- Durable headlights that can last as long as your car
- Innovative heat management systems for more lifetime

### Exceptional Philips quality

- Philips automotive lighting at the highest quality level
- Easy installation and compatible with many car models

### Brighter whiter LED fog lights for cars

- Get up to 200% brighter light for superior visibility

# PHILIPS

car fog light bulb  
LED-FOG [~H8/H11/H16] 6500K, Up to 200% brighter light, Advanced automotive system

12794UNIX2

# Highlights

## Pure bright white light



With a color temperature of up to 6500 Kelvin, the Philips X-tremeUltinon LED fog lights based on automotive grade LUXEON technology produces a bright white, daylight-like beam. With clearer vision you're better able to spot obstacles and take the perfect driving line. And as you don't have to strain to see the terrain ahead, brighter lights make for a more comfortable and exciting night-time drive.

## Stylish white light upgrade

Just like our eyes are windows into our souls, so your headlights say a lot about your car. If you're looking to upgrade your style, without buying a newer car, upgrading your headlights is one of the smartest ways to spend your money. Your car is an expression of who you are, so make a style statement with Philips LED fog lights. Instead of yellow, you'll get a crisp, white and modern light. For that high-end look, smart drivers choose the superior style of Philips LED fog lights.

## Bright light where you need it



The best car lights are not simply the ones that produce the strongest light. Creating ever brighter LED bulbs for cars is the easier task. It's what you do with that extra light that

matters. Uncontrolled bright light is not ideal for driving and can create dangerous glare. Fitted with SafeBeam technology, Philips LED fog lights concentrate light where you need it. The uniform and accurate beam pattern is designed according to road safety regulations for halogen headlights. With more precise control of light, you have greater visibility, making you a better and safer night-time driver.

## Enjoy a lifetime of light

You want bright and stylish fog lights. But you don't want to keep replacing failed lamps. That's a major weakness of conventional headlights; the more powerful the light, the shorter its lifespan. At a higher light intensity level, LEDs last much longer, and Philips X-tremeUltinon LED products show superior durability. Due to features such as AirFlux and AirCool heat management systems, they last up to 12 years. With most cars replaced or upgraded within that time, your stylish new headlights should last you the lifetime of your car.

## Longer-lasting car light lamps

LED fog lights generate heat that needs controlling. Philips AirFlux and AirCool technologies is a smart cooling system that diverts heat away from the light's critical components. By increasing heat resistance, Philips LED fog lights last longer than other comparable products currently on the market. But durable lights are not just about convenience and value for money, they're also about safety. You don't want your lights to fail while in use. With Philips LED lights you can drive in total serenity.

## Automotive grade quality

The technologically advanced Philips lighting is renowned in the automotive industry, and has been for over 100 years. The Philips Automotive Grade Quality products are designed and developed following strict quality control processes (including applicable ISO norms), leading to consistently high production standards. Major car manufacturers choose Philips lamps, because when you buy Philips, you buy quality. You get powerful bright light,

and precise beam performance. You get high-end style. And you get an advanced LED lighting system for a safer, smoother and more enjoyable drive.

## Ready, steady, installed!

Designed to be easily installed in compatible vehicles, drivers with maintenance experience will be able to upgrade compatible headlights with ease. However, it's recommended that you get your new Philips LED headlights installed by specialist mechanics – they will make sure you're ready to go. While these headlights are compatible with a wide range of existing car models, not all car types are supported.

## Vivid bright light



Driving in the dark is demanding, so you rely on your headlights. Forward and peripheral vision are both important to enhance your driving ability for a safer drive. With an intense bright beam, Philips X-tremeUltinon LED fog lights for cars improve your visibility by up to 200%. Once you experience this daylight-like effect, you'll always prefer LED. The more you can see, the better you perform, the faster you react and the safer you are. So don't let darkness win, choose Philips and start driving at night with greater confidence and control.

# Specifications

## Marketing specifications

- Expected benefits: Advanced automotive system
- Product highlight: Brighter, Stronger, Whiter

## Product description

- Application: Front fog
- Base: PGJ19-1; PGJ19-2; PGJ19-3
- Designation LED Type: LED-FOG [~H8/H11/H16]
- Range: X-tremeUltinon LED
- Technical features: AirFlux, IP65, SafeBeam
- Technology: LED
- Type: H8, H11, H16

## Lifetime

- Life time: Up to 12 years

## Light characteristics

- Color temperature: Up to 6500 K
- Lumens: 1200 lm

## Electrical characteristics

- Wattage: 10 W
- Voltage: 12 V

## Ordering information

- Order entry: 12794UNIX2
- Ordering code: 39739031

## Packaging Data

- Packaging type: X2
- EAN1: 8727900397390
- EAN3: 8727900397406



Issue date 2023-12-29

Version: 20.2.1

© 2023 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)

\* It is your own responsibility to ensure that the use of the LED retrofit lights complies with applicable local legal requirements.